




FX-232ADP COMMUNICATION ADAPTER USER'S GUIDE

JY992D48801B


This manual contains text, diagrams and explanations which will guide the reader in the correct installation and operation of the FX-232ADP and should be read and understood before attempting to install or use the unit. Further information can be found in the FX SERIES PROGRAMMING MANUAL and FX SERIES HARDWARE MANUAL.

1 INTRODUCTION

- The FX-232ADP type RS232C adapter (hereinafter called 232ADP) is connected to the FX(V3.07 or later), FX2c series PC to exchange serial data with a personal computer, barcode reader, printer, and other various RS232C devices.
- Only one 232ADP unit can be connected to one base unit to the serial port provided at the left side.
- The buffer size and location are specified by an RS instruction in the PC.
- This product cannot be combined with special adapters such as FX-8AV, FX2-40AP/AW, or the like.




EXTERNAL DIMENSIONS



2 TERMINAL LAYOUTS

The connector is a 25-pin D-SUB type, and the pin configuration is as shown below.



Pin No.	Function
1	Frame ground
2	Send data (232ADP to RS232C device)
3	Receive data (RS232C device to 232ADP)
4 · 5	Not used
6	Shows RS232C device is ready to receive
7	Signal ground
8	ON when carrier is detected for data reception
20	Signal requesting preparation for data sending to RS232C device.

3 INSTALLATION NOTES AND USAGE

Performance specification

Transmission standard	Conforming to RS232C, 25pin D-SUB, connector used	
Isolation method	Photo coupler isolation	
Transmission distance	15m or less (shielded cable recommended)	
Current consumption	DC 5V 200mA from base unit	
Related flag and data registers	M8121:Send wait flag	D8120:Communication format
	M8122:Send flag	D8122:Remainder of send data
	M8123:Receive completion	D8123:Number of received data
	M8124:Carrier detection	D8124:Header byte
	M8161:8 bits/16 bits changeover	D8125:Terminator byte

General specification

General specifications (excluding following)	Same as those for the FX or FX2C base unit	
Dielectric withstand voltage	500V AC, 1min	Between 25-pin D-SUB and base unit
Insulation resistance	500V DC, 1MΩ by Megger	unit

- For data transmission to be effective it is necessary to match the communication format between the product and the RS232C device, such as baud rate and parity.

Communication format D8120 (bit mapping)

Bit	Description	0(OFF)	1(ON)
b 0	Data length	7 bit	8 bit
b 1	Parity	(0 0) : None	(0 1) : Odd
b 2		(1 1) : Even	
b 3		Stop	1 bit
b 4	Baud rate (bps)	(0 0 1 1) : 3 0 0	(0 1 0 0) : 6 0 0
b 5		(0 1 0 1) : 1 2 0 0	(0 1 1 0) : 2 4 0 0
b 6		(0 1 1 1) : 4 8 0 0	(1 0 0 0) : 9 6 0 0
b 7		(1 0 0 1) : 1 9 2 0 0	

Bit	Description	0(OFF)	1(ON)
b 8	Header	None	D8124 ※1
b 9	Terminator	None	D8125 ※2
b 10	Not used		
b 11	Mode (Control line)	Ordinary mode	Single line mode
b 12	Control line	None	H/W
b 13	Not used		
b 14			
b 15			

- ※1 The default value is STX (02H changeable)
- ※2 The default value is ETX (03H changeable)

- The communication format is set by special data register D8120. Setting the communication format using D8120 is effective only at the time the RS instruction is driven, and therefore if changed after driving, it is not actually accepted.


- An example of setting D8120 is shown below.



H138F = 0001 0011 1000 1111 (binary)
The settings for the above program are as right

Data length	8 bit
Parity	Even
Stop	2 bit
Baud rate	9,600
Header	Used
Terminator	Used
Control line	H/W
Mode	Ordinary mode


- The control line is set by b12
b12=0 : No hardware hand shaking Send and receive are controlled by software protocol.
b12=1 : Hardware hand shaking Signal lines ER(DTR) and DR(DSR) are used to control send and receive of data



4 WIRING


- The connections of RS232C devices varies with each device being used. Check the specification of the device, and connect.

Connection examples



5 PROGRAM EXAMPLES


- Connecting 232ADP and a printer, and printing out the data sent from the PC.




- The communication format of the serial printer is as follows

Data length	8 bit
Parity	Even
Stop bit	1 bit
Baud rate	2400bps

Sequence program




Operation



- In this example, CR (H000D) and LF (H000A) are written at the end of the message. The printer moves down one line for each message.
CR Carriage Return
LF Line Feed

Note It may be necessary to set the DIP switches of your printer. Check your printer manual for how to configure the serial communications.

- Connect 232ADP and a personal computer, and exchange data with the PC



- Use the communication cable suited to the connector pin configuration of the personal computer (For representative wiring see section 4)

Preparation of software


- Use ordinary communication software (terminal emulator) or dedicated program in the personal computer

The communication format of the PC for this example is as follows


Data length	8 bit
Parity	Even
Stop bit	1 bit
Baud rate	2400

If the communication format of the software cannot be adjusted to this setting, adjust the PC and the software to be the same

Sequence program



Operation



6 DIAGNOSTICS

- If data transfer does not perform correctly when using the 232ADP, check the operation using the following programs
- Program when sending




```

M8002 [MOV H**** D8120]
M8000 [RS D0 K20 D100 K0]
M8013 [PLS M0]
M0 [SET M8122]
[END]
      
```
- Program when receiving


```

M8002 [MOV H**** D8120]
M8000 [RS D100 K0 D0 K20]
M8123 [RST M8123]
[END]
      
```
- If sending and receiving using these programs is successful, it is considered that the operation failure was due to sequence program or communication protocol error
- If not operating normally when using these programs, eliminate the cause using the flow diagrams shown following

*Write the data to be sent to D 0 to D 1 9 before operating



Guidelines for the safety of the user and protection of the FX-232ADP

- This manual has been written to be used by trained and competent personnel. This is defined by the European directives for machinery, low voltage and EMC
- If in doubt at any stage during the installation of the FX-232ADP always consult a professional electrical engineer who is qualified and trained to the local and national standards. If in doubt about the operation or use of the FX-232ADP please consult the nearest Mitsubishi Electric distributor
- Under no circumstances will Mitsubishi Electric be liable or responsible for any consequential damage that may arise as a result of the installation or use of this equipment
- All example and diagrams shown in this manual are intended only as an aid to understanding the text, not to guarantee operation. Mitsubishi Electric will accept no responsibility for actual use of the product based on these illustrative examples
- Owing to the very great variety in possible application of this equipment, you must satisfy yourself as to its suitability for your specific application

Manual number JY992D48801
Manual revision B
Date DECEMBER 1996

MITSUBISHI ELECTRIC CORPORATION
HEAD OFFICE MITSUBISHI DENKI BLDG MARUNOUCHI TOKYO 100 TELEX J24532 CABLE MELCO TOKYO
HIMEJI WORKS 840, CHIYODA CHO, HIMEJI, JAPAN