

MELSEC A Series

Programmable Logic Controller

Reference Manual

**A(1S)J71LP21(G/GE),
A(1S)J72(Q)LP25(G),
A(1S)J71BR11, A(1S)J72(Q)BR15,
A(1S)J71LR21, A(1S)J72(Q)LR25
MELSECNET/10 Network System
(Remote I/O Network)**

● SAFETY PRECAUTIONS ●

(Read these precautions before using.)

When using our product, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to our remote I/O network modules. Refer to the user's manual of the CPU module for safety precautions of the PLC system.

● SAFETY PRECAUTIONS ● shown here are classified into two, "DANGER" and "CAUTION".



DANGER

indicates an imminent hazard that, if not avoided, will result in death or serious injury.



CAUTION

indicates a hazardous situation that, if not avoided, may result in minor or moderate injury, or property damage.

Note that situations indicated by  CAUTION may lead to serious results depending on circumstances.

In any case, it is important to follow the directions for usage.

Store this manual in a handy place so that you can take it out and read it whenever necessary. Be sure to forward this to the end user.

[Precautions on System Design]



DANGER

- When the data link results in a communication error, the faulty station will be in the following status.
Using the communication status data, make an interlock circuit in the sequence program to operate the system safely.
Failure to do so may cause an accident due to a mis-output or malfunction.
 - (1) The data prior to the error is retained.
 - (2) The outputs from the remote I/O station all turn off.

[Precautions on System Design]



CAUTION

- Do not bundle control or communication cables together with main circuit or power lines, or lay them close to these lines.
Separate the cables by a distance of at least 100 mm, otherwise malfunctions may occur due to noise.

[Precautions on Mounting]



CAUTION

- Use the PLC in the environment prescribed in the general specifications in the user's manual for the CPU module to be used. Failure to do so may cause an electric shock, fire, malfunction, or damage/deterioration of the product.
- For a network module for A series, fully insert the module fixing latches at the bottom of the module into the fixing hole of the base unit to mount the module. Improper mounting may cause a malfunction, fault or drop of the module.
- For a network module for AnS series, fully insert the module fixing latches at the bottom of the module into the fixing hole of the base unit and tighten the module fixing screws with the specified torque. Failure to do so may cause a malfunction, fault or drop of the module.
- Tighten the screws within the specified torque range.
Loose tightening can cause a drop, short circuit or fault.
Overtightening can cause a drop, short circuit or fault due to damage to the screws or module.
- Before mounting or dismounting the module, always shut off the power of the whole system externally in all phases.
Not doing so may damage the product.
- Do not touch the conductive parts and electronic areas of the module directly.
Doing so can cause malfunction or failure of the module.

[Precautions on Wiring]

 **DANGER**

- Be sure to shut off the power of the whole system externally in all phases before starting installation and wiring work.
Failure to do so could result in electrical shocks and equipment damage.

 **CAUTION**

- Prevent foreign matter such as chips or wiring offcuts from entering the inside of the module.
It will cause fire, failure or malfunction
- Solder the coaxial cable connectors correctly.
Incomplete soldering can cause a malfunction.
- The communication cables connected to the modules must be placed in a duct or fixed with clamps.
Failure to do so can cause damage to the modules or cables due to the dangling or careless pulling of the cables, or result in malfunction due to poor contact of the cables.
- When disconnecting the communication cable connected to the module, do not hold and pull the cable area.
For a cable with connector(s), hold the connector connected to the module with your hand and pull it out.
Pulling the cable part with it connected to the module can cause damage to the module or cable or result in malfunction due to poor contact of the cable.

[Precautions on Startup and Maintenance]



- Do not touch terminals while the power is ON. This will cause malfunctions.



- Read this manual thoroughly and confirm the safety before starting online operations instructed from peripheral devices to a CPU module running at other station (especially in the case of program modification, forced output or change of operation status).
Incorrect operation may cause mechanical damage or accidents.
- Never disassemble or modify the module. This may cause breakdowns, malfunctions, injuries or fire.
- Before mounting or dismounting the module, always shut off the power of the whole system externally in all phases. Failure to do so may damage the module or result in malfunctions.
- Do not touch the terminals while the power is on. Doing so may cause malfunctions.
- Before cleaning the module or retightening the terminal screws and module installation screws, always shut off the power of the whole system externally in all phases. Failure to do so may cause module breakdowns and malfunctions. Loose screws may cause the module to short-circuit, malfunction or fall off. Overtightening the screws may damage the screws and cause the module to short circuit, malfunction or fall off.
- Always make sure to touch the grounded metal to discharge the electricity charged in the body, etc., before handling the module.
Failure to do so may cause a failure or malfunctions of the module.

[Precautions on Disposal]



- Dispose of this product as industrial waste.

REVISIONS

*The manual number is given on the bottom left of the back cover.

Print Date	*Manual Number	Revision
Sep., 1994	SH (NA) 3509-A	First edition
Nov., 1997	SH (NA) 3509-B	<p>Correction Section 1.6, 2.2, 4.3.2, 7.2.1, 8.2, 10.3</p> <p>Addition Section 1.4, 11.1</p>
Jul., 2001	SH (NA) 3509-C	<p>Model addition A1SJ71LR21, A1SJ72QLP25, A1SJ72QBR15, A1SJ72QLR25</p> <p>Correction SAFETY PRECAUTIONS, MANUALS, Section 1.1, 1.2, 1.3.1, 1.4, 1.6, 2.1, 2.2, 2.3.1, 3.1, 3.2.1, 3.2.2, 3.3.1, 3.3.2, 3.4.1, 3.4.2, 3.4.3, 3.4.4, 3.4.6, 4.4.1, 5.1, 6.1, 7, 7.1.3, 7.4, 7.5.1, 7.6.1, 8.2.3, 8.2.4, 9.1.3, 10.1, 10.2.1, 10.2.2, 10.3.1, 10.3.2, 11.1,</p> <p>Addition 3.3.3, 7.6.5, WARRANTY</p>
Jun., 2003	SH (NA) 3509-D	<p>Partial additions SAFETY PRECAUTIONS, Section 3.3.2, 3.3.3, 4.4.1, 4.4.2, 10.3.2, 11.1, 11.2.1, 11.3</p>

INTRODUCTION

Thank you for choosing the Mitsubishi MELSEC-A Series of General Purpose Programmable Controllers. Please read this manual carefully so that the equipment is used to its optimum. A copy of this manual should be forwarded to the end User.

CONTENTS

1	GENERAL DESCRIPTION	1 - 1 - 1 - 13
1.1	What is a Remote I/O Network?	1 - 1
1.2	Features	1 - 2
1.3	System Configurations	1 - 7
1.3.1	Two-tier system	1 - 7
1.3.2	Multi-tier system	1 - 9
1.4	Products Required for Remote I/O Network	1 - 10
1.5	Symbols Used in the Text, Tables, and Figures	1 - 11
1.6	Special Function Modules Available for Remote I/O Stations	1 - 12
2	SPECIFICATIONS	2 - 1 - 2 - 6
2.1	Performance Specifications	2 - 1
2.2	Optical fiber cable specifications	2 - 3
2.3	Coaxial Cable	2 - 4
2.3.1	Coaxial cable	2 - 4
2.3.2	Connector for coaxial cable	2 - 5
3	PRE-OPERATION PROCEDURES	3 - 1 - 3 - 31
3.1	Pre-Operation Procedure	3 - 1
3.2	Names and Settings of External Parts	3 - 2
3.2.1	Master station (AJ71LP21 (G), AJ71BR11, AJ71LR21, A1SJ71LP21, A1SJBR11, A1SJ71LR21)	3 - 2
3.2.2	Remote I/O station (AJ72LP25 (G,GE), AJ72BR15, AJ72LR25, A1SJ72QLP25, A1SJ72QLR25, A1SJ72LQBR15)	3 - 7
3.3	Connections	3 - 12
3.3.1	Optical loop systems	3 - 12
3.3.2	Coaxial loop system	3 - 14
3.3.3	Coaxial bus system	3 - 16
3.4	Checking the Connection with Network Modules	3 - 20
3.4.1	Hardware test	3 - 21
3.4.2	Internal self-loopback test	3 - 23
3.4.3	Self-loopback test	3 - 25
3.4.4	Station-to-station test	3 - 27
3.4.5	Forward loop/reverse loop test (Optical loop system only)	3 - 29
3.4.6	Checking switch settings	3 - 31
4	STARTING OPERATION	4 - 1 - 4 - 46
4.1	Communicating with an I/O Module	4 - 1
4.1.1	Preparing for communication	4 - 1
4.1.2	Actual communication	4 - 3
4.2	Communicating with a Special Function Module	4 - 23
4.2.1	Preparing for communication	4 - 23
4.2.2	Actual communication	4 - 24
4.3	Communication Using an Intelligent Special Function Module	4 - 43

4.3.1	Preparing for communication	4 - 43
4.3.2	Precautions when using intelligent special function modules	4 - 44
4.4	Communication Using a Peripheral Device	4 - 45
4.4.1	Preparing for communication	4 - 45
4.4.2	PC No. setting method	4 - 46
5	OPERATIONS POSSIBLE AT PERIPHERAL DEVICES	5 - 1 ~ 5 - 31
5.1	Network Monitor	5 - 2
5.1.1	Line monitor	5 - 2
5.1.2	Condition monitor	5 - 12
5.1.3	Error list monitor	5 - 21
5.2	Network Diagnosis	5 - 25
5.2.1	Loop test (Optical loop system only)	5 - 26
5.2.2	Setting confirmation test	5 - 27
5.2.3	Station order confirmation test	5 - 28
5.2.4	Communication test	5 - 30
6	SYSTEM CONFIGURATIONS	6 - 1 ~ 6 - 5
6.1	Two-Tier System	6 - 1
6.2	Multi-Tier System	6 - 3
7	FUNCTIONS	7 - 1 ~ 7 - 27
7.1	Cyclic Transmission Function	7 - 2
7.1.1	Communication with an I/O module	7 - 2
7.1.2	Communication with a special function module	7 - 3
7.1.3	Stop/restart function	7 - 4
7.2	Transient Transmission Function	7 - 6
7.2.1	Communication range	7 - 6
7.2.2	Routing function	7 - 7
7.3	Reserve Station Function	7 - 10
7.4	I/O Allocation	7 - 11
7.5	Extension Function	7 - 14
7.5.1	Constant link scan function	7 - 14
7.5.2	Multiplex transmission function (Optical loop system)	7 - 16
7.5.3	Number of online return stations setting function	7 - 17
7.5.4	Number of ZNFR/ZNTO accesses setting function	7 - 17
7.6	RAS Function	7 - 19
7.6.1	Loopback function (Optical/Coaxial loop system)	7 - 19
7.6.2	Station separation function (Coaxial bus system)	7 - 22
7.6.3	Automatic online return function	7 - 23
7.6.4	Diagnosis function	7 - 24
7.6.5	Fuse brown error/I/O verify error check disable function (error clear function)	7 - 25
8	LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME	8 - 1 ~ 8 - 9
8.1	Link Data Send/Receive Processing	8 - 1
8.1.1	Outline of send/receive processing	8 - 1

8.1.2	Link data when there are faulty stations or stations where communication is stopped	8 - 3
8.1.3	Data link condition and PC CPU status	8 - 3
8.2	Transmission Delay Time	8 - 4
8.2.1	X/Y communication	8 - 4
8.2.2	ZNFR/ZNTO instructions	8 - 6
8.2.3	Link refresh time	8 - 7
8.2.4	Link scan time	8 - 8
9	NETWORK SETTINGS	9 - 1 ~ 9 - 30
9.1	Data Link Parameters	9 - 2
9.1.1	Number of modules settings	9 - 2
9.1.2	Network refresh parameters	9 - 5
9.1.3	Common parameters	9 - 10
9.1.4	I/O allocations	9 - 23
9.2	Routing Parameters	9 - 27
9.3	Precautions when the System Includes Networks Other than Remote I/O Networks	9 - 30
10	PROGRAMMING	10 - 1 ~ 10 - 31
10.1	Precautions Relating to Programming	10 - 1
10.2	Reading/Writing Data from/to Special Function Module's Buffer Memory	10 - 6
10.2.1	Reading data from buffer memory (ZNFR instruction)	10 - 6
10.2.2	Writing data to buffer memory (ZNTO instruction)	10 - 11
10.3	Special Link Relays (SB)/Registers (SW)	10 - 14
10.3.1	Special link relays (SB)	10 - 14
10.3.2	Special link registers (SW)	10 - 19
10.3.3	Effective SB/SW devices for offline diagnosis	10 - 29
10.4	Special Relays (M) and Special Registers (D) for Remote I/O Stations	10 - 29
10.4.1	Special relays (M)	10 - 29
10.4.2	Special registers (D)	10 - 30
11	TROUBLESHOOTING	11 - 1 ~ 11 - 12
11.1	Error Codes	11 - 1
11.2	Troubleshooting	11 - 7
11.2.1	Points to check first	11 - 7
11.2.2	Troubleshooting when data link is disabled throughout the system	11 - 8
11.2.3	Troubleshooting when the data link is disabled at a specific station	11 - 9
11.2.4	Troubleshooting when the communicated data is abnormal	11 - 10
11.3	LEDs on the Network Module	11 - 11
APPENDICES		APP - 1 ~ APP - 15
APPENDIX 1	NETWORK PARAMETER SETTING SHEETS	APP - 1
1.1	"Number of Modules" Settings	APP - 1
1.2	Network Refresh Parameters	APP - 2
1.3	Common Parameters (MELSECNET/10), Remote I/O Network	APP - 3
1.4	I/O Allocations	APP - 6
1.5	Routing Parameters	APP - 8

	1.6 Network Module Settings	APP – 9
APPENDIX 2	GLOSSARY	APP – 11

How to Use This Manual

This manual describes the system configuration, performance, specifications, functions, programming, etc., of the MELSECNET/10 network system. The manual is divided into three parts: GUIDANCE (Sections 1 through 5), DETAIL DESCRIPTION (Sections 6 through 11), and the APPENDIX.

GUIDANCE

It is essential to read this part if using a MELSECNET/10 remote I/O network for the first time.

1 GENERAL DESCRIPTION

- This section describes the characteristics of the remote I/O network.

2 SPECIFICATIONS

- This section gives the performance specifications and describes the data link cables.

3 PRE-OPERATION PROCEDURES

- This section describes the procedures and settings prior to establishing the data link.

4 STARTING OPERATION

- This section describes the establishment of a data link using actual system examples.

5 OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

- This section describes the monitoring and testing functions that can be performed from peripheral devices.

DETAIL DESCRIPTION

Read this part when you understand the contents of the GUIDANCE part and need more detailed information in order to design a system or carry out programming.

6 SYSTEM CONFIGURATIONS

- This section describes the device ranges and parameter setting items for configuring a system.

7 FUNCTIONS

- This section describes the functions of the system.

8 LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

- This section describes the methods for send and receive processing using the data link, the time required for processing.

9 NETWORK SETTINGS

- This section describes the parameters set at peripheral devices.

10 PROGRAMMING

- This section describes how to create programs.

11 TROUBLESHOOTING

- This section describes the corrective action to take when faults occur.

Manuals

The manuals relating to MELSECNET/10 network systems and remote I/O networks are indicated below.

Order the manuals indicated in this table if required.

Related Manuals

Manual Name	Manual Number (Model Code)
MELSECNET/10 Network System Reference Manual (PC-to-PC Network) Describes MELSECNET/10 PC-to-PC networks. (Available separately)	IB (NA) 66440
Type SW4IVD-GPPA GPP Function Software Package Operating Manual Explains the operations for parameter setting, network monitoring, network diagnosis, etc.	IB (NA) 66855


GUIDANCE

1. GENERAL DESCRIPTION

1.1 What is a Remote I/O Network?

If a machine controlled by a programmable controller is a long way from the programmable controller, the wiring is both troublesome and costly. However, it is possible to reduce the wiring requirements, cut costs, and shorten start-up time by installing the I/O portion close to the machine and connecting it in a remote I/O network.

Note that a remote I/O network is a network consisting exclusively of remote I/O stations which has an A2ASCPU and AnUCPU as the master station. Stations in a PLC to PLC network cannot be included in the same network.




1.2 Features

(1) High-speed communication


At 10 MBPS, the communication speed is as fast as in a PLC to PLC network.

(2) Large link device capacity


(a) There are 8192 points for each type of link device (LB, LW, LX, LY) in the master station.



(b) The maximum number of link points that can be allocated to one remote I/O station is 1600.




(c) The maximum number of I/O points that can be used at one remote I/O station is 2048.



(3) Large-scale systems

(a) Up to 4 network modules can be installed to one A2ASCPU or AnUCPU.




(b) The optical loop system/coaxial loop system or coaxial bus system can be selected.

1) Optical loop system/coaxial loop system

In the optical loop system, the transmission paths are not affected by noise since fiber-optic cables are used.

In the coaxial loop system, wiring can be performed easily since coaxial cables are used.

Up to 64 remote I/O stations can be connected to one master station.



Optical loop system

Fiber-Optic Cable		Station-to-Station Distance	Overall Length
SI cable	H type	300 m (984 ft.)	30 km (98425 ft.)
	L type	500 m (1640ft.)	
H-PCF cable		1 km (3281 ft.)	
Broad-band H-PCF cable		1 km (3281 ft.)	
QSI cable		1 km (3281 ft.)	
GI cable		2 km (6557 ft.)	

Coaxial loop system

Coaxial cable	Station-to-Station Distance	Overall Length
3C-2V	300 m (984 ft.)	19.2 km (62950 ft.)
5C-2V	500 m (1640 ft.)	30 km (98425 ft.)


1. GENERAL DESCRIPTION

MELSEC-A

2) Coaxial bus system


Since coaxial cables are used, wiring is easy.

Up to 32 remote I/O stations can be connected to one master station.




Coaxial Cable	Station-to-Station Distance	Overall Distance
3C-2V	300 m (984 ft.)	300 m (984 ft.)
5C-2V	500 m (1640 ft.)	500 m (1640 ft.)

By using A6BR10/A6BR10-DC repeater units, the station-to-station/overall distance can be increased to a maximum of 2.5 km (8202 ft.) (when 4 modules are used).



(c) Connections can be made without regard to the station number order.


Stations which are to be added to the system in the future (and whose numbers are therefore skipped) can be registered as reserve stations.



(d) Up to 255 networks, including PC-to-PC networks and remote I/O networks, can be connected.


1. GENERAL DESCRIPTION

- (4) When a peripheral device is connected to a remote I/O station, device monitoring and testing can be performed in the same way as if it were connected to the master station.



(5) Routing function

The routing function allows transient transmissions from a remote I/O station to stations in other networks. For example, in the system configuration shown below, station No.2 of network No.3 (PC-to-PC network) can be accessed from remote I/O station No.3 of network No.1 (remote I/O network).




(6) Perfected RAS functions

Request source


(a) Automatic return function

If a station is disconnected from the link system due to a fault, the automatic return function automatically returns it to the system and resumes data link operation after the fault is remedied.




(b) Loopback function

When a station becomes faulty or a cable is disconnected, the faulty part is bypassed by using the forward and reverse loops to maintain the data link with available stations.



(c) Station separation function

When a station is down due to power failure, the station is separated and the data link is executed with the available stations.



(d) Diagnosis functions

- **Offline diagnosis**
Used to check the hardware and cable connections.
- **Online diagnosis**
Used to check the connections, switch settings, and parameter settings from a peripheral device.
- **Network monitor**
Used to check the data link condition from a peripheral device.

REMARK

Any of the following faults activates the RAS functions.

- Cable disconnection
- Station power-off
- Network setting error
- Error that can be detected by self-diagnostics of CPU module

If the network module has become faulty, the RAS functions may not be activated depending on the fault.

1. GENERAL DESCRIPTION

1.3 System Configurations

The system can be configured as a two-tier system or as a multi-tier system

1.3.1 Two-tier system

A two-tier system is a single system in which a network module master station and remote I/O stations are connected by fiber-optic cables or coaxial cables.

(1) Optical loop system

A maximum of 64 remote I/O stations can be connected to a single master station.


The master station CPU must be an A2ASCPU or AnUCPU.

A1SJ71LP21, AJ71LP21, AJ71LP25G, AJ71LP21G

.....Master station (station No.0)

AJ72LP25, AJ72LP25G, A1SJ72QLP25

..... Remote I/O station (station Nos. 1 to 64)




(2) Coaxial loop system

A maximum of 64 remote I/O stations can be connected to a single master station.

The master station CPU must be an A2ASCPU or AnUCPU.

A1SJ71LR21, AJ71LR21..... Master station (station No.0)

AJ72LR25, A1SJ72QLR25..... Remote I/O station (station Nos. 1 to 64)




1. GENERAL DESCRIPTION

(3) Coaxial bus system

A maximum of 32 remote I/O stations can be connected to a single master station.
The master station CPU must be an A2ASCPU or AnUCPU.

A1SJ71BR11, AJ71BR11..... Master station (station No.0)
AJ72BR15, A1SJ72QBR15..... Remote I/O station (station Nos. 1 to 32)



REMARKS


The A1SJ72QLP25, A1SJ72QLR25, or A1SJ72QBR15 can be used as a remote I/O station in a remote I/O network where the AnUCPU runs as a master station. The same functions as those of AJ72LP25, AJ72LR25 and AJ72BR15 are available for any of them. Their performance specifications are also the same except for consumption current and weight.

1. GENERAL DESCRIPTION

MELSEC-A

1.3.2 Multi-tier system

A multi-tier system is a system in which multiple networks are connected.




1. GENERAL DESCRIPTION

1.4 Products Required for Remote I/O Network

To create a remote I/O network, the following listed below is necessary.

Item	Model	Applicable Software Version
Master station CPU (shown as "AnUCPU" for all)	A2UCPU A2UCPU-S1 A3UCPU A4UCPU	"N" or later * (product released in April 1994 or later)
	A2USCPU A2USCPU-S1	"D" or later * (product released in April 1994 or later)
	A2USHCPU-SI	"A" or later
	Q02CPU-A Q02HCPU-A Q06HCPU-A	"A" or later
Master station network modules	AJ71LP21, A1SJ71LP21 (for optical loop system, SI/QSI cable) AJ71BR11, A1SJ71BR11 (for coaxial bus system) AJ71LP21G, AJ71LP21GE, A1SJ71LP21GE (for optical loop system, GI cable) AJ71LR21, A1SJ71LR21 (for coaxial loop system)	A1SJ71LP21, A1SJ71BR11, AJ71LP21G, AJ71LP21GE, A1SJ71LP21GE, AJ71LR21, A1SJ71LR21 "A" or later AJ71LP21, AJ71BR11 "J" or later *
Remote I/O station network modules	AJ72LP25, A1SJ72QLP25 (for optical loop system, SI/QSI cable) AJ72BR15, A1SJ72QBR15 (for coaxial bus system) AJ72LP25G, AJ72LP25GE (for optical loop system, GI cable) AJ72LR25, A1SJ72QLR25 (for coaxial loop system)	
Peripheral device	A6GPP/A6PHP (using SW [] GP-GPPAU) A7PHP, LM700/7500 (using SW [] SRXV-GPPA) PC9801 (using SW [] NX-GPPA) DOS/V personal computer (using SW [] IVD-GPPA) Personal Computer running Windows (GX Developer Version [] installed)	
GPP function software package	SW [] GP-GPPAU SW [] SRXV-GPPA SW [] NX-GPPA SW [] IVD-GPPA GX Developer Version []	[] is 1 or higher. [] is 2 or higher. [] is 2 or higher. [] is 2 or higher. [] is 1 or higher.
Link cable Maximum distance indicated in parentheses ().	For optical loop system	SI cable, H type (300 m) (984 ft.) SI cable, L type (500 m) (1640 ft.) H-PCF cable (1 km) (3281 ft.) Broad-band H-PCF cable (1km) (3281 ft.) QSI cable (1 km) (3281 ft.) GI cable (2 km) (6557ft.)
	For coaxial bus/loop system	3C-2V (300 m) (984 ft.) 5C-2V (500 m) (1640 ft.)
Terminal resistances (Required for a 75 Ω and coaxial bus system.)	A6RCON-R75	
*F" connector	One supplied with AJ71BR11, AJ72BR15 and A1SJ71BR11	

* How to read a module's version indication



1. GENERAL DESCRIPTION

MELSEC-A

1.6 Special Function Modules Available for Remote I/O Stations

Model	Type	Occupied Slots	Number that can be Installed	Remarks	
AD70	Normal	1	64 (main base + 7 extension bases)		
AD70D			64 (main base + 7 extension bases)		
AD71 (S1/S2/S7)			64 (main base + 7 extension bases)		
AD72		2	32 (main base + 7 extension bases)		
AD75P1/P2/P3-S3			32 (main base + 7 extension bases)		
AD75M1/M2/M3		1	32 (main base + 7 extension bases)		
AD76			64 (main base + 7 extension bases)		
A61LS			64 (main base + 7 extension bases)		
A62LS		2	32 (main base + 7 extension bases)		
AD61 (S1)			64 (main base + 7 extension bases)		
A68AD (S2)		1	64 (main base + 7 extension bases)		
A68ADN			64 (main base + 7 extension bases)		
A616AD			64 (main base + 7 extension bases)		
A60MX			Used in combination with A616AD, A616TD.		
A60MXR					
A616TD		64 (main base + 7 extension bases)			
A616MXT		2	Used in combination with A616TD.		
A62DA (S1)		1	64 (main base + 7 extension bases)		
A616DAV			64 (main base + 7 extension bases)		
A616DAI		2	64 (main base + 7 extension bases)		
A84AD			32 (main base + 7 extension bases)		
A68DAV		1	64 (main base + 7 extension bases)		
A68DAI			64 (main base + 7 extension bases)		
A68RD3			64 (main base + 7 extension bases)		
A68RD4			64 (main base + 7 extension bases)		
AD59 (S1)			64 (main base + 7 extension bases)		
A11VC		64 (main base + 7 extension bases)			
AJ71C21 (S1)		64 (main base + 7 extension bases)			
AJ71C22		64 (main base + 7 extension bases)			
A64BTL		1	64 (main base + 7 extension bases)		
AS50VS		2	32 (main base + 7 extension bases)		
AS50VS-GN			32 (main base + 7 extension bases)		
A1SD70		2	8 (main base + 1 extension bases)		
A1SD71-S2/S7			8 (main base + 1 extension bases)		
A1SD75P1/P2/P3-S3		1	16 (main base + 1 extension bases)		
A1SD75M1/M2/M3			16 (main base + 1 extension bases)		
A1S62LS			16 (main base + 1 extension bases)		
A1SD61			16 (main base + 1 extension bases)		
A1SD62			16 (main base + 1 extension bases)		
A1SD62D (S1)			16 (main base + 1 extension bases)		
A1SD64AD			16 (main base + 1 extension bases)		
A1S68AD			16 (main base + 1 extension bases)		
A1S62DA			16 (main base + 1 extension bases)		
A1S68DAV			16 (main base + 1 extension bases)		
A1S68DAI			16 (main base + 1 extension bases)		
A1S62RD3			16 (main base + 1 extension bases)		
A1S62RD4			16 (main base + 1 extension bases)		
A1S68TD			16 (main base + 1 extension bases)		
A1S63ADA			16 (main base + 1 extension bases)		
A1S66ADA			16 (main base + 1 extension bases)		
A1S64TCTT-S1			16 (main base + 1 extension bases)		
A1S64TCTTBW-S1			16 (main base + 1 extension bases)		
A1S64TCRT-S1			16 (main base + 1 extension bases)		
A1S64TCRTBW-S1			16 (main base + 1 extension bases)		
A1S62TCTT-S2			16 (main base + 1 extension bases)		
A1S62TCTTBW-S2			16 (main base + 1 extension bases)		
A1S62TCRT-S2	16 (main base + 1 extension bases)				
A1S62TCRTBW-S2	16 (main base + 1 extension bases)				
A1SD59J-S2	16 (main base + 1 extension bases)				

TypeNormal : Other than intelligent special function module
 Intelligent :Intelligent special function module

Special function modules that are NOT available.

- AD57(S1/S2) • AD58 • AD51FD(S3) • AI61 • AJ71C23(S3) • AJ71AP21/AR21 • AJ71LP21/BR11
- LP21G/LR21 • AJ71AT21B • A1SJ71AP21/AR21 • A1SJ71LP21/BR11/LR21 • A1SJ71AT21B • A1S161
- A1SJ71CMO-S3 • AD22-S1 • A1SD21-S1 • A1S71SL92N • AD35ID1 • AD35ID2 • A1S35ID1 • A1S35ID2
- AJ71PT32-S3 • AJ71T32-S3 • A1SJ71PT32-S3 • A1SJ71T32-S3

Some models have restrictions when installed to the remote I/O station. For details, refer to the user's manual of the corresponding special function module.

1. GENERAL DESCRIPTION

MELSEC-A

Model	Type	Occupied Slots	Number that can be installed	Remarks
AD57G (S3)	Intelligent	2	2 (total, including other intelligent special function modules)	
AJ71C24 (S3/S6/S8)		1	2 (total, including other intelligent special function modules)	
AJ71UC24			2 (total, including other intelligent special function modules)	
AD51 (S3)		2	2 (total, including other intelligent special function modules) (can be used within the A3H range)	Interrupt programs cannot be used.
AD51H			2 (total, including other intelligent special function modules) (can be used within the A3A range)	
AD51H-S3			2 (total, including other intelligent special function modules)	
AJ71E71-S3		1	2 (total, including other intelligent special function modules) (can be used within the A3A range)	
AJ71P41			2 (total, including other intelligent special function modules) (can be used within the A3A range)	
AJ61BT11		1	2 (total, including other intelligent special function modules)	In intelligent mode. (16 modules in I/O mode.)
A1SJ71UC24-R2 (R4/PRF)		1	2 (total, including other intelligent special function modules) (can be used within the A3A range)	
A1SD51S		2	2 (total, including other intelligent special function modules) (can be used within the A3A range)	Interrupt programs cannot be used.
A1SJ71E71-B2-S3		1	2 (total, including other intelligent special function modules) (can be used within the A3A range)	
A1SJ71E71-B5-S3			2 (total, including other intelligent special function modules) (can be used within the A3A range)	
A1SJ61BT11		1	2 (total, including other intelligent special function modules)	In intelligent mode. (16 modules in I/O mode.)

TypeNormal : Other than intelligent special function module
 Intelligent :Intelligent special function module

Special function modules that cannot be used.

- AD57(S1/S2) • AD58 • AD51FD(S3) • AI61 • AJ71C23(S3) • AJ71AP21/AR21 •AJ71LP21/BR11
- LP21G/LR21 •AJ71AT21B •A1SJ71AP21/AR21 •A1SJ71LP21/BR11/LR21 •A1SJ71AT21B •A1SI61
- A1SJ71CMO-S3 •AD22-S1 •A1SD21-S1 •A1S71SL92N •AD35ID1 • AD35ID2 •A1S35ID1 •A1S35ID2
- AJ71PT32-S3 •AJ71T32-S3 •A1SJ71PT32-S3 • A1SJ71T32-S3

Some models have restrictions when installed to the remote I/O station. For details, refer to the user's manual of the corresponding special function module.

2. SPECIFICATIONS

This section gives the specifications of network performance and cables. For general specifications, refer to the manual for the PLC CPU used in the network system.

2.1 Performance Specifications

Table 2.1 gives the performance specifications of the network system.

Table 2.1 Performance Specifications

Item	Optical Loop System (SI, QSI cable)		Coaxial Bus System	
	AJ71LP21, A1SJ71LP21	AJ72LP25, A1SJ72QLP25	AJ71BR11, A1SJ71BR11	AJ72BR15, A1SJ72QBR15
Maximum number of link points per network	LX/LY	8192 points		
	LB	8192 points		
	LW	8192 points		
Maximum number of link points per station	Master station → Remote I/O station $\left\{ \frac{LY+LB}{8} + (2 \times LW) \right\} \leq 1600$ bytes		Remote I/O station → Master station $\left\{ \frac{LX+LB}{8} + (2 \times LW) \right\} \leq 1600$ bytes	
Maximum number of I/O points per remote station	—	X+Y ≤ 2048 point	—	X+Y ≤ 2048 point
Communication speed	20 MBPS (multiplexing)/10 MBPS		10 MBPS	
Communication method	Token ring method		Token bus method	
Synchronizing method	Frame synchronous communication			
Coding method	NRZI coding (Non Return to Zero Inverted)		Manchester coding	
Type of transmission channel	Duplex loop		Single bus	
Transmission format	Conforms to HDLC (frame type)			
Maximum number of networks	255 (total with the PC-to-PC network)			
Number of stations available for a network	65 stations (master: 1 ; remote I/O: 64)		33 stations (master: 1 ; remote I/O: 32)	
Overall length of a network (Station-to-station)	30 km	$\left(\begin{array}{l} \text{Station-to-station:} \\ \text{SI cable H type: 300m (984 ft.)} \\ \text{SI cable L type: 500m (1640 ft.)} \\ \text{H-PCF cable, broadband H-PCF} \\ \text{cable or QSI cable: 1km (3281 ft.)} \end{array} \right)$	3C-2V	300 m (984 ft.) (Station-to-station: 300 m (984 ft.))
			5C-2V	500 m (1640 ft.) (Station-to-station: 500 m (1640 ft.))
Error control method	Retry by CRC ($X^{16}+X^{12}+X^5+1$) and time out			
RAS functions	<ul style="list-style-type: none"> • Loopback in case of error detection or cable disconnection. (available with optical/coaxial loop system only) • Self-diagnosis function of link line. • Error detection by using special relays and registers. • Network monitor and diagnostic functions 			
Transient transmission	• Monitoring with peripheral modules, program uploading and downloading			
Current consumption (5 VDC)	0.65 A	AJ72LP25: 0.8 A A1SJ72QLP25: 0.52 A	0.8 A	AJ72BR15: 0.9 A A1SJ72QBR15: 0.7 A
Weight	AJ71LP21: 0.45 kg (0.99 lb) A1SJ71LP21: 0.33 kg (0.73 lb)	AJ72LP25: 0.53 kg (1.67 lb) A1SJ72QLP25: 0.4 kg (0.90 lb)	AJ71BR11: 0.45 kg (0.99 lb) A1SJ71BR11: 0.33 kg (0.73 lb)	AJ72BR15: 0.60 kg (1.32 lb) A1SJ72QBR15: 0.43 kg (0.95 lb)
Number of occupying I/O points	32 points	—	32 points	—

* JIS: Japanese Industrial Standard

2. SPECIFICATIONS

MELSEC-A

Table 2.1 Performance Specifications (continued)

Item	Optical Loop System (GI cable)		Coaxial Loop System	
	AJ71LP21GE, A1SJ71LP21GE, AJ71LP21G	AJ72LP25G, AJ72LP25GE	AJ71LR21, A1SJ71LR21	AJ72LR25, A1SJ72QLR25
Maximum number of link points per network	LX/LY	8192 points		
	LB	8192 points		
	LW	8192 points		
Maximum number of link points per station	Master station → Remote I/O station $\left\{ \frac{LY+LB}{8} + (2 \times LW) \right\} \leq 1600$ bytes		Remote I/O station → Master station $\left\{ \frac{LX+LB}{8} + (2 \times LW) \right\} \leq 1600$ bytes	
Maximum number of I/O points per remote station	—	X + Y ≤ 2048 point	—	X + Y ≤ 2048 point
Communication speed	20 MBPS (multiplexing)/10 MBPS			
Communication method	Token ring method			
Synchronizing method	Frame synchronous communication			
Coding method	NRZI coding (Non Return to Zero Inverted)		Manchester coding	
Type of transmission channel	Duplex loop		Duplex loop	
Transmission format	Conforms to HDLC (frame type)			
Maximum number of networks	255 (total with the PC-to-PC network)			
Number of stations connected to a network	65 stations (master: 1 ; remote I/O: 64)			
Overall length of a network (Station-to station)	30 km (Station-to-station: 2 km (6553 ft.) when GI cable is used)		3C-2V	19.2 km (62950 ft.) (Station-to-station: 300 m (984 ft.))
			5C-2V	30 km (98360 ft.) (Station-to-station: 500 m (1640 ft.))
Error control method	Retry by CRC ($X^{16}+X^{12}+X^5+1$) and time out			
RAS functions	<ul style="list-style-type: none"> • Loopback in case of error detection or cable disconnection. (available with optical/coaxial loop system only) • Self-diagnosis function of link line. • Error detection by using special relays and registers. • Network monitor and diagnostic functions 			
Transient transmission	• Monitoring with peripheral modules, program uploading and downloading			
Current consumption (5 VDC)	0.65 A	0.8 A	AJ71LR21: 1.20 A A1SJ71LR21: 1.14 A	AJ72LR25: 1.3 A A1SJ72QLR25: 1.24 A
Weight	AJ71LP21G, AJ71LP21GE: 0.45 kg (0.99 lb) A1SJ71LP21GE: 0.33 kg (0.73 lb)	0.53 kg (1.17 lb)	AJ71LR21: 0.45 kg (0.99 lb) A1SJ71LR21: 0.30 kg (0.66 lb)	AJ72LR25: 0.60 kg (1.32 lb) A1SJ72QLR25: 0.42 kg (0.92 lb)
Number of occupying I/O points	32 points	—	32 points	—

* JIS: Japanese Industrial Standard

2. SPECIFICATIONS

2.2 Optical fiber cable specifications

The following is the specifications for the optical fiber cable used in the MELSECNET/H loop system. Check and confirm that proper cable is used.

These optical fiber cables and connectors are specially-designed products and available from MITSUBISHI ELECTRIC SYSTEM & SERVICE CO. LTD. (Related catalogues are also available.)

MITSUBISHI ELECTRIC SYSTEM & SERVICE CO. LTD. also provides installation service. For details, contact your local sales representative.

Table2.2 Optical fiber cable specifications

Item	SI (Multi-particulate glass)	H-PCF (Plastic-clad)	Broad-band H-PCF (Plastic-clad)	QSI (Quartz glass)	QI-50/125 (Quartz glass)	QI-62.5/125 (Quartz glass)
Interstation distance	500m	1km	1km	1km	2km	2km
Transmission loss	12dB/km	6dB/km	5dB/km	5.5dB/km	3dB/km	3dB/km
Core diameter	200µm	200µm	200µm	185µm	50µm	62.5µm
Clad diameter	220µm	250µm	250µm	230µm	125µm	125µm
Primary membrane	250µm	—	—	250µm	—	—
Applicable connector	F06/F08 or equivalent (Conformed to JIS C5975/5977)					

REMARK

Prepare the following types of optical cables.

A type: Cable for connection inside control panel.

B type: Cable for connections between outside control panels.


C type: Cable for outdoor connections.

D type: Cable for outdoor connections that have been reinforced.

There are special cables available for moveable applications and resistance to heat.

Contact your MITSUBISHI ELECTRIC SYSTEM & SERVICE CO. LTD. for details.

(1) Transmission loss of GI-62.5/125 optical fiber cable



*1: Conversion cable

Conversion Type	Cable
CA type↔FC type	AGE-1P-CA/FC1.5M-A
CA type↔ST type	AGE-1P-CA/ST1.5M-A
CA type↔SMA type	AGE-1P-CA/SMA1.5M-A

Available from: Mitsubishi Electric Europe GmbH

2.3 Coaxial Cable


This section gives the specifications of coaxial cable used for the coaxial data link.

The coaxial cables used are high-frequency coaxial cables "3C-2V" and "5C-2V" (conforming to JIS C 3501).

2.3.1 Coaxial cable

Table 2.3 gives the specifications of the coaxial cable.

Table 2.3 Coaxial Cable

Item	3C-2V	5C-2V
Construction	 <p>The diagram shows a cross-section of a coaxial cable. From left to right, it consists of: an internal conductor (hatched pattern), an insulator (solid white), an external conductor (cross-hatched pattern), and a sheath (solid white). Labels with leader lines point to each of these four components.</p>	
Cable diameter	5.4 mm (0.21 in)	7.4 mm (0.29 in)
Allowable bending radius	22 mm (0.87 in) or more	30 mm (1.18 in) or more
Diameter of internal conductor	0.5 mm (0.02 in) (Annealed copper wire)	0.8 mm (0.03 in) (Annealed copper wire)
Diameter of insulator	3.1 mm (0.12 in) (Polyethylene)	4.9 mm (0.19 in) (Polyethylene)
Diameter of external conductor	3.8 mm (0.15 in) (Single annealed copper wire mesh)	5.6 mm (0.22 in) (Single annealed copper wire mesh)
Applicable connector plug	Connector plug for 3C-2V (BNC-P-3-Ni-CAU is recommended.)	Connector plug for 5C-2V (BNC-P-5-Ni-CAU is recommended.)

2.3.2 Connector for coaxial cable

The following explains the structure and connecting procedures of the BNC connector for the coaxial cable.

(1) Structure of the BNC connector and the coaxial cable

Fig. 2.1 shows the structure of the BNC connector and the coaxial cable.






Fig. 2.1 Structure of the BNC Connector and the Coaxial Cable

(2) Connecting the BNC connector with the coaxial cable


(a) Remove the outer sheath of the end of the coaxial cable as shown below.




(b) Slip a nut, a washer, a gasket, and a clamp on the coaxial cable as shown below, and loosen the outer conductor.




(c) Cut the outer conductor, insulator, and internal conductor to specified dimensions shown below. Cut the outer conductor and extend it over the end of the clamp.



(d) Solder the contact to the tip of the internal conductor.



(e) Insert the contact assembly in the plug shell, and engage the plug shell with the nut.




- Observe the following when soldering the contact to the internal conductor.
- Soldered part must not have excess solder mound.
 - The tail end of the contact must come into close contact with the cut end of the insulator. The contact must not be cutting in the insulating material.
 - Neither clearance nor bite between the contact and the cable insulator is allowed.
 - Apply solder quickly so that the insulator may not be deformed by heat.

3. PRE-OPERATION PROCEDURES

This section describes the procedures, settings, connections and tests required to establish a data link.

3.1 Pre-Operation Procedure

The following flow chart shows the procedures leading to the establishment of a data link.




3. PRE-OPERATION PROCEDURES

MELSEC-A


3.2 Names and Settings of External Parts

3.2.1 Master station (AJ71LP21 (G,GE), AJ71BR11, AJ71LR21, A1SJ71LP21 (GE), A1SJBR11, A1SJ71LR21)


(1) AJ71LP21 (G,GE)



(2) AJ71BR11




(3) AJ71LR21




3. PRE-OPERATION PROCEDURES

MELSEC-A

(4) A1SJ71LP21 (GE)



(5) A1SJ71BR11



(6) A1SJ71LR21








Table 3.1 Names of Parts and Settings

No.	Name	Description				
(1)	LED	No.	Name	State	Description	
	AJ71LP21 (G, GE)/AJ71LR21		1	RUN	Lit	Normal state
					Unlit	WDT error, SP. UNIT ERROR
			2	PC	Lit	Setting for a PC-to-PC network is made. (SW1: OFF)
	3	REMOTE	Setting for a remote I/O network is made. (SW1: ON)			
	4	DUAL	Multiplexing being executed. (Unlit: Multiplexing not executed.)			
	5	SW.E	Switch settings with (2) to (6) have abnormality.			
	6*1	M/S.E	Two same station numbers or two master stations are set in a network.			
	7	PRM.E	The network refresh parameter settings are duplicated (when more than one module is installed).			
	8	POWER	Power is supplied. (Unlit: Power is not supplied.)			
	9	MNG	Set as a master station.			
	10	S.MNG				
	11	D.LINK	Data link is operative. (Unlit: Data link is inoperative.)			
	12	T.PASS	Baton passing being executed. (Transient transmission possible)			
	13	CPU R/W	Communicating with the CPU.			
	14	CRC	Code check error in received data. <Causes> Timing when the station which is sending data to a specific station is set off-line, hardware fault, cable fault, noise, etc.			
	15	OVER	Processing of received data delayed. <Causes> Hardware fault, cable fault, noise, etc.			
	16	AB. IF	<ul style="list-style-type: none"> "1"s in the number larger than specified are received consecutively. Received data length is shorter than specified. <Causes> Timing when the station which is sending data to a specific station is set off-line, WDT setting is too short, cable fault, noise, etc.			
	17	TIME	Data link WDT error. <Causes> WDT setting is too short, cable fault, noise, etc.			
	18	DATA	Abnormal data larger than 2 kbytes are received. <Causes> Cable fault, noise, etc.			
	19	UNDER	Internal processing of send data is not at constant intervals. <Causes> Hardware fault			
	20	LOOP	The forward or reverse loop is faulty. (F.E.: F loop error, R.E.: R loop error) <Causes> Power to the adjacent station is OFF. Cable breakage or not connected, etc.			
	21	F.E.	Dimly lit	Data being transmitted.		
	22	R.E.		Data being transmitted.		
23	SD					
24*2	RD					
AJ71BR11						
A1SJ71LP21 (GE)/A1SJ71LR21						
A1SJ71BR11						

*1. The M/S.E LED may not light depending on the line or cable connections even if station No. or control station is duplicated in a network. Execute on-line diagnosis as well as visually check the system.

*2. When using an AJ71BR11/A1SJ71BR11, if there are no terminal resistances RD may be lit all the time, regardless of whether the data link is operative; this does not mean that there is a network module error.

Table 3.1 Names of Parts and Settings (Continued)






No.	Name	Description																																																			
(2) *3	<p>Network number setting switches</p> 	<p>Setting of network number (Factory setting: 001) <Setting range> 1 to 255: Network number Other than 1 to 255: Setting error (SW.E LED is lit.)</p>																																																			
(3) *3	<p>Group number setting switch</p> 	<p>Setting of group number (Factory setting: 0) <Setting> range Not used (ignored)</p>																																																			
(4) *3	<p>Station number setting switches</p> 	<p>Setting of station number (Factory setting: 01) <Setting range> 0: Master station Other than 0: Setting error (SW.E LED is lit.)</p>																																																			
(5) *3	<p>Mode select switch</p> 	<p>Setting of mode (Factory setting: 0)</p> <table border="1"> <thead> <tr> <th>Mode</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>On-line (Automatic on-line return is set.)</td> <td>Automatic on-line return during data link is enabled.</td> </tr> <tr> <td>1</td> <td colspan="2">Unusable (An SW.E error occurs if these are set.)</td> </tr> <tr> <td>2</td> <td>Off-line</td> <td>Host station is set off-line.</td> </tr> <tr> <td>3</td> <td>Test mode 1</td> <td>Loop test (Forward loop)</td> </tr> <tr> <td>4</td> <td>Test mode 2</td> <td>Loop test (Reverse loop)</td> </tr> <tr> <td>5</td> <td>Test mode 3</td> <td>Station-to-station test (Master station)</td> </tr> <tr> <td>6</td> <td>Test mode 4</td> <td>Station-to-station test (Slave station)</td> </tr> <tr> <td>7</td> <td>Test mode 5</td> <td>Self-loopback test</td> </tr> <tr> <td>8</td> <td>Test mode 6</td> <td>Internal self-loopback test</td> </tr> <tr> <td>9</td> <td>Test mode 7</td> <td>Hardware test</td> </tr> <tr> <td>A</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>B</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>C</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>D</td> <td>Test mode 8</td> <td>Network number confirmation (LED indication)</td> </tr> <tr> <td>E</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>F</td> <td>Test mode</td> <td>Station number confirmation (LED indication)</td> </tr> </tbody> </table>	Mode	Name	Description	0	On-line (Automatic on-line return is set.)	Automatic on-line return during data link is enabled.	1	Unusable (An SW.E error occurs if these are set.)		2	Off-line	Host station is set off-line.	3	Test mode 1	Loop test (Forward loop)	4	Test mode 2	Loop test (Reverse loop)	5	Test mode 3	Station-to-station test (Master station)	6	Test mode 4	Station-to-station test (Slave station)	7	Test mode 5	Self-loopback test	8	Test mode 6	Internal self-loopback test	9	Test mode 7	Hardware test	A	_____	Unusable	B	_____	Unusable	C	_____	Unusable	D	Test mode 8	Network number confirmation (LED indication)	E	_____	Unusable	F	Test mode	Station number confirmation (LED indication)
		Mode	Name	Description																																																	
		0	On-line (Automatic on-line return is set.)	Automatic on-line return during data link is enabled.																																																	
		1	Unusable (An SW.E error occurs if these are set.)																																																		
		2	Off-line	Host station is set off-line.																																																	
		3	Test mode 1	Loop test (Forward loop)																																																	
		4	Test mode 2	Loop test (Reverse loop)																																																	
		5	Test mode 3	Station-to-station test (Master station)																																																	
		6	Test mode 4	Station-to-station test (Slave station)																																																	
		7	Test mode 5	Self-loopback test																																																	
		8	Test mode 6	Internal self-loopback test																																																	
		9	Test mode 7	Hardware test																																																	
		A	_____	Unusable																																																	
B	_____	Unusable																																																			
C	_____	Unusable																																																			
D	Test mode 8	Network number confirmation (LED indication)																																																			
E	_____	Unusable																																																			
F	Test mode	Station number confirmation (LED indication)																																																			

*3. After changing settings, reset the ACPU.

*4. In the case of AJ71BR11, an SW.E error occurs if these are set.

*5. Resetting of the ACPU is not necessary for mode settings D and F.

Table 3.1 Names of Parts and Settings (Continued)

No.	Name	Description																												
(6) *6 	Condition setting switches	Setting of operating conditions (Factory setting: all set to OFF) <table border="1" data-bbox="571 353 1441 703"> <thead> <tr> <th>SW</th> <th>Description</th> <th>OFF</th> <th>ON</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Network type</td> <td>PC-to-PC network (PC)</td> <td>Remote I/O network (REMOTE)</td> </tr> <tr> <td>2</td> <td>Station type</td> <td colspan="2" rowspan="5">Setting not necessary</td> </tr> <tr> <td>3</td> <td>Parameters</td> </tr> <tr> <td>4</td> <td>Number of stations</td> </tr> <tr> <td>5</td> <td>Number of stations</td> </tr> <tr> <td>6</td> <td>Total number of B/W points</td> </tr> <tr> <td>7</td> <td>Total number of B/W points</td> <td colspan="2"></td> </tr> <tr> <td>8</td> <td>Not used</td> <td colspan="2">Always OFF</td> </tr> </tbody> </table>	SW	Description	OFF	ON	1	Network type	PC-to-PC network (PC)	Remote I/O network (REMOTE)	2	Station type	Setting not necessary		3	Parameters	4	Number of stations	5	Number of stations	6	Total number of B/W points	7	Total number of B/W points			8	Not used	Always OFF	
	SW	Description	OFF	ON																										
	1	Network type	PC-to-PC network (PC)	Remote I/O network (REMOTE)																										
	2	Station type	Setting not necessary																											
	3	Parameters																												
	4	Number of stations																												
	5	Number of stations																												
	6	Total number of B/W points																												
	7	Total number of B/W points																												
8	Not used	Always OFF																												
(7)	Connector	Connect fiber optic cables to an AJ71LP21 (G,GE)/A1SJ71LP21 (GE), an F connector to an AJ71BR11/A1SJ71BR11, and a coaxial cable to an AJ71LR21/A1SJ71LR21. 																												
	(8)	LED indication select switch A1SJ71LP21 (GE)/A1SJ71LR21  A1SJ71BR11 	Used to select between the LED indications.  <p>*CPU R/W is displayed regardless of the switch position.</p>																											

*6..... Reset the ACPU if the setting has been changed while the power of the ACPU is ON.

3. PRE-OPERATION PROCEDURES


MELSEC-A

3.2.2 Remote I/O station (AJ72LP25 (G,GE), AJ72BR15, AJ72LR25, A1SJ72QLP25, A1SJ72QLR25, A1SJ72QBR15)

(1) AJ72LP25 (G)

(2) AJ72BR15

(3) AJ72LR25




* Do not touch the DIP switches on the printed circuit board at the side face of the module.


3. PRE-OPERATION PROCEDURES

MELSEC-A

(4) A1SJ72QLP25



(5) A1SJ72QLR25



(6) A1SJ72QBR15




Table 3.2 Names of Parts and Settings

No.	Name	Description			
(1)	LED	No.	Name	State	Description
	AJ72LP25 (G,GE)/AJ72LR25	1	RUN	Lit	Normal state
				Unlit	WDT error, SP. UNIT ERROR
		2	RMT.E.	Lit	Blown fuse, I/O verification error (host station)
		3	DUAL		Multiplex transmission being executed. (Unlit: Multiplex transmission not executed.)
		4	SW.E		Switch settings of (3) and (4) are abnormal.
		5*1	ST.E		Two same station numbers or two master stations are set in a network.
		6	PRM.E		<ul style="list-style-type: none"> I/O allocations abnormal Insufficient LB/LW points (special function module) Parameters received from the master station are abnormal
		7	POWER		Power is supplied. (Unlit: Power is not supplied.)
		8	D.LINK		Data link is operative. (Unlit: Data link is inoperative.)
		9	T.PASS		Baton passing being executed. (Transient transmission possible)
		10	WAIT		Waiting for communication with a special function module
		11	CRC		Code check error in received data. <Causes> Timing of disconnection of data-sending station, hardware fault, cable fault, noise, etc.
		12	OVER		Processing of received data delayed. <Causes> Hardware fault, cable fault, noise, etc.
		13	AB. IF		<ul style="list-style-type: none"> Consecutive "1" more than specified is received. Received data length is shorter than specified. <Causes>Timing of disconnection of data-sending station, WDT setting is too short, cable fault, noise, etc.
		14	TIME		Data link WDT times out. <Causes> WDT setting is too short, cable fault, noise, etc.
		15	DATA		Abnormal data larger than 2 kbytes are received. <Causes> Cable fault, noise, etc.
		16	UNDER		Internal processing of send data is not at constant intervals. <Causes> Hardware fault
		17	LOOP		The forward or reverse loop is faulty. (F.E.: F loop error, R.E.: R loop error) <Causes> Power to the adjacent station is OFF. Cable breakage or not connected, etc.
		21	F.E		Dimly lit
	22	R.E	Data being transmitted.		
	18	SD	Unlit		Lit in Q4AR output hold mode
	19*2	RD			
	20	HOLD			






*1..... "ST.E" may not light up depending on the condition of lines or cable connections even if a station number is duplicated in a network. Execute both the setting check test of on-line diagnosis and visual check to confirm the correct status.

*2..... When no terminal resistor is installed to AJ72BR15, "RD" may be lit all the time whether data link is operative or not. (This does not indicate any failure of the network module.)

3. PRE-OPERATION PROCEDURES

MELSEC-A

Table 3.2 Names of Parts and Settings (Continued)



No.	Name	Description																																																					
(2)	RESET switch 	Used to reset the hardware.																																																					
(3) *3	Station number setting switches STATION NO. X10  X1 	Setting of station number (Factory setting: 01) <Setting range> 1 to 64: Station number Other than 1 to 64: Setting error (SW.E LED is lit.)																																																					
(4) *3	Mode select switch MODE 0: ONLINE(A.R) 1: ONLINE(U.R) 2: OFFLINE 	Setting of mode (Factory setting: 0)																																																					
		<table border="1"> <thead> <tr> <th>Mode</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>On-line (Automatic on-line return is set.)</td> <td>Automatic on-line return during data link is enabled.</td> </tr> <tr> <td>1</td> <td>Unusable (An SW.E error occurs if these are set.)</td> <td></td> </tr> <tr> <td>2</td> <td>Off-line</td> <td>Host station is set off-line.</td> </tr> <tr> <td>3</td> <td>Test mode 1</td> <td>Loop test (Forward loop)</td> </tr> <tr> <td>4</td> <td>Test mode 2</td> <td>Loop test (Reverse loop)</td> </tr> <tr> <td>5</td> <td>Test mode 3</td> <td>Station-to-station test (Master station)</td> </tr> <tr> <td>6</td> <td>Test mode 4</td> <td>Station-to-station test (Slave station)</td> </tr> <tr> <td>7</td> <td>Test mode 5</td> <td>Self-loopback test</td> </tr> <tr> <td>8</td> <td>Test mode 6</td> <td>Internal self-loopback test</td> </tr> <tr> <td>9</td> <td>Test mode 7</td> <td>Hardware test</td> </tr> <tr> <td>A</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>B</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>C</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>D</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>E</td> <td>_____</td> <td>Unusable</td> </tr> <tr> <td>*4</td> <td>*5</td> <td>F</td> <td>Test mode 8</td> <td>Station number confirmation (LED indication)</td> </tr> </tbody> </table>	Mode	Name	Description	0	On-line (Automatic on-line return is set.)	Automatic on-line return during data link is enabled.	1	Unusable (An SW.E error occurs if these are set.)		2	Off-line	Host station is set off-line.	3	Test mode 1	Loop test (Forward loop)	4	Test mode 2	Loop test (Reverse loop)	5	Test mode 3	Station-to-station test (Master station)	6	Test mode 4	Station-to-station test (Slave station)	7	Test mode 5	Self-loopback test	8	Test mode 6	Internal self-loopback test	9	Test mode 7	Hardware test	A	_____	Unusable	B	_____	Unusable	C	_____	Unusable	D	_____	Unusable	E	_____	Unusable	*4	*5	F	Test mode 8	Station number confirmation (LED indication)
		Mode	Name	Description																																																			
		0	On-line (Automatic on-line return is set.)	Automatic on-line return during data link is enabled.																																																			
		1	Unusable (An SW.E error occurs if these are set.)																																																				
		2	Off-line	Host station is set off-line.																																																			
		3	Test mode 1	Loop test (Forward loop)																																																			
		4	Test mode 2	Loop test (Reverse loop)																																																			
		5	Test mode 3	Station-to-station test (Master station)																																																			
		6	Test mode 4	Station-to-station test (Slave station)																																																			
		7	Test mode 5	Self-loopback test																																																			
		8	Test mode 6	Internal self-loopback test																																																			
		9	Test mode 7	Hardware test																																																			
		A	_____	Unusable																																																			
		B	_____	Unusable																																																			
C	_____	Unusable																																																					
D	_____	Unusable																																																					
E	_____	Unusable																																																					
*4	*5	F	Test mode 8	Station number confirmation (LED indication)																																																			
(5)		Always OFF at SW1 to 5.																																																					

*3..... If the setting has been changed while the power to the remote I/O station was ON, re-set by using the RESET switch: (2) in the table above.

*4..... In the case of AJ72BR15, an SW.E. error occurs if these are set.

*5..... "F" does not have to be reset with the RESET switch.

Table 3.2 Names of Parts and Settings (Continued)

No.	Name	Description						
(6)	RS-422 interface 	Used to connect peripheral devices. (Available only for peripheral devices using GPP function software package for remote I/O networks (see Section 1.4).)						
(7)	Connector	Connects fiber optic cable to an AJ72LP25 (G,GE)/A1SJ72QLP25, F connector to an AJ72BR15/A1SJ72QBR15, a coaxial cable to an AJ72LR25/A1SJ72QLR25. 						
(8)	Display select switch	Used to select the CRC to UNDER error indications between the forward and reverse loops and to select between the RUN to F.E. and PW to R.E. indications (factory setting: L position) <table border="1" data-bbox="568 1469 1439 1787"> <thead> <tr> <th data-bbox="568 1469 938 1509">Switch position</th> <th data-bbox="938 1469 1439 1509">Description</th> </tr> </thead> <tbody> <tr> <td data-bbox="568 1509 938 1653">L (F.L.)</td> <td data-bbox="938 1509 1439 1653">LEDs (CRC through UNDER) indicate the forward loop status and RUN to F.E. indications are set to be valid. (PW-to-R.E is NOT valid.)</td> </tr> <tr> <td data-bbox="568 1653 938 1792">R (R.L.)</td> <td data-bbox="938 1653 1439 1792">LEDs (CRC through UNDER) indicate the reverse loop status and PW-to-R.E indications are set to be valid. (RUN-to-F.E is NOT valid.)</td> </tr> </tbody> </table>	Switch position	Description	L (F.L.)	LEDs (CRC through UNDER) indicate the forward loop status and RUN to F.E. indications are set to be valid. (PW-to-R.E is NOT valid.)	R (R.L.)	LEDs (CRC through UNDER) indicate the reverse loop status and PW-to-R.E indications are set to be valid. (RUN-to-F.E is NOT valid.)
Switch position	Description							
L (F.L.)	LEDs (CRC through UNDER) indicate the forward loop status and RUN to F.E. indications are set to be valid. (PW-to-R.E is NOT valid.)							
R (R.L.)	LEDs (CRC through UNDER) indicate the reverse loop status and PW-to-R.E indications are set to be valid. (RUN-to-F.E is NOT valid.)							

3.3 Connections

3.3.1 Optical loop systems

(1) Precautions on making connections

(a) The usable fiber-optic cable type is determined depending on the interstation distance.

Type		Interstation Distance (m)		
		AJ71LP21, A1SJ71LP21 AJ72LP25, A1SJ72QLP25	AJ71LP21G AJ72LP25G	AJ71LP21GE A1SJ71LP21GE AJ72LP25GE
SI fiber-optic cable (Old type: A-2P-□)	L type	500	Not available	Not available
	H type	300		
SI fiber-optic cable		500		
H-PCF fiber-optic cable		1000		
Broad-band H-PCF fiber-optic cable		1000		
QSI fiber-optic cable		1000		
GI-50/125 fiber-optic cable		Not available	2000	Not available
GI-62.5/125 fiber-optic cable		Not available	Not available	2000

(b) When using the optical fiber cable, the cable bending radius is limited. For details, check the cable to be used.

(c) When installing the fiber-optic cables, do not touch the cable core of the cable-side and module-side connectors and keep dirt or dust away from it. Hand oil, dust and/or dirt may increase transmission loss, resulting in a data link error.

(d) When installing/removing the fiber-optic cable, hold the cable connector by hand directly.

(e) Connect the cable connector and module connector securely until they "click".

3. PRE-OPERATION PROCEDURES


MELSEC-A

(2) Connection method


Connect fiber-optic cables as shown below.

The connections do not have to follow the station No. order.

(a) AJ71LP21, A1SJ71LP21, AJ72LP25, AJ71LP21G, AJ72LP25GE



(b) AJ71LP21GE, A1SJ71LP21GE, AJ72LP25GE




POINT

Designate stations reserved for future use (those included in the total number of stations but not actually connected) as reserved stations. This prevents the stations from being detected as abnormal stations, and it does not affect the link scan time.

REMARKS

When the interstation distance exceeds the limit in the optical loop system, changing the connection order of the stations can shorten the distance as shown below.



Connection not allowed between No. 1 and No. 5.

3. PRE-OPERATION PROCEDURES

3.3.2 Coaxial loop system

(1) Precautions on connections


(a) Restrictions on the interstation cable length

- 1) For connection between network modules, use the cable length given in the following table depending on the cable type.

Cable Type	Interstation Cable Length	Overall Distance
3C-2V	300 m	19.2 km
5C-2V	500 m	30.0 km

(b) Notes on cabling


- 1) Run coaxial cables at least 100mm away from the other power and control cables.
- 2) When intensive influence by noise is expected, use of double-shielded coaxial cables is recommended.



A 5C-2V connector plug can be applied to the doubly shielded coaxial cable. Connect the 5V-2C connector plug to the coaxial cable in the inside of the doubly shielded coaxial cable. Ground the shield part in the outside of the doubly shielded coaxial cable as shown above.

(c) Coaxial cables have the following limitations on the bending radius.

Cable Type	Allowable bending radius r [mm] (inch)
3C-2V	23 (0.91)
5C-2V	30 (1.18)



- (d) Do not pull the connected coaxial cable. Doing so may cause poor contact or cable disconnection.


3. PRE-OPERATION PROCEDURES

MELSEC-A

(2) Connection method

Connect coaxial cables as shown below.

They need not be connected in the order of station number.




POINT

Designate stations reserved for future use (those included in the total number of stations but not actually connected) as reserved stations. This prevents the stations from being detected as abnormal stations, and it does not affect the link scan time.

REMARKS

When the interstation distance exceeds the limit in the optical loop system, changing the connection order of the stations can shorten the distance as shown below.



Connection not allowed between No. 1 and No. 5.

3.3.3 Coaxial bus system

(1) Precautions for cable connections

(a) The restrictions to the cable length


- 1) When building an coaxial bus system, cables of different lengths must be used according to the total number of stations. If cables other than those specified below are used, communication errors may occur.

Number of Connected Stations	Applicable Cable	Overall Length	Interstation Cable Length
2 to 9 stations	3C-5V	300 m	1 to 300m (less than 1m not allowed.)
	5C-2V	500 m	1 to 500m (less than 1m not allowed.)
10 to 32 stations	3C-2V	300 m	1 to 5m (less than 1m not allowed.)
			13 to 17 m
			25 to 300 m
	5C-2V	500 m	1 to 5m (less than 1m not allowed.)
			13 to 17 m
			25 to 500 m

- 2) If there is a possibility that the number of stations will increase, due to system expansion for example, do the necessary wiring work in advance, taking care to comply with the applicable restrictions.
- 3) If A6BR10/A6BR10-DC repeater units are used, always use the cable length indicated for 10 to 33 stations, regardless of the number of connected stations and the number of repeater units.

(b) Cautions on cabling


- 1) Coaxial cable must be laid providing a 100 mm (3.94 inch) or more clearance to power cables or control cables.
- 2) Where intensive influence by noise is expected, use of double-shielded coaxial cables is recommended.



A 5C-2V connector plug can be applied to the doubly shielded coaxial cable. Connect the 5V-2C connector plug to the coaxial cable in the inside of the doubly shielded coaxial cable. Ground the shield part in the outside of the doubly shielded coaxial cable as shown above.

(c) Coaxial cables have the following limitations on the bending radius.


Cable Type	Allowable Bending Radius r [mm] (inch)	Connector A [mm] (inch)
3C-2V	23 (0.91)	50 (1.97)
5C-2V	30 (1.18)	




Front face of the module

(d) Do not pull connected coaxial cable. Contact failure and cable disconnection may occur.

(e) There are integral type and separate type F-shaped connectors. In the case of the separate type F-shaped connector, tighten the ring of the connector until the ring is tight before connecting the connector to the network module. If the ring is loose, a communication error may occur.




Turn clockwise (tightening direction).



Integral type F-shaped connector

After connecting the F-shaped connector to the network module, retighten its ring periodically.

Retighten it with both hands as shown below.



Network module

Turn clockwise.

Coaxial cable

(f) A white oxide, which may be deposited on the F-shaped connector depending on the operating environment, is not produced in the fitting portion, posing no functional problems.


(2) Connection method

Connect coaxial cables as shown below.


Be sure to connect terminal resistors to both ends.

One F connector is supplied with each module (AJ71BR11, A1SJ71BR11, AJ72BR15).

(a) When no repeater is used



(b) When repeater is used (serial connection)



REMARK

For detailed information on the repeater (A6BR10), refer to the User's Manual supplied with the product.


User's Manual of repeaters for A6BR10/A6BR10-DC type MELSECNET/10 coaxial bus systems.

IB-66499

3. PRE-OPERATION PROCEDURES

MELSEC-A

(c) When repeater is used (connection including a branch)



POINT

Designate stations reserved for future use (those included in the total number of stations but not actually connected) as reserved stations. This prevents the stations from being detected as abnormal stations, and it does not affect the link scan time.


REMARK

Terminal resistors are not included in the product package.
Please procure A6RCON-R75 resistors.

3.4 Checking the Connection with Network Modules

Before operating the data link, check the network modules and the cables. Set the items to be tested by setting the mode select switch on the front face of the network module.

[Test Procedure]




* Not possible for remote I/O stations

3. PRE-OPERATION PROCEDURES

MELSEC-A

3.4.1 Hardware test

Check hardware inside the network module.



To the next page.

From the previous page.


Hardware test is being executed!

The test results are indicated by the LEDs.

<When normal>

The CRC, OVER, AB.IF, TIME, DATA, and UNDER LEDs light in this order.

When this cycle is repeated 5 or more times the status is normal.



<When abnormal>


For the optical loop system (AJ71LP21, AJ72LP25, A1SJ71LP21, AJ71LP21G, AJ72LP25G, AJ71LP21GE, A1SJ71LP21GE, AJ72LP25GE), the coaxial loop system (AJ71LR21, AJ72LR25, A1SJ71LR21) and the coaxial bus system (AJ71BR11, AJ72BR15, A1SJ71BR11): When the following errors occur, corresponding LED will light. Replace the network module.

- 1) CRC is lit: ROM check error
- 2) OVER is lit: RAM check error
- 3) AB.IF is lit: Timer or interrupt function check error

For the optical loop system (AJ71LP21, AJ72LP25) only


- 1) TIME is lit: Forward loop disconnection check error
- 2) DATA is lit: Reverse loop disconnection check error

When a light amount check error occurs, locate the cause by following the flow chart given below.



3.4.2 Internal self-loopback test

Check the hardware including the send and receive circuits for transmissions in a single network module.



To the next page.

From the previous page.

Internal self-loopback test is being executed!

The test results are indicated by the LEDs.

<When normal>
 The CRC, OVER, AB.IF, TIME, DATA, and UNDER LEDs light in this order.
 When this cycle is repeated 5 times or more, the status is normal. The LOOP LED is irrelevant to this.

CRC	●	○	○	○	○	○	
OVER	○	●	○	○	○	○	○: Unlit
AB. IF	○	○	●	○	○	○	●: Lit
TIME	○	○	○	●	○	○	
DATA	○	○	○	○	●	○	
UNDER	○	○	○	○	○	●	

Repeating cycle: (CRC lit) → (OVER lit) → (AB.IF lit) → (TIME lit) → (DATA lit) → (UNDER lit) → (CRC lit) → ...

<When abnormal>
 For the optical loop system (AJ71LP21, AJ72LP25, A1SJ71LP21, AJ71LP21G, AJ72LP25G, AJ71LP21GE, A1SJ71LP21GE, AJ72LP25GE) and the coaxial loop system (AJ71LR21, AJ72LR25, A1SJ71LR21)
 1) ERROR LED is lit
 • Hardware failure

For the coaxial bus system (AJ71BR11, AJ72BR15)
 1) ERROR LED is lit
 • Hardware failure

REMARKS

When an error occurs in the coaxial bus system, the M/S.E or PRM.E LED other than the ERROR LEDs (CRC, OVER, AB.IF, TIME, DATA, UNDER) may light up.
 When asking for repairs of the network module, please inform the state of LEDs.


3. PRE-OPERATION PROCEDURES

MELSEC-A

3.4.3 Self-loopback test

Check hardware including the send and receive circuits for transmissions in a single network module.

Conduct this test to check the cables when the result of the internal self-loopback test is normal.



To the next page.

From the previous page.

Self-loopback test is being executed!

The test results are indicated by the LEDs.

<When normal>
The CRC, OVER, AB.IF, TIME, DATA, and UNDER LEDs light in this order.

CRC	●	○	○	○	○	○	
OVER	○	●	○	○	○	○	○: Unlit
AB. IF	○	○	●	○	○	○	●: Lit
TIME	○	○	○	●	○	○	
DATA	○	○	○	○	○	●	
UNDER	○	○	○	○	○	○	

↑ Repeated

<When abnormal>
For the optical loop system (AJ71LP21, AJ72LP25, A1SJ71LP21, AJ71LP21G, AJ72LP25G, AJ71LP21GE, A1SJ71LP21GE, AJ72LP25GE) and the coaxial loop system (AJ71LR21, AJ72LR25, A1SJ71LR21)


- 1) TIME is lit
 - Forward loop cable is broken.
 - The send and receive sides of the forward loop are not connected with a cable.
 - The forward loop send side is connected to the reverse loop send side, and the forward loop receive side is connected to the reverse loop receive side.
- 2) DATA is lit:
 - Reverse loop cable is broken.
 - The send and receive sides of the reverse loop are not connected with a cable.
- 3) CRC, OVER, and AB.IF of the forward and reverse sides flash:
 - Cable is faulty.
- 4) ERROR LED other than the above is lit:
 - Hardware fault
 - Cable disconnected during the test.
 - Cable broken during the test.

For the coaxial bus system (AJ71BR11, AJ72BR15)

- 1) TIME is lit:
 - Connector is disconnected.
- 2) CRC, OVER, and AB.IF flash:
 - Connector is faulty.
- 3) ERROR LED other than the above is lit:
 - Hardware fault
 - Connector disconnected during the test.

3.4.4 Station-to-station test

Check the channel between two adjacent stations.



To the next page.


From the previous page.

Station-to-station test is executed!

The test results are indicated by the LEDs.

<When normal>

The CRC, OVER, AB.IF, TIME, DATA, and UNDER LEDs light in this order. When this cycle is repeated 5 times or more, the status is normal.



<When abnormal>

For the optical loop system (AJ71LP21, AJ72LP25, A1SJ71LP21, AJ71LP21G, AJ72LP25G, AJ71LP21GE, A1SJ71LP21GE, AJ72LP25GE) and the coaxial loop system (AJ71LR21, AJ72LR25, A1SJ71LR21)

1) TIME is lit:

- Forward loop cable is broken.
- The send and receive sides of the forward loop are not connected with a cable.
- The forward loop send side is connected to the reverse loop send side, and the forward loop receive side is connected to the reverse loop receive side.

2) DATA is lit:

- Reverse loop cable is broken.
- The send and receive sides of the reverse loop are not connected with a cable.

3) CRC, OVER, and AB.IF of the master station flash:

- Cable is faulty.

4) ERROR LED other than the above is lit:

- Hardware fault
- Cable disconnected during the test.
- Cable broke during the test.

For the coaxial bus system (AJ71BR11)

1) TIME is lit:

- Cable is broken.

2) CRC, OVER, and AB.IF flash:


- Cable is faulty.

3) ERROR LED other than the above is lit:

- Hardware fault
- Cable disconnected during the test.
- Cable broke during the test.

3.4.5 Forward loop/reverse loop test (Optical loop system only)

Check the channel after connecting all stations with fiber-optic cables.



To the next page.

From the previous page.



Forward loop / reverse loop test is executed!

The test results are indicated by the LEDs.

<When normal>
The CRC, OVER, AB.IF, TIME, DATA, and UNDER LEDs light in that order.

CRC	●	○	○	○	○	○	
OVER	○	●	○	○	○	○	○ : Unlit
AB. IF	○	○	●	○	○	○	● : Lit
TIME	○	○	○	●	○	○	
DATA	○	○	○	○	○	●	
UNDER	○	○	○	○	○	○	

Repeated

<When abnormal>

- 1) TIME, DATA, and UNDER LEDs of the forward and reverse loop sides flash:
 - Either the fiber-optic cable or other stations have fault, and the loopback operation is executed.
- 2) CRC, OVER, and AB.IF of the forward and reverse loop sides flash:
 - Cable is faulty.
- 3) TIME and DATA LEDs of the forward and reverse loop sides flash:
 - Incorrect connections. Check the cable connections at the stations before and after the station where the error occurred.

POINT

When a fault is found by the forward / reverse loop test, check the loop by executing a reverse / forward loop operation or loopback operation.

3. PRE-OPERATION PROCEDURES


MELSEC-A

3.4.6 Checking switch settings

Check the numbers with the LEDs on the front side of the network module.

REMARK

This test cannot be made on the A1SJ71LP21, A1SJ71BR11 and A1SJ71LR21.



4. STARTING OPERATION


This section describes how remote I/O network communications are executed in a simple system.

4.1 Communicating with an I/O Module

The preparatory steps for communication with an I/O module are explained here by referring to an actual system example.

4.1.1 Preparing for communication

An outline of communication with an I/O module is presented below.



[Input]

- (1) X00 of the input module turns ON.
- (2) The input module information is transferred to the remote I/O network module (AJ72LP25/AJ72BR15).
- (3) The remote I/O station information is transferred to the network module (AJ71LP21/AJ71BR11) of the master station via a fiber-optic cable or coaxial cable.
- (4) The information of the master station's network module (AJ71LP21/AJ71BR11) is transferred to the AnUCPU.
- (5) X1000 in the sequence program turns ON.

[Output]

- (6) The sequence program switches Y1010 ON.
- (7) The information of the AnUCPU is transferred to the network module (AJ71LP21/AJ71BR11) of the master station.
- (8) The information of the master station's network module (AJ71LP21/AJ71BR11) is transferred to the network module (AJ72LP25/AJ72BR15) of the remote I/O station via a fiber-optic cable or coaxial cable.
- (9) The information of the network module (AJ72LP25/AJ72BR15) in the remote I/O station is transferred to the output module.
- (10) Y10 of the output module turns ON.

REMARK


The "network refresh parameters" are used to set relationships between the AnUCPU and network module such as those in (4) and (7).

The "common parameters" are used to set relationships between network modules, such as those in (3) and (8).

4.1.2 Actual communication

This section describes the preparation for communication with an I/O module in the system configuration shown below.


[System configuration]




(1) Parameters to be set

Set the parameters indicated below.

(a) Common parameters



(b) Network refresh parameters




4. STARTING OPERATION

MELSEC-A


(2) Program

Write the following program to the A3UCPU and check that communication is executed normally.



[Operation timing]

When X00 of the AX40 of the remote I/O station turns ON, Y10 of the AY40 of the remote I/O station flashes for 3 s.




4. STARTING OPERATION

MELSEC-A


(3) Network module settings

Make the appropriate settings at the master station and the network modules in the remote I/O stations.

(a) Master station (AJ71LP21)



(b) Remote I/O station (AJ72LP25)



4. STARTING OPERATION

MELSEC-A

- (4) Setting parameters/creating a program at a peripheral device, and writing to the CPU

In order to operate the data link, parameters have to be set in the CPU of the master station from a peripheral device.

The parameter settings to be made are listed in the table below.

Item	Setting
Number of modules	◎
Network refresh parameters	○
Common/remote I/O parameters	◎
Station specific parameters	x
I/O allocations	△
Transfer parameters for data link	x

◎ : Must always be set

○ : Change if necessary (default setting is provided)

△ : Set if necessary

x : Setting not possible

1 Select "CREATE".

```

<INITIAL SETTING>
1 : CREATE
2 : FILE READ
3 : PC READ
Esc : QUIT
    
```

[1]

2 Select "A3U" as the CPU type.

```

<CREATE>
1 : A0J2
2 : A0J2H
3 : A1S, A1SJ
4 : A1(N)
-----
A : A3A
B : A2U, A2US
C : A3U
D : A4U
Esc : CLOSE
    
```

[C]

Continued on next page

Continued from previous page

3 Choose to perform file setting.

SET FILE?
YES NO

[Enter]

4 Set a file name.

<CREATE>	
SYSTEM [C]	[]
COMMENT	[]
SUB-SYSTEM	[]
COMMENT	[]
COMMENT (GPP)	[]
Esc : CLOSE	

[Enter] (If the drive is other than C, enter the drive name and then press [Enter].)

[R] [E] [M] [O] [T] [E] [Enter]

[Enter] (No COMMENT)

[N] [E] [T] [W] [O] [R] [K] [1] [Enter]

[Enter] (No COMMENT)

[Enter] (No COMMENT (GPP))

Continued on next page

Continued from previous page

5 The file name is set.

```
<CREATE>
SYSTEM [C]      [ REMOTE  ]
COMMENT        [                ]
SUB-SYSTEM     [ NETWORK1 ]
COMMENT        [                ]
COMMENT (GPP)  [                ]
Esc : CLOSE
```

[Enter]

6 Choose to write to the file.

```
WRITE TO FILE?
  YES          NO
```

[Enter]

7 Select "PARAMETER".

```
<MENU>
1 : PROGRAMMING
2 : PARAMETER
3 : ON-LINE
4 : DOCUMENTATION
```

[2]

Continued on next page

Continued from the previous page

8 Select "NETWORK/LINK".

<PARAMETER>

1 : MEMORY CAPACITY

2 : LATCH RANGE

3 : NETWORK/LINK

4 : I/O ALLOCATION

5 : AUXILIARY

[3]

9 Select "DATA LINK PARAM.".

<NETWORK/LINK>

1 : DATA LINK PARAM.

2 : ROUTING PARAMETER

Esc : CLOSE

[1]

10 Set the number of modules settings.

<MODULES>

NO OF MODULES(1-4) []

MODULE NO. ACCESSED BY GPP []

	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO.	[]	[]	[]	[]
NETWORK MODULE TYPE				
NETWORK NO.	[]	[]	[]	[]

End : SET Esc : CLOSE

Continued on next page

Continued from the previous page

[1] [Enter]

[1] [Enter]

[Enter]

[4]

[1] [Enter]

11 The number of modules have now been set.

-MODULES-

NO OF MODULES(1-4) [1]

MODULE NO. ACCESSED BY GPP [1]

	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO.	[00]	[]	[]	[]
NETWORK MODULE TYPE	MELSECNET/10 RMT. MASTER			
NETWORK NO.	[1]	[]	[]	[]

End : SET End : CLOSE

[End]

Continued on the next page

Continued from the previous page

12 Set the common/remote I/O parameter settings.

COMMON PARAM. (MELSECNET10) REMOTE I/O		PARAM. NAME				
MODULE NO.		REFRESH PARAMETER		Size		
1		LB ↔ B(1)	0000-1FFF	8192		
		LB ↔ B(2)	-			
		LW ↔ W(1)	0000-1FFF	8192		
		LW ↔ W(2)	-			
NO. OF STN.	LINK WDT = 10 ms	REMOTE I/O STN. NO.	M→R	M←R	M→R	M←R
			LB	LB	LW	LW
	200		-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-

Page Up/Page Down MODULE CHANGE : Shift + F1, F2, F3, F4 End : CHECK & SET Esc CLOSE

[1] [Enter] (Total number of link stations)

[F9] [Enter] (Change to the LX/LY setting)

[1] [0] [1] [0] [→] [1] [0] [1] [F] [→]

[1] [0] [→] [1] [F] [→]

[1] [0] [0] [0] [→] [1] [0] [0] [F] [→]

[0] [→] [F]

[End] (Check)

Continued on next page

Continued from the previous page

13 The common/remote I/O parameters have now been set.

COMMON PARAM. (MEL SECNET/I/O) REMOTE I/O		PARAM. NAME				
MODULE NO.		REFRESH PARAMETER		Size		
1		LX↔X(1)		-		
		LX↔X(2)		-		
		LY↔Y(1)		-		
		LY↔Y(2)		-		
NO. OF STN.	LINK WDT = 10 ms	REMOTE I/O STN. NO.	M→R		M←R	
			LY	LY	LX	LX
1	200	1	1010 - 101F	0010 - 001F	1000 - 100F	0000 - 000F
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-

Page Up/Page Down MODULE CHANGE : Shift + F1, F2, F3, F4 End : CHECK & SET Esc : CLOSE

[End] (Setting completed)

14 The remote I/O allocations are NOT set.

SET REMOTE I/O ALLOCATIONS?

YES NO

[→] (NO)

[Enter]

Continued on the next page

Continued from the previous page

15 Check the settings for the network parameter.

NETWORK PARAMETER				
NET MODULE SETTING	1	O : MUST BE SET. @ : ALREADY SET. ? : IF WHEN NECESSARY. * : ALREADY SET.		
NETWORK PARAMETER CAPACITY 4KB	1 MODULE NET/10(R)			
NETWORK REFRESH PARAMETER	@			
MELSECNET II	X			
COMMON/REMOTE I/O PARAM.	@			
STATION NATIVE PARAMETER	X			
I/O ALLOCATION	?			
TRANSFER PARAMETER	X			

End: CHECK/RET Esc: CLOSE

[Enter]

16 Change the network refresh parameter.

NETWORK REFRESH PARAMETER			
OTHER MODULES		LB↔B TRANS.	
LB↔B TRANSFER 1:1000 - 1FFF		SET SOURCE LB NUMBER, DESTINATION B NUMBER(UNITS OF 16).	
1		2:	
		3:	
		4:	
[PAGE 1] NETWORK MODULE 1			
MELSECNET/10(RMT MAST)	I/O NO. 00	NETWORK NO. 1	
LB↔B	LB [0000]↔B [0000]	SIZE[2000]HPOINTS	
LW↔W	LW [0000]↔W [0000]	SIZE[2000]HPOINTS	
LX↔X	LX [0000]↔X [0000]	SIZE[0000]HPOINTS	
LY↔Y	LY [0000]↔Y [0000]	SIZE[0000]HPOINTS	
SB COPIED TO	SB [000]↔DEST. [Y] [1C00]	SIZE [100]HPOINTS	
SW COPIED TO	SW [000]↔DEST. [D] [7168]	SIZE [100]HPOINTS	
ERROR HISTORY	RETAIN		

CHANGE MODULE WITH SHIFT + F1, F2, F3, F4 KEYS End: SET Esc: CLOSE

Continued on next page

Continued from the previous page

[↓][↓][→][→]

[2][0][0][0][↓]

[2][0][0][0][↓][←][←]

[M][↓][6][0][0][0][↓]

[7][0][0][0]

The network refresh parameters have now been changed.

17

NETWORK REFRESH PARAMETER

<p>OTHER MODULES</p> <p>SW COPIED TO 1:D7168 - D7423</p> <p>2:</p> <p>3:</p> <p>4:</p> <p>[PAGE 1] NETWORK MODULE 1</p>	<p>SW TRANS. DEV.</p> <p>SPECIFY SOURCE SW, DESTINATION DEVICE, IT'S NO. AND TRANSFER SIZE.</p> <p>AVAILABLE DEVICES T, C, D, W</p>
---	---

MELSECNET/10(RMT MAST)	I/O NO. 00	NETWORK NO. 1
LB↔B	LB [0000]↔B [0000]	SIZE[2000]HPOINTS
LW↔W	LW [0000]↔W [0000]	SIZE[2000]HPOINTS
LX↔X	LX [0000]↔X [0000]	SIZE[2000]HPOINTS
LY↔Y	LY [0000]↔Y [0000]	SIZE[2000]HPOINTS
SB COPIED TO	SB [000]↔DEST. [M] [6000]	SIZE [100]HPOINTS
SW COPIED TO	SW [000]↔DEST. [D] [7000]	SIZE [100]HPOINTS
ERROR HISTORY	RETAIN	

CHANGE MODULE WITH SHIF + F1, F2, F3, F4 KEYS End: SET Esc: CLOSE

[End] (Setting completed)

[End] (Completion of setting of network parameters)


[Esc] [Esc] (Return to the menu)

Continued on the next page


4 - 15

Continued from the previous page

[1]



[1]



Enter the program in Section 4.1.2 (2).

Press [F4] (convert) while holding down [Shift].

Continued on the next page

Continued from the previous page

20 The program has now been created.

```
LADDER WRITE A311-D-FE-PC-D MELSEC NETWORK MAIN F11.MENU F12.HELP
0 X1000 [ PLS M0 ]
4 M0 [ SET M1 ]
6 M1 M9031 TO (Y1010)
   (K30 T0)
13 T0 [ RST T0 ]
   [ RST M1 ]
```

[F11] (Opens the menu)

[3] (Online)

[1] (PC)

[2] (Write)

21 Connect the CPU to the peripheral device.

CPU side RS-422 cable

Continued on the next page

Continued from the previous page

22 Write the data to the CPU.

WRITE		MENU	
F1	PARAM. NET PARAM (AnU)+MAIN	LINE	ING
F2	PARAM.+NET PARAM.(AnU)	MONITOR	
F3	NETWORK PARAMETER(AnU)	DIAGNOSIS	
F4	MAIN PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	TRACE	MAINTENANCE
F5	SUB PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	NG TRACE	
F6	COMMENT 1:COMMENT1 2:COMMENT2	← CLOSE	
F7	EXTENDED COMMENT	9 : QUIT	
F8	DEVICE MEMORY 1:ALL AREA 2:AREA [M B T C D W R] 3:EXPANSION R BLOCK []		
		Esc. CLOSE	

[Enter]

23 Execute writing.

EXECUTE?	
<input checked="" type="checkbox"/> YES	<input type="checkbox"/> NO

[Enter]

Continued on the next page

Continued from the previous page

24 Check the program.

CHECK SEQUENCE PROGRAM?

[Enter]

25 Verify the data.

VERIFY?

[Enter]

26 Writing to the CPU has now been completed.



WRITE		MENU	
F1	PARAM.+NET PARAM.(AnU)+MAIN	LINE	ING
F2	PARAM.+NET PARAM.(AnU)	MONITOR	DIAGNOSIS
F3	NETWORK PARAMETER(AnU)	TRACE	MAINTENANCE
F4	MAIN PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	NG TRACE	CLOSE
F5	SUB PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	9: QUIT	
F6	COMMENT 1:COMMENT1 2:COMMENT2	Esc: CLOSE	
F7	EXTENDED COMMENT		
F8	DEVICE MEMORY 1:ALL AREA 2:AREA [M B T C D W R] 3:EXPANSION R BLOCK []		
Esc: CLOSE			

COMPLETED

1: MAIN
2: PARAM
3: NET
4: MAIN
5: SUB
6: COMM
7: EX.COM
8: DEVICE
9: 0

Continued on next page

Continued from the previous page



4. STARTING OPERATION

MELSEC-A

(5) Check the data link conditions

Check the data link conditions by checking the network module LEDs and the sequence program.

(a) Checking the status of the LEDs

Check the LED statuses of the master station and the remote I/O station.

1) Master station (AJ71LP21)

O: Unlit ●: Lit

LED Name	When Normal	LED Name	When Normal
RUN	●	POWER	●
PC	○	MNG	●
REMOTE	●	S.MNG	○
DUAL	○	D.LINK	●
SW.E.	○	T.PASS	●
M/S.E.	○	—	—
PRM.E.	○	CPU R/W	●(dimly lit)
CRC	○	CRC	○
OVER	○	OVER	○
AB.IF	○	AB.IF	○
TIME	○	TIME	○
DATA	○	DATA	○
UNDER	○	UNDER	○
LOOP	○	LOOP	○
SD	●(dimly lit)	SD	○
RD	●(dimly lit)	RD	●(dimly lit)

Note that these statuses depend on the loop status.

2) Remote station (AJ72LP25)

O: Unlit ●: Lit


LED Name	When Normal	LED Name	When Normal
RUN	●	POWER	●
ERROR	○	—	—
—	—	—	—
DUAL	○	D.LINK	●
SW.E.	○	T.PASS	●
ST.E.	○	—	—
PRM.E.	○	WAIT	○
CRC	○	CRC	○
OVER	○	OVER	○
AB.IF	○	AB.IF	○
TIME	○	TIME	○
DATA	○	DATA	○
UNDER	○	UNDER	○
LOOP	○	LOOP	○
SD	●(dimly lit)	SD	○
RD	●(dimly lit)	RD	●(dimly lit)

Note that these statuses depend on the loop status.

(b) Checking the sequence program


Check if the program written to the PC CPU operates normally.

[System configuration]



[Operation check]

When (1)X00 of the input module (AX40) of the remote I/O station turns ON, (2)Y10 of the output module turns alternately ON and OFF for 3 seconds.




4.2 Communicating with a Special Function Module

The preparatory steps for communication with a special function module are explained here by referring to an actual system example.

4.2.1 Preparing for communication

An outline of communication with a special function module is presented below.



[Buffer memory]

- (1) When a ZNFR/ZNT0 instruction is executed.
- (2) ZNFR The buffer memory data is written to W devices.
ZNT0 The data in the W devices is written to the buffer memory.

- (3) On completion of the ZNFR/ZNT0 instruction the completion signal (M0) comes ON for 1 scan.

* LB devices are used for handshake processing when an instruction is executed.
LW devices are used for handshake processing and for data reading/writing when an instruction is executed.


[Input/output]

- (4) X/Y communications are executed in the same way as communications with an I/O module.

4.2.2 Actual communication

This section describes the preparation for communication with a special function module in the system configuration shown below.


[System configuration]



A62DA ... Digital to analog converter module (2-channel)
 This module must be one that handles voltage only.

4. STARTING OPERATION

- (1) Parameters to be set
Set the parameters indicated below.
- (a) Common parameters



4. STARTING OPERATION

MELSEC-A

(1) to (4), (1)' to (4)' Required for each special function module for handshake use.

M→R		M←R	
LB ^{*1}	LW	LB ^{*1}	LW ^{*2}
4 points/module	4 points/module	4 points/module	4 points/module

*1 : Note that LB devices are set in 16-point units.

*2 : The result of execution of the ZNTO/ZNFR instruction is stored in the first M←R LW point (in this example, LW10). (See Section 11.1)

(5), (6), (5)', (6)' The LW devices can be set in 1 point units; set the number of points that matches the size of the special function module's buffer memory.


POINT

Even if only one LB or LW point is set, it is checked whether there is a sufficient number of points for handshake processing use for the special function module that is installed.

If the number of points is found to be insufficient, a "PRM.E." error occurs.

If no points at all are set this check is not performed.

(b) Network refresh parameters



4. STARTING OPERATION

MELSEC-A

(2) Program

Write the following program to the A3UCPU and check that communication is performed normally.

Check the condition of the data link between the host station and the remote I/O station and ensure that the entire program operation is possible.


Setting is enabled when the A62DA READY signal turns ON.

When X0020 of the master station turns ON, the digital switch data is fetched to W0004 and W0005, and written to the buffer memory of the A62DA.

W0004 → CH1
W0005 → CH2

If the result of execution of the ZNTO/ZNFR instruction is abnormal, Y006F of the master station is turned alternately ON and OFF.

When X0021 turns ON CH1 and CH2 output is enabled.
When X0022 turns ON, CH1 and CH2 output is disabled.




4. STARTING OPERATION

MELSEC-A

The voltage set value check codes for CH1 and CH2 of A62DA are read to W0014 and W0015 at all times.
 (CH1 → W0014)
 (CH2 → W0015)

If a CH1 set value error occurs, Y0068 turns ON.
 If a CH2 set value error occurs, Y0069 turns ON.


When X0023 turns ON the voltage set value check codes for CH1 and CH2 are cleared to "0".
 (W0006 → CH1)
 (W0007 → CH2)



(3) Setting the network modules


Set the master station and remote I/O station network modules.

(a) Master station (AJ71LP21)



Item		Setting	
(1)	NETWORK No.	0	
		x 100	
		x 10	
(2)	GROUP No.	0	
(3)	STATION No.	x 10	
		x 1	
(4)	MODE	0	
(5)	OFF	ON	
	PC	REMOTE	
	N.ST	MNG	
	PRM	D.PRM	
	STATION SIZE (8,16,32,64)		OFF
	LB/LW SIZE (2,4,6,8 k)		OFF
—		OFF	

(b) Remote I/O station (AJ72LP25)



Item		Setting
(1)	STATION No.	x 10
		x 1
(2)	MODE	0
(3)	SW	1
		2
		3
		4
		5

- (4) Setting parameters/creating a program, and writing to the CPU, at a peripheral device

In order to operate the data link, parameters have to be set in the CPU of the master station from a peripheral device. The parameter settings to be made are listed in the table below.

Item	Setting
Number of modules	⊙
Network refresh parameters	○
Common/remote I/O parameters	⊙
Station specific parameters	x
I/O allocations	Δ
Transfer parameters for data link	x

- ⊙ : Must always be set
- : Change if necessary (default setting is provided)
- Δ : Set if necessary
- x : Setting not possible

Details of the operation from switching the peripheral device power ON to "data link parameters" are not given here. See Section 4.1.2, items 1 through 12 for this information.

Set the "MODULES"

1

◀MODULES▶

NO OF MODULES(1-4) []


MODULE NO. ACCESSED BY GPP []

	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO.	[]	[]	[]	[]
NETWORK MODULE TYPE				
NETWORK NO.	[]	[]	[]	[]

End : SET Esc : CLOSE

↓
Continued on the next page


Continued from the previous page



The number of modules have now been set.

2

MODULES				
NO OF MODULES(1-4)	[1]			
MODULE NO. ACCESSED BY GPP	[1]			
	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO.	[00]	[]	[]	[]
NETWORK MODULE TYPE	MELSECNET/10 RMT. MASTER			
NETWORK NO.	[1]	[]	[]	[]
End : SET Esc : CLOSE				



Continued on the next page

Continued from the previous page

3 Set the common/remote I/O parameter settings.

COMMON PARAM. (MELSECNET I/O) REMOTE I/O		PARAM. NAME				
MODULE NO.		REFRESH PARAMETER		Size		
1		LB ↔ B(1)	0000-1FFF	8192		
		LB ↔ B(2)	-			
		LW ↔ W(1)	0000-1FFF	8192		
		LW ↔ W(2)	-			
NO. OF STN.	LINK WDT - 10 ms	REMOTE I/O STN. NO.	M→R LB	M←R LB	M→R LW	M←R LW
	200		-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-

Page Up/Page Down MODULE CHANGE : SHIF + F1, F2, F3, F4 Ent : CHECK & SET Esc : CLOSE

[1] [Enter] (Total number of link stations)

[0] [→] [F] [→] [1] [0] [→] [1] [F]

[0] [→] [F] [→] [1] [0] [→] [1] [F]

[F9] [Enter] (Change to the LX/LY setting)

[1] [0] [0] [0] [→] [1] [0] [1] [F] [→]

[0] [→] [1] [F] [→]

[1] [0] [0] [0] [→] [1] [0] [1] [F] [→]

[0] [→] [1] [F] [→]

[End]

Continued on next page

Continued from the previous page

The common/remote I/O parameters have now been set.

4

-COMMON PARAM. (MELSECNET/0) REMOTE I/O-

PARAM. NAME :

MODULE NO.		REFRESH PARAMETER	Size	
1		LX↔X(1)	-	
1		LX↔X(2)	-	
1		LY↔Y(1)	-	
1		LY↔Y(2)	-	

NO. OF STN.	LINK WDT * 10 ms	REMOTE I/O STN. NO.	M→R		M←R	
			LY	LY	LX	LX
1	200	1	1000 - 101F	0000 - 001F	1000 - 101F	0000 - 001F
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-
-	-	-	-	-	-	-

Page Up/Page Down : MODULE CHANGE : Shift + F1, F2, F3, F4 End : CHECK & SET Esc : CLOSE

[End]

The remote I/O allocations are NOT set.

5

SET REMOTE I/O ALLOCATIONS?

YES

NO

[→] (NO)

[Enter]

Continued on the next page

Continued from the previous page

6 Check the settings for the network parameter.

-NETWORK PARAMETER-

NET MODULE SETTING 1 O : MUST BE SET. @ : ALREADY SET.
 ? : IF WHEN NECESSARY. * : ALREADY SET.

NETWORK PARAMETER CAPACITY 4KB	1 MODULE NET/10(R)			
NETWORK REFRESH PARAMETER	@			
MELSECNET II	X			
COMMON/REMOTE I/O PARAM.	@			
STATION NATIVE PARAMETER	X			
I/O ALLOCATION	?			
TRANSFER PARAMETER	X			

End : CHECK/SET Esc : CLOSE

[Enter]

7 Change the network refresh parameter.

-NETWORK REFRESH PARAMETER-

OTHER MODULES **LB↔B TRANS-**

LB↔B TRANSFER 1:1000 - 1FFF SET SOURCE LB NUMBER, DESTINATION B NUMBER(UNITS OF 16).

1				
2:				
3:				
4:				


[PAGE 1] NETWORK MODULE 1

MELSECNET/10(RMT MAST)	I/O NO. 00	NETWORK NO. 1
LB↔B LB [0000]↔B [0000]		SIZE[2000]HPOINTS
LW↔W LW [0000]↔W [0000]		SIZE[2000]HPOINTS
LX↔X LX [0000]↔X [0000]		SIZE[0000]HPOINTS
LY↔Y LY [0000]↔Y [0000]		SIZE[0000]HPOINTS
SB COPIED TO SB [000]↔DEST. [Y] [1C00]		SIZE [100]HPOINTS
SW COPIED TO SW [000]↔DEST. [D] [7168]		SIZE [100]HPOINTS
ERROR HISTORY RETAIN		

CHANGE MODULE WITH SHIF + F1, F2, F3, F4 KEYS END : SET Esc : CLOSE

Continued on next page

Continued from the previous page



The network refresh parameters have now been changed.

8

-NETWORK REFRESH PARAMETER-

OTHER MODULES	-SW TRANS. DEV-
SW COPIED TO 1:D7168 - D7423 2: 3: 4: <div style="border: 1px solid black; width: 100px; height: 20px; margin-top: 5px; display: flex; justify-content: space-between; align-items: center;"> 1 </div>	SPECIFY SOURCE SW, DESTINATION DEVICE, IT'S NO. AND TRANSFER SIZE. AVAILABLE DEVICES T, C, D, W

[PAGE 1] NETWORK MODULE 1

MELSECNET/10(RMT MAST)	I/O NO. 00	NETWORK NO. 1
LB↔B	LB [0000]↔B [0000]	SIZE[2000]HPOINTS
LW↔W	LW [0000]↔W [0000]	SIZE[2000]HPOINTS
LX↔X	LX [0000]↔X [0000]	SIZE[2000]HPOINTS
LY↔Y	LY [0000]↔Y [0000]	SIZE[2000]HPOINTS
SB COPIED TO	SB [000]↔DEST. [M] [6000]	SIZE [100]HPOINTS
SW COPIED TO	SW [000]↔DEST. [D] [7000]	SIZE [100]HPOINTS
ERROR HISTORY	RETAIN	

CHANGE MODULE WITH SHIF + F1, F2, F3, F4 KEYS. End : SET Esc : CLOSE

↓

[End] (Setting completed)

↓

[End] (Completion of setting of network refresh parameters)

↓


[Esc] [Esc] (Return to the menu)

↓


Continued on the next page

Continued from the previous page

[1]



[1]



Enter the program in Section 4.2.2 (2).

Press [F4] (convert) while holding down [Shift].

Continued on the next page

Continued from the previous page

11 The program has now been created.

LADDER WRITE A11: OFF PC 0 2045937 C-NETWORK MAIN F11: MENU F12: HELP

0 M6073 [MC NO M0]

N0 M0

7 M9036 [MOV D7116 M10]

14 M0 [MC N1 M50]

N1 M50

20 X1000 X1001 (M100)

(Y0080)

26 M100 X0020 [P K4
[BRN X0040 W0004]

[P K4
[BRN X0050 W0005]

[PLS M101]

[F11] (Opens the menu)

[3] (Online)

[1] (PC)

[2] (Write)

12 Connect the CPU to the peripheral device.

CPU is STOP

CPU side RS-422 cable

Continued on the next page

Continued from the previous page

13 Write the data to the CPU.

WRITE		MENU	
F1	PARAM.+NET PARAM.(AnU).MAIN	LINE	ING
F2	PARAM.+NET PARAM.(AnU)	MONITOR	
F3	NETWORK PARAMETER(AnU)	DIAGNOSIS	
F4	MAIN PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	TRACE	MENANCE
F5	SUB PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	NG TRACE	
F6	COMMENT 1:COMMENT1 2:COMMENT2	CLOSE	
F7	EXTENDED COMMENT	9: QUIT	
F8	DEVICE MEMORY 1:ALL AREA 2:AREA [M B T C D W R] 3:EXPANSION R BLOCK []		
		Esc:CLOSE	

[Enter]

14 Execute writing.

EXECUTE?
YES NO

[Enter]

Continued on the next page

Continued from the previous page

15 Check the program.

CHECK SEQUENCE PROGRAM?

[Enter]

16 Verify the data.

VERIFY?

[Enter]

17 Writing to the CPU has now been completed.



WRITE		MENU	
F1	PARAM.+NET PARAM.(AnU)+MAIN	LINE	ING
F2	PARAM.+NET PARAM.(AnU)	MONITOR	
F3	NETWORK PARAMETER(AnU)	DIAGNOSIS	
F4	MAIN PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	TRACE	MAINTENANCE
F5	SUB PROGRAM 1:ALL AREA 2:RANGE []-[] 3:T/C VALUE	NG TRACE	
F6	COMMENT 1:COMMENT1 2:COMMENT2	CLOSE	
F7	EXTENDED COMMENT	9: QUIT	
F8	DEVICE MEMORY 1:ALL AREA 2:AREA [M B T C D W R] 3:EXPANSION R BLOCK []		
Esc:CLOSE			

COMPLETED

1:MAIN 2:PARAM 3:NET 4:MAIN 5:SUB 6:COMM 7:EX.COM 8:DEVICE 9:0

Continued on next page

Continued from the previous page



(5) Check the data link conditions

Check the data link conditions by checking the network module LEDs and the sequence program.

(a) Checking the status of the LEDs

Check the LED statuses of the master station and the remote I/O station.

1) Master station (AJ71LP21)

O: Unlit ●: Lit

LED Name	When Normal	LED Name	When Normal
RUN	●	POWER	●
PC	○	MNG	●
REMOTE	●	S.MNG	○
DUAL	○	D.LINK	●
SW.E.	○	T.PASS	●
M/S.E.	○	———	———
PRM.E.	○	CPU R/W	●(dimly lit)
CRC	○	CRC	○
OVER	○	OVER	○
AB.IF	○	AB.IF	○
TIME	○	TIME	○
DATA	○	DATA	○
UNDER	○	UNDER	○
LOOP	○	LOOP	○
SD	●(dimly lit)	SD	○
RD	●(dimly lit)	RD	●(dimly lit)

Note that these statuses depend on the loop status.

2) Remote station (AJ72LP25)

O: Unlit ●: Lit


LED Name	When Normal	LED Name	When Normal
RUN	●	POWER	●
ERROR	○	———	———
———	———	———	———
DUAL	○	D.LINK	●
SW.E.	○	T.PASS	●
ST.E.	○	———	———
PRM.E.	○	WAIT	○
CRC	○	CRC	○
OVER	○	OVER	○
AB.IF	○	AB.IF	○
TIME	○	TIME	○
DATA	○	DATA	○
UNDER	○	UNDER	○
LOOP	○	LOOP	○
SD	●(dimly lit)	SD	○
RD	●(dimly lit)	RD	●(dimly lit)

Note that these statuses depend on the loop status.

(b) Checking the sequence program

Check if the program written to the PC CPU operates normally.

[System configuration]



[Operation check]


- 1) Y0060 is lit when the A62DA module is normal.
- 2) The digital switch (CH1: X0040 to 4F, CH2: X0050 to 5F) values are fetched using X0020 and written to addresses 0 to 1 of the A62DA buffer memory.
- 3) X0021 lights, enabling CH1/CH2 output, and Y0061 lights.
- 4) X0022 lights, disabling CH1/CH2 output, and Y0061 goes out.
- 5) If a value outside the range -2000 to 2000 is set as a CH1 digital switch value, Y0068 lights.
- 6) If a value outside the range -2000 to 2000 is set as a CH2 digital switch value, Y0069 lights.
- 7) If the result of execution of the ZNTO/ZNFR instruction is abnormal, Y006F flashes.

4.3 Communication Using an Intelligent Special Function Module

This section describes communication when using an intelligent special function module.

4.3.1 Preparing for communication

An outline of communication using an intelligent special function module is presented below.
The example presented here shows the case when an AJ71UC24 computer link module is used.



(1) When "0" (master station) is set as the PC No.

All devices in the master station's AnUCPU can be accessed.

(2) When "FF" (host station) is set as the PC No.

The devices of the network modules (AJ72LP25/AJ72BR15) shown below can be accessed.

- X 2048 points (X000 to 7FF)
- Y 2048 points (Y000 to 7FF)
- B 8192 points (B000 to 1FFF)
- W 8192 points (W000 to 1FFF)
- M 512 points (M0 to 511 device points are used instead of addresses SB0000 to 01FF)
- D 512 points (D0 to 511 device points are used instead of SW0000 to 01FF)
- Special M 256 points (M9000 to 9255)
- Special D 256 points (D9000 to 9255)

4.3.2 Precautions when using intelligent special function modules

This section describes the precautions to be taken when using an intelligent special function module installed at a remote I/O station.

- (1) A maximum of two intelligent special function modules can be installed at one remote I/O station.
- (2) The range of devices that can be accessed at the host station differs according to the model.

Device	Accessible Range		
	A3UCPU or Equivalent	A3HCPU or Equivalent	A3ACPU or Equivalent
X	0 to 7FF	0 to 7FF	0 to 7FF
Y	0 to 7FF	0 to 7FF	0 to 7FF
B	0 to 1FFF	0 to 3FF	0 to FFF
W	0 to 1FFF	0 to 3FF	0 to FFF
M*	0 to 511	0 to 511	0 to 511
D*	0 to 511	0 to 511	0 to 511
Special M	9000 to 9255	9000 to 9255	9000 to 9255
Special D	9000 to 9255	9000 to 9255	9000 to 9255

* Devices for substituting SB/SW

A3UCPU or equivalent ... AJ71UC24

A3ACPU or equivalent ... AJ71C24-S6

AJ71C24-S8

AD51H(S3) etc.

A3HCPU or equivalent ... AJ71C24-S3


AD51(S3) etc.

4.4 Communication Using a Peripheral Device

This section describes communication when using a peripheral device.

4.4.1 Preparing for communication

An outline of communication using a peripheral device is presented below.



(1) When "0" (master station) is set as the PC No.

All devices in the master station's AnUCPU can be accessed.

(2) When "FF" (host station) is set as the PC No.

(This function cannot be set on GX Developer.)


The devices of the network modules (AJ72LP25/AJ72BR15) shown below can be accessed.

- X 2048 points (X000 to 7FF)
- Y 2048 points (Y000 to 7FF)
- B 8192 points (B0000 to 1FFF)
- W 8192 points (W0000 to 1FFF)
- M 512 points (M0 to 511 device points are used instead of addresses SB0000 to 01FF)
- D 512 points (D0 to 511 devices points are used instead of SW0000 to 01FF)
- Special M 256 points (M9000 to 9255)
- Special D 256 points (D9000 to 9255)

It is also possible to access the buffer memory of the special function module.


The address setting is the same as for a PC CPU.

Example:



4.4.2 PC No. setting method


This section describes how to set the "PC No." from a peripheral device.
 (In this example, SW□IVD-GPPA is used on the peripheral device.)



5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

The following operations are possible at a peripheral device:

- (1) "Network monitoring", which allows the conditions of the network to be ascertained at a glance.
- (2) "Network diagnosis", which allows the network conditions to be checked, for example during start-up.



REMARKS

(1) SB[][][] and SW[][][], which will be encountered in the explanations in Section 5.1 "Network Monitor", refer to the special relays (SB) and special registers (SW) used for monitoring.

The network monitor function is not available during offline test (the data cannot be displayed correctly).

(2) When accessing a remote I/O station from a peripheral device, use SW[]IVD-GPPA. GX Developer cannot be used to access the remote I/O station.

5.1 Network Monitor


5.1.1 Line monitor

The conditions of the line, data link, CPU, and parameters used with a network to which a peripheral device is connected can be checked.

(1) Checking the line condition and link scan time (Line monitor)


The condition of the network can be checked with a network diagram.

- Check points in the screen
- Mode
 - F/R loop condition
 - Loopback condition
 - Link scan time



(a) Line condition The condition of the loop and bus is displayed.

• Optical loop system



5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

(2) Checking the condition of the master station and data link (Detailed line monitor)

Check points in the screen

- Host station number, network number, group number
- Settings and operating condition of the master station
- Data link data
- Constant link scan
- F/R loops and loopback condition
- Parameter settings with the host station

<DETAIL LINE MONITOR MODULE # 1>				
(a)	STATION NO.	0	CONST.LINK SCAN 100 ms	(j)
(b)	NETWORK NO.	1		
	GROUP NO.	-----	LOOPBACK INFORMATION	
			F.LOOP	(k)
			R.LOOP	(l)
			F.LOOP BACK STATION	(m)
			R.LOOP BACK STATION	(n)
			LOOP CHANGE TIMES	(o)
(c)	I/O ALLOCATION	NO	HOST STATUS	
			PARAMETER SETTING	
			LB/LW AT COMM. STOP	
			LX AT COMM. STOP	
			LB/LW AT LINK HALT	
			LX AT LINK HALT	
			RESERVED	
			YES	(p)
			CONSTANT SCAN	(q)
(d)	TOTAL # OF STATIONS	8	COMM. MODE	(r)
(e)	MAX. NORMAL STN. #	3	TRANSM. DESIGNATE	(s)
(f)	MAX. DATA LINK STN.#	0	TRANSM. STATUS	
(g)	COMM. STATUS	OFF-LINE (OTHER)		
(h)	CAUSE:COMM.STOP	NORMAL		
(i)	CAUSE:D/LINK STOP	ALL STN. (1)		


- (a) STATION NO. The host station number is displayed. (SW0042)
- (b) NETWORK NO. The network number of the host station is displayed. (SW0040)
- (c) I/O ALLOCATION The I/O allocations are displayed.
- YES
 - NO
- (d) TOTAL NUMBER OF LINK STATIONS The "total number of link stations + 1" set in the common parameters is displayed. (SW0059)
- (e) MAXIMUM NORMAL STATION NUMBER The maximum station number which is normally executing baton passing (transient transmission possible). (SW005A)
The T.PASS LED is lit.
- (f) MAXIMUM DATA LINK STATION NUMBER The maximum station number which is normally executing data link (cyclic and transient transmissions). (SW005B)
The D.LINK and T.PASS LEDs are lit.

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

- (g) COMMUNICATION Communication condition of the host station is displayed. (SW0047)
- DATA LINKING
 - OFF-LINE Cyclic transmission is stopped by another (OTHER) station.
 - OFF-LINE Cyclic transmission is stopped by the host (HOST) station.
 - TOKEN The B/W/X/Y send areas are not set with (NO AREA) the host station.
 - TOKEN There is a parameter error with the host (AB. PARAM.) station.
 - TOKEN Common parameters are not yet received. (NO.RECV)
 - DISCONNECT Station numbers overlap. Cable is not con- (NO. BT) nected.
 - DISCONNECT Cable is not connected. (AB. LINE)
 - TEST BEING On-line or off-line test is being executed. EXECUTED
- (h) CAUSE OF COM- Cause of communication stop (transient MUNICATION STOP transmission) at the host station is displayed. (SW0048)
- NORMAL
 - TOKEN DUPLICAL . . . More than one baton has been received.
 - ONLINE TESTING . . . On-line test is being executed.
 - DUPLICATED STN . . . The station numbers overlap.
 - DUPLICATED More than one control station is set. CTRL
 - OTHERS Refer to the error codes list. (error code)
 - OFFLINE TEST Off-line test is being executed.
 - TOKEN ERASE
 - INITIAL STATUS
 - DELINKING
 - LINE TROUBLE
 - RECV. RETRY ERR
 - SEND RETRY ERR
 - SHIFT CTRL STN
 - OFFLINE
 - NO BATON (HOST)

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

- (i) CAUSE OF DATA LINK STOP Cause of data link stop (cyclic transmission) at the host station is displayed. (SW0049)
- NORMAL
 - STAT20N ()Cyclic transmission is stopped by another station.
 - HOST-STN.Cyclic transmission is stopped by the host station.
 - ALL STN. ()Cyclic transmission at all stations is stopped.
 - NO PARAMETERParameters are not yet received.
 - ABNORMALThere is a parameter error. PARAM.
 - PARAM.There is a matching error between common parameters and station specific parameters. UNMATCHED
 - I/O ALOC.The I/O allocation with the remote I/O network has an error. UNMATCH
 - OTHERSRefer to the error codes list. (error code)
 - COM. INTERRUPT
- (j) CONSTANT LINKSet conditions of constant link scan are displayed. (SW0068)
- (k) F. LOOPThe F loop condition is displayed. (SB0099, SW0090)
- NORMAL
 - LOOPBACK
 - NO DATA-LINK
- "--" is displayed when the bus system is monitored.
- (l) R. LOOPThe R loop condition is displayed. (SB009A, SW0090)
- NORMAL
 - LOOPBACK
 - NO DATA-LINK
- "--" is displayed when the bus system is monitored.
- (m) F. LOOPBACKThe loopback station number in the F loop is displayed. (SW0099)
STATION
"--" is displayed when the bus system is monitored.



5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

- (n) R. LOOPBACK STATIONThe loopback station number in the R loop is displayed. (SW009A)
"--" is displayed when the bus system is monitored.
- (o) LOOP CHANGE TIMESThe number of times of loop switching and loopback operations is displayed. (SW00CE)
"--" is displayed when the bus system is monitored.
- (p) RESERVEDThe set condition of reserve station is displayed. (SB0064)
- YES
 - NO
- (q) COMMUNICATION MODEThe link scan condition is displayed. (SB0068)
- NORMAL MODE
 - CONSTANT SCAN
- (r) TRANSMISSION DESIGNATEThe setting condition of multiplex transmission is displayed. (SB0069)
- NORMAL
 - DUPLEX
- "-----" is displayed when the bus system is monitored.
- (s) TRANSMISSION STATUSThe condition of multiplex transmission is displayed. (SB006A)
- NORMAL...
 - DUPLEX...
- "-----" is displayed when the bus system is monitored.

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

- (3) Checking the condition of communication, data link, CPU, and loop (Line monitor of another station)

The condition of the communication, data link, CPU, parameters, loop, and reserve stations at each station can be checked.

<LINE MON. OTHER STN. MODULE # 1>	
F1	COMMUNICATION STATUS
F2	DATA LINK STATUS
F3	PARAMETER STATUS
*1 { F4	OPERATION STATUS
F5	CPU RUN STATUS
F6	LOOP STATUS
F7	RESERVATION

Indication of items F1 to F4 and F6 shown above is highlighted when there is a faulty station, that of F5 is highlighted when there is a STOP station, and that of F7 is highlighted when there is a reserve station.


*1... These are not relevant in the case of a remote I/O network ("CANNOT SELECT." is displayed).

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

(a) Communication condition of each station: [F1]

The condition of transient transmission is displayed. (SW0070 to 73)
The condition display is given for the total number of link stations set with the common parameter.


Normal display Normal station, reserve station
Highlighted Faulty station



(b) Data link condition of each station: [F2]

The condition of cyclic transmission and transient transmission is displayed. (SW0074 to 77)
The condition display is given for the total number of link stations set with the common parameter.

Normal display Normal station, reserve station
Highlighted Faulty station



5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

(c) Parameter condition of each station: [F3]

1) The parameter communication condition is displayed.
(SW0078 to 7B)


The condition display is given for the total number of link stations set with the common parameter.

Normal display Other than during parameter communication, reserve station
Highlighted During parameter communication

2) The parameter condition is displayed. (SW007C to 7F)

The condition display is given for the total number of link stations set with the common parameter.

Normal display Parameter normal, reserve station, non-connected station
Highlighted Parameter error




(d) Loop condition of each station (Optical loop system only): [F6]

The forward/reverse loop condition is displayed.
(SW0091 to 94, SW0095 to 98)

The condition display is given for the total number of link stations set with the common parameter.

Normal display Normal, reserve station
Highlighted Faulty, non-connected station



5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

(e) Reserve designation of each station: [F7]

The reserve station designating condition is displayed.

The condition display is given for the total number of link stations set with the common parameter.

Normal display Non-reserved station



Highlighted Reserved station

<RESERVATION>							
						■ : RESERVED	
1	2	3	4	5	6	7	8

5.1.2 Condition monitor

The switch and parameter settings and conditions of data link, on-line/off-line test, etc. of the host station can be checked.

(1) Checking the module conditions of the host station (Condition monitor)



(a) MODULE TYPEThe type of module of the host station is displayed.

- MELSECNET/10

(b) STATION NUMBER . . .The host station number is displayed. (SW0042)

(c) NETWORK TYPEThe type of the network of the host station is displayed. (SB0040, SW0046)

- PC NET (LOOP)
- PCNET (BUS)
- REMOTE I/O (LOOP)
- REMOTE I/O (BUS)

(d) ONLINE SWITCHThe mode select switch condition of the host station is displayed. (SW0043)

- ONLINE
- NO ONLINE (master station only)

- (e) STATION TYPEThe station type setting with the host station is displayed. (SB0044)
- MASTER
 - REMOTE STATION
- (f) NETWORK NUMBER . .The network number of the host station is displayed. (SW0040)

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

MELSEC-A

(2) Checking the switch and parameter settings and data link condition of the host station (Detailed condition monitor)

- Check points in the screen
- Switch setting
 - Parameter settings
 - Data link condition
 - Data link start/stop condition

<DETAIL STATUS MONITOR MODULE # 1>			
HOST STATION		DATA LINK INFORMATION	
(a) → MODULE ID	COAXIAL SNGL	NO. OF STATIONS	8 ← (m)
(b) → NETWORK TYPE	PC NET (BUS)	MAX. NORMAL STN. #	3 ← (n)
(c) → MODULE STATUS	NORM	MAX. D/LINK STN. #	0 ← (o)
(d) → ONLINE SWITCH	AUTO RET	COM. STATUS	OFF-LINE (OTHER) ← (p)
(e) → SWITCH SETTING	NORM	CAUSE: COMM. STOP	NORM ← (q)
(f) → STATION SETTING	REMOTE STATION	CAUSE: D/LINK HALT	STATION (1) ← (r)
(g) → STATION NO.	2	DATA LINK STATUS (HOST)	
NO. OF B/W POINTS	-----	STARTUP STATUS	NO INSTRUCT ← (s)
USED PARAMETERS	-----	HALT STATUS	NO INSTRUCT ← (t)
(h) → PARAMETER ERROR	NO	DATA LINK STATUS (SYSTEM)	
LB/LW COMMU. STOPP	-----	STARTUP STATUS	COMPLETE ← (u)
LX AT COMMU. STOP	-----	HALT STATUS	NO INSTRUCT ← (v)
LB/LW AT D/LINK HALT	-----	HOST ERR. STATUS	
(i) → RESERVED	YES	HOST ERR. STATUS	NORMAL ← (w)
(j) → COM. MODE	CONSTANT SCAN		
(k) → TRANSM. DESIGNATE	NORMAL		
(l) → TRANSM. STATUS	NORMAL...		

(a) MODULE ID..... The type of the module is displayed. (SW0046)

Left	Right
Optical	Single
Coaxial	Duplex

(b) NETWORK TYPE..... The type of network is displayed. (SB0040, SW0046)

- PC NET (LOOP)
- PC NET (BUS)
- REMOTE I/O (LOOP)
- REMOTE I/O (BUS)

(c) MODULE STATUS..... The condition of the module is displayed. (SW0020)

- NORMAL
- (error code)

- (d) ONLINE SWITCHThe mode select switch condition is displayed. (SW0043)
 - AUTO RET
 - NON AUTO RET
 - OFFLINE
 - LOOP TEST (MASTER)
 - LOOP TEST (SUB.)
 - STN. TEST (MASTER)
 - STN. TEST (SLAVE)
 - HOST-LOOPBACK TEST
 - HOST-LOOPBACK (INTNL)
- (e) SWITCH SETTINGThe switch setting conditions of the module are displayed. (SB0045, SW0045)
 - NORMAL
 - (error code)
- (f) STATION SETTINGThe station type is displayed. (SB0044)
 - MASTER
 - REMOTE STATION
- (g) STATION NUMBERThe station number is displayed. (SW0042)
- (h) PARAMETERThe error condition of the parameter set with the host station is displayed. (SW0055)
 - ERROR
- (i) RESERVEDThe set condition of reserve station is displayed. (SB0064)
 - YES
 - NO
- (j) COMMUNICATIONThe link scan condition is displayed. (SB0068)
 - MODE
 - NORMAL MODE
 - CONSTANT SCAN
- (k) TRANSMISSIONThe setting condition of multiplex transmission is displayed. (SB0069)
 - DESIGNATE
 - NORMAL
 - DUPLEX"-----" is displayed when the bus system is monitored.
- (l) TRANSMISSIONThe condition of multiplex transmission is displayed. (SB006A)
 - STATUS
 - NORMAL...
 - DUPLEX..."-----" is displayed when the bus system is monitored.

- (m) NUMBER OF STATIONSThe total number of link stations set with the common parameter is displayed.
- (n) MAX. NORMAL STATION NUMBERThe maximum station number which is normally executing baton passing (transient transmission possible). (SW005A)
The T.PASS LED is lit.
- (o) MAX. DATA LINK STATION NUMBERThe maximum station number which is normally executing data link (cyclic and transient transmissions). (SW005B)
The D.LINK and T.PASS LEDs are lit.
- (p) COMMUNICATION STATUSCommunication condition of the host station is displayed. (SW0047)
- DATA LINKING
 - OFF-LINE (OTHER)Cyclic transmission is stopped by an other station.
 - OFF-LINE (HOST)Cyclic transmission is stopped by the host station.
 - TOKEN (NO AREA)The B/W/X/Y send areas are not set with the host station.
 - TOKEN (AB. PARAM.)There is a parameter error with the host station.
 - TOKEN (NO.RECV)Common parameters are not yet received.
 - DISCONNECT (NO. BT)Station numbers overlap. Cable is not connected.
 - DISCONNECT (AB. LINE)Cable is not connected.
 - TEST BEING EXECUTEDOn-line or off-line test is being executed.
- (q) CAUSE OF COMMUNICATION STOPCause of communication stop (transient transmission) at the host station is displayed. (SW0048)
- NORMAL
 - TOKEN DUPLICAL ..More than one baton has been received.
 - ONLINE TESTING ...On-line test is being executed.
 - DUPLICATED STN ..The station numbers overlap.
 - DUPLICATED CTRLMore than one control station is set.
 - OFFLINE TESTOff-line test is being executed.
 - OTHERS (error code)Refer to the error codes list.
 - TOKEN ERASE
 - INITIAL STATUS
 - DELINKING
 - LINE TROUBLE
 - RECV. RETRY ERR
 - SEND RETRY ERR

- SHIFT CTRL STN
 - OFFLINE
 - NO BATON (HOST)
- (r) CAUSE OF DATA LINK HALTCause of data link stop (cyclic transmission) at the host station is displayed. (SW0049)
- NORMAL
 - STAT20N ()Cyclic transmission is stopped by other station.
 - HOST-STN. INSTR.Cyclic transmission is stopped by the host station.
 - ALL STN. ()Cyclic transmission at all stations is stopped.
 - NO PARAMETERParameters are not yet received.
 - ABNORMAL PARAM.There is a parameter error.
 - PARAM. UNMATCHEDThere is a matching error between common parameters and station specific parameters.
 - I/O ALOC. UNMATCHThe I/O allocation with the remote I/O network has an error.
 - OTHERS (error code)Refer to the error codes list.
 - COM. INTERRUPT
- (s) STARTUP STATUSThe cyclic start condition from the host station to the host station is displayed. (SB0000, SB004C, SB004D, SW004D)
- NO INSTRUCT
 - INCOMPLETE
 - COMPLETE
 - ERROR (error code)
- (t) HALT STATUSThe cyclic stop condition from the host station to the host station is displayed. (SB0001, SB004E, SB004F, SW004F)
- NO INSTRUCT
 - INCOMPLETE
 - COMPLETE
 - ERROR (error code)
- (u) STARTUP STATUSThe cyclic start condition from the host station to the system is displayed. (SB0002, SB0050, SB0051, SW0051)
- NO INSTRUCT
 - INCOMPLETE
 - COMPLETE
 - ERROR (error code)

(v) HALT STATUSThe cyclic stop condition from the host station to the system is displayed. (SB0003, SB0052, SB0053, SW0053)

- NO INSTRUCT
- INCOMPLETE
- COMPLETE
- ERROR (error code)


(w) HOST ERRORThe host station condition and the slot No. STATUS when the error occurred are displayed. (SW004B, SW004C)

- NORMAL
- ERROR (error code)
- ERROR SLOT NO

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

MELSEC-A

(3) Checking the on-line/off-line test conditions of the host station (Test monitor)



- (a) INSTRUCTIONThe on-line test designation condition of the host station is displayed. (SB00A8)
- NOT RECV
 - RECEIVED
- (b) COMPLETIONThe on-line test end condition of the host station is displayed. (SB00A9)
- NOT RECV
 - COMPLETE
- (c) FROM OTHERThe on-line test response setting condition of the host station is displayed. (SB00AA)
- NOT RECV
 - RECEIVED
- (d) RESPONSE TOThe on-line test response end condition of the host station is displayed. (SB00AB)
- NOT RECV
 - COMPLETE
- (e) TEST ITEMThe execution items when the host station is on the on-line test request side are displayed. (SW00A8)
- LOOP CHECK
 - ENTRY CHECK
 - ORDER CHECK
 - COM. CHECK
- (f) ABNORMALThe error station number found in the test is displayed. (SW00AB)
- (g) RESULTThe test result when the host station is on the test request side is displayed. (SW00A9)
- (h) TEST ITEMThe execution items when the host station is on the on-line test response side are displayed. (SW00AA)
- LOOP CHECK
 - ENTRY CHECK
 - ORDER CHECK
 - COM. CHECK

- (i) RESULTThe test result when the host station is on the test response side is displayed. (SW00AB)
- (j) INSTRUCTIONThe off-line test designation condition of the host station is displayed. (SB00AC)
 - NOT RECV
 - RECEIVED
- (k) COMPLETIONThe off-line test end condition of the host station is displayed. (SB00AD)
 - NOT RECV
 - COMPLETE
- (l) FROM OTHER STATIONThe off-line test response setting condition of the host station is displayed. (SB00AE)
 - NOT RECV
 - RECEIVED
- (m) RESPONSE TO THE STATIONThe off-line test response end condition of the host station is displayed. (SB00AF)
 - NOT RECV
 - COMPLETE
- (n) TEST ITEMThe execution items when the host station is on the off-line test request side are displayed. (SW00AC)
 - F. LOOP TEST
 - R. LOOP TEST
 - STN. TEST (MASTER)
 - STN. TEST (SLAVE)
 - HOST-LP.BACK TEST

Only the master station can execute monitor.
- (o) ABNORMALThe error station number found in the test is displayed. (SW00AC)
- (p) RESULTThe test result when the host station is on the test request side is displayed. (SW00AD)
- (q) TEST ITEMThe execution items when the host station is on the off-line test respond side are displayed. (SW00AE)
 - F. LOOP TEST
 - R. LOOP TEST
 - STN. TEST (MASTER)
 - STN. TEST (SLAVE)
 - HOST-LP.BACK TEST

Only the master station can execute monitor.
- (r) RESULTThe test result when the host station is on the test respond side is displayed. (SW00AF)

5.1.3 Error list monitor

The lists of loop errors, communication errors, and transient transmission errors can be checked.

- (1) Checking the accumulated number of times of line errors (Error list monitor)

<ERROR HISTORY		MODULE 1>	
(a) →	# OF LOOP SWITCHING	0	# OF TRANSIENT ERR.
			0 ← (b)
	F. LOOP		R. LOOP
(c) →	RETRY	0	RETRY
(d) →	LINE TROUBLE	0	LINE TROUBLE
	COMMU. ERROR		COMMU. ERROR
(e) →	UNDER	0	UNDER
(f) →	CRC	0	CRC
(g) →	OVER	0	OVER
(h) →	SHORT FLAME	0	SHORT FLAME
(i) →	ABORT	0	ABORT
(j) →	TIME-OUT	0	TIME-OUT
(k) →	EXCEEDING 2KB	0	EXCEEDING 2KB
(l) →	DPLL ERROR	0	DPLL ERROR
			0

- (a) NUMBER OF LOOP SWITCHING ... The number of times of loop switching and loopback operations is displayed. (SW00CE)
- (b) NUMBER OF TRANSIENT ERROR ... The number of times of occurrences of the transient transmission errors is displayed. (SW00EE)
- (c) RETRY ... The number of times of retries (retransmission when communication is not successful) is displayed. (SW00C8, SW00C9)
- (d) LINE TROUBLE ... The number of times of occurrences of the line errors is displayed. (SW00CC, SW00CD)
- (e) UNDER ... The number of times of occurrences of the UNDER errors is displayed. (SW00B8, SW00C0)
- (f) CRC ... The number of times of occurrences of the CRC errors is displayed. (SW00B9, SW00C1)
- (g) OVER ... The number of times of occurrences of the OVER errors is displayed. (SW00BA, SW00C2)
- (h) SHORT FLAME ... The number of times of occurrences of the short frame errors (data text is too short) is displayed. (SW00BB, SW00C3)
- (i) ABORT ... The number of times of occurrences of the AB.IF errors is displayed. (SW00BC, SW00C4)
- (j) TIME-OUT ... The number of times of occurrences of the TIME errors is displayed. (SW00BD, SW00C5)

- (k) EXCEEDINGThe number of times of occurrences of the
2 KBYTE DATA errors is displayed.
(SW00BE, SW00C6)
- (l) DPLL ERRORThe number of times of occurrences of the
DPLL errors (data cannot be correctly rec-
ognized for synchronization or modula-
tion) is displayed. (SW00BF, SW00C7)

(2) Checking the factors for loop switching (Loop switching data display)

<LOOP SWITCHING HISTORY>			
	(a) REQUESTED BY	(b) FACTOR	(c) SWITCHED TO
1	1	F LOOP H/W ERROR	LOOPBACK
2	1	R LOOP H/W ERROR	LOOPBACK
3	1	F. LOOP ERROR COM.	R. LOOP
4	1	R. LOOP ERROR COM.	F. LOOP
5	1	F. LOOP MASTABLE ERR	R. LOOP
6	1	R. LOOP MASTABLE ERR	F. LOOP
7			
8			
9			
10			
11			
12			
13			
14			
15			
16			

- (a) REQUESTED BY The station number which requests loop switching or loopback is displayed. (SW00E0 to E7)
- (b) FACTOR The factor for executing loop switching or loopback is displayed. (SW00D0 to DF)
- RETURN INSTR.
 - F.LOOP H/W ERROR Cable or optical module is faulty.
 - R.LOOP H/W ERROR
 - F. LOOP ERROR COM. Forced error for executing loopback.
 - R. LOOP ERROR COM.
 - F. LOOP MAST-ABLE ERR Normal and abnormal conditions repeat alternately and communication condition is instable.
 - R. LOOP MAST-ABLE ERR
 - F.LOOP SEQ-LIN ERR
 - R.LOOP SEQ-LIN ERR
- (c) SWITCHED TO The condition of data link after loop switching is displayed. (SW00D0 to DF)
- DUPLEXReturned to the initial state.
 - F. LOOP
 - R. LOOP
 - LOOPBACK

- (3) Checking errors occurred with transient transmission (Transient transmission error)

Error factors are stored in SW00F0 to FF.
Refer to the error codes list for details.

<TRANSIENT ERROR>		
	ERR. CODE	ERROR TYPE
1		
2		
3		
4		
5		
6		
7		
8		
9		
10		
11		
12		
13		
14		
15		
16		

- (4) Clearing error history contents

(a)	→ F1	RETRY COUNTER CLEAR
(b)	→ F2	COMM. ERROR COUNTER CLEAR
(c)	→ F3	FORWARD TRANSM. ERROR CLEAR
(d)	→ F4	REVERSE TRANSM. ERROR CLEAR
(e)	→ F5	LOOP SWITCH COUNTER CLEAR
(f)	→ F6	TRANSIENT TRANSMISSION ERROR CLEAR

(a) RETRY COUNTER CLEARClears item (c) in Section 5.1.3 (1). (SB0005)

(b) COMMUNICATION ERROR COUNTER CLEARClears items (e) through (l) in Section 5.1.3 (1). (SB0006)

(c) FORWARD TRANSMISSION ERROR CLEARClears item (d) in Section 5.1.3 (1). (SB0007)

(d) REVERSE TRANSMISSION ERROR CLEARClears item (d) in Section 5.1.3 (1). (SB0008)

(e) LOOP SWITCH COUNTER CLEARClears item (a) in Section 5.1.3 (1) and item (b) in Section 5.1.3 (2). (SB0009)

(f) TRANSIENT TRANSMISSION ERROR CLEARClears item (c) in Section 5.1.3. (SB000A)

5.2 Network Diagnosis

By using the network diagnosis function of a peripheral device, line conditions can easily be checked and diagnosed. Testing can be performed from any station, regardless of whether it is a master station or a remote I/O station.

This function permits diagnosis while the network module is online if trouble occurs while the system is operating.

For details on the operation and screen displays for each function, refer to the Operating Manual for the GPP function.

Item	Optical Loop System	Coaxial Bus System	Data Link Condition (Cycle Transmission/Transient Transmission)
Loop test	○	x	Suspended
Setting confirmation test	○	○	Suspended
Station order confirmation test	○	x	Suspended
Communication test	○	○	Run

○: Execution possible x: Execution impossible

POINTS

- (1) Perform diagnosis in which data link operation is temporarily stopped at appropriate times, for example during system start-up. If such diagnosis is performed while the system is operating, make sure that the following conditions will not cause problems:
 - (a) Stopping of data link operation during online diagnosis.
 - (b) The failure to reset stations or execute RUN/STOP switching (online diagnosis may be completed abnormally).
- (2) Perform the setting confirmation test, station order confirmation test, and communication test after confirming that the line condition is normal by performing a loop test.

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

5.2.1 Loop test (Optical loop system only)

When the optical loop cable connections are completed, check the forward and reverse loops. The loopback executing station can also be checked during the loopback operation.

For example, in the system condition shown in Fig. 5.1 below, when the loop test is conducted by using a peripheral device connected to 1MR, the monitor screen shown in Fig. 5.2 below is displayed indicating that 1R4 is faulty, and 1R3 and 1R1 are executing loopback operation.




Fig. 5.1 System Condition

TEST : ~~PARAMETER~~
 : # OF STN [] <REMOTE MASTER>
 [DATA LINK : NORM]

<LOOP TEST RESULT> <STATION STATUS>

MODULE [1] TOTAL [8] A: # OF STN [0] (WRONG CABLE CONNECTION)
 B: # OF STN [1] (NO RESPONSE)

LOOP [LOOPBACK]

Reserve stations are not displayed.

1	3	4	5	6	7	8														
		B																		

Fig. 5.2 Loop Test Display Screen

5.2.2 Setting confirmation test

Switch settings with the network module can be checked. The following checking items are provided:

For example, in the system condition shown in Fig. 5.3 below, when the setting confirmation test is conducted by using a peripheral device connected to 1MR, the monitor screen shown in Fig. 5.4 below is displayed, and the set conditions of each station can be checked.




Fig. 5.3 System Condition

<REMOTE I/O> TEST : PARAMETER / # OF STN [] MASTER STN: []
 MODULE [1] HOST STN # [1] NETWORK # [1] CTRL STN # [1] TOTAL [8]

(STN. #)	1	2	3	B 4	5	6	7	8									
(NETWORK #)	E	--	--	--	--	--	--	--									
(GROUP #)	--	D	D	--	--	--	--	--									
(STN. #)																	
(NETWORK #)																	
(GROUP #)																	
(STN. #)																	
(NETWORK #)																	
(GROUP #)																	

A: CTRL STN DUPLIX B: STN DUPLIX C: NETWORK # ER D: RESERVED E: ABNORMAL

Fig. 5.4 Setting Confirmation Test Display Screen

5.2.3 Station order confirmation test

Station numbers in an optical loop system can be checked. The following checks can be done according to the loop condition (displayed on the test result screen as shown in Fig. 5.6 on the next page):

Loop Condition	Display Contents
Forward and reverse loops	Station numbers connected in the forward loop direction and those connected in the reverse loop direction both beginning with the host station.
Forward loop	Station numbers connected in the forward loop direction beginning with the host station.
Reverse loop	Station numbers connected in the reverse loop direction beginning with the host station.
Loopback	Station numbers connected in the forward loop direction beginning with the host station.

For example, in the system condition shown in Fig. 5.5 below, when the station order confirmation test is conducted by using a peripheral device connected to 1M_R, the monitor screen shown in Fig. 5.6 below is displayed indicating the station numbers connected in the forward loop direction are executing the loopback operation.




Fig. 5.5 System Condition




Fig. 5.6 Station Order Confirmation Test Display Screen

5.2.4 Communication test

Communications between the host station and the destination (designated with network number and station number) can be checked. Also, when the destination is in other network, the relay network number and station number are displayed during this test so that the routing parameter settings can be checked.

For example, in the system condition shown in Fig. 5.7 below, when the communication test is conducted by using a peripheral device connected to 1R1 in network number 1 to 4Ns6 in network number 4, the monitor screen shown in Fig. 5.8 below is displayed indicating that the routing parameters are not correctly set.




Fig. 5.7 System Condition




Fig. 5.8 Communication Test Display Screen

5. OPERATIONS POSSIBLE AT PERIPHERAL DEVICES

If the routing parameter settings are incorrect, "PC COMMUNICATION ERROR" is displayed and no communication test result is displayed.




Fig. 5.9 System Condition




Fig. 5.10 Communication Test Display Screen

DETAIL DESCRIPTION

6. SYSTEM CONFIGURATIONS

This section describes the configurations, usable device ranges, and parameter setting items, for each system.


6.1 Two-Tier System

(1) System configuration

(a) Optical loop system/Coaxial loop system

A maximum of 64 remote I/O stations can be connected to a single master station.


The master station CPU must be an AnUCPU.



(b) Coaxial bus system

A maximum of 32 remote I/O stations can be connected to a single master station.


The master station CPU must be an AnUCPU.



(2) Usable device ranges

All of B/W 0 to 1FFF (8192 points) can be used.

As for the X/Y ranges, the range after actual I/O points (the I/O device number ranges in which I/O modules and special function modules are actually installed) in 0 to 1FFF (8192 points) can be used.



(3) Parameter setting items

Set the parameters at the master station.

Item	Setting	Reference Section
Number of modules	◎	Section 9.1.1
Network refresh parameters	○	Section 9.1.2
Common parameters	◎	Section 9.1.3
Station specific parameters	—	—
Transfer parameters for data link	—	—
Routing parameters	x	—

◎ : Must always be set

○ : Change if necessary (default setting is provided)

— : Set if necessary

x : Setting not possible

(4) Maximum number of link points per remote I/O station

Master station → Remote I/O station

$$\frac{LB+LY}{8} + (2 \times LW) \leq 1600 \text{ bytes}$$

Remote I/O station → Master station

$$\frac{LB+LX}{8} + (2 \times LW) \leq 1600 \text{ bytes}$$


6.2 Multi-Tier System

A multi-tier system is a system in which multiple network modules (AJ71LP21/BR11) and data link modules (AJ71AP21/AR21) are mounted to an AnUCPU.

(1) The numbers of modules indicated below can be mounted to an AnUCPU.

- 4 network modules max.
- 2 data link modules max. } Total of 4 modules

(2) If multiple modules are installed, as in the system example shown below, care is required when setting the parameter settings.




- MELSECNET
 - MELSECNET/10 PC-to-PC network
 - MELSECNET/10 Remote I/O network
- } Each of these networks operate independently

[Concept for parameter settings]


(a) B/W settings

An AnUCPU has 8192 B/W points, a network module 8192 B/W points, and a data link module 4096 B/W points. Accordingly, the B/W allocations must be made within the device range of the AnUCPU, as shown below.



(b) X/Y settings

An AnUCPU has 8192 X/Y points, a network module 8192 X/Y points, and a data link module 2048 X/Y points. Accordingly, the X/Y allocations must be made within the device range of the AnUCPU, as shown below.



6. SYSTEM CONFIGURATIONS

MELSEC-A

(c) Parameter setting items

The parameter settings that have to be made for each station are shown below.

Setting Item	Mp(Ns) Station	MR Station	L Station	m Station
Number of modules			◎	
Network refresh parameters	○	○	x	○
Common parameters	◎ (x)	◎	x	x
MELSECNET parameters	x	x	x	◎
Station specific parameters	△	x	x	x
Transfer parameters for data link	△	x	△	△

◎: Must always be set

○: Change if necessary (default setting is provided in accordance with the number of modules setting)


△: Set if necessary

x: Setting not possible

7. FUNCTIONS

This section describes the functions of the MELSECNET/10 remote I/O system.

The function list is given below.




7.1 Cyclic Transmission Function

The cyclic transmission function is a function whereby data is periodically communicated between the master station and remote I/O stations.

7.1.1 Communication with an I/O module


It is possible to communicate with an I/O module by using X/Y (LX/LY) devices.



- (1) When X00 of the input module at the remote I/O station turns ON, X1000 of the master station turns ON.
- (2) When Y1010 of the master station turns ON, Y10 of the output unit at the remote I/O station turns ON.

7.1.2 Communication with a special function module

It is possible to communicate with a special function module by using X/Y (LX/LY) and B/W (LB/LW) devices.



[Buffer memory]

- (1) When a ZNFR/ZNTO instruction is executed...
 - (2) ZNFR The buffer memory data is written to W devices.
ZNTO The data in the W devices is written to the buffer memory.
 - (3) On completion of the ZNFR/ZNTO instruction the completion signal (M0) comes ON for 1 scan.
- * LB devices are used for handshake processing when an instruction is executed.
LW devices are used for handshake processing and for data reading/writing when an instruction is executed.

[Input/output]


- (4) X/Y communications are executed in the same way as communications with an I/O module.

7.1.3 Stop/restart function

Stop/restart of cyclic transmission is executed from a peripheral device.

(1) Method for stop/restart

Stop/restart is executed using the "network test" function of the network monitor.




(2) Operation for stop/restart

In the case of a remote I/O network, all stations within the same network are stopped/restarted. It is not possible to stop/restart individual stations.

(a) Stop


Cyclic transmission is stopped at all stations (including the host station). ([F6] key)



(b) Start


1) Start (link start)

The network system can be started by a request of the station from which the stop was requested. ([F3] key)



2) Forced start (forced link start)

The network system can be started by a request of any station other than the stop-requested station. ([F9] key)



POINT

- (1) All stations are treated as stations at which communication is stopped.
- (2) The station in the offline mode does not change its operation even if a link stop/restart is executed.
Since there is no response from the station in the offline mode, no error is detected in the source station of start request.

7.2 Transient Transmission Function

The transient transmission function is a function whereby communication is executed only when there has been a communication request.

The request source for transient transmission can be either of the following:

- A peripheral device
- A special function module (one that can specify communication destinations such as AJ71UC24 and AD51H(S3) modules)


7.2.1 Communication range

The master station (MR) can communicate with all remote I/O stations (R) and all stations (Mp, Ns, N) in a PC network.

A remote I/O station (R) can communicate with the master station (MR) and all stations (Mp, Ns, N) in a PC network.

Communication between remote I/O stations is not possible.

[Example system configuration]



Transient Transmission Range

Request Source \ Request Destination	1Mp1	1Ns2	1Ns3 2MR	1N4	2R1	2R2
1Mp1	Host station	O	*1	O	O *5	O *5
1Ns2	O	Host station	*1	O	O *5	O *5
1Ns3 *3	O	O	Host station	O	O	O
2MR	O	O	Host station	O	O	O
1N4	*4	x	x	Host station	x	x
2R1	O	O	*2	O	Host station	x
2R2	O	O	*2	O	x	Host station

- O : Possible
- x : Not possible
- *1 : Possible by specifying 1Ns3 (network No.1, station No.3)
- *2 : Possible by specifying 2MR (network No.2, station No.0)
- *3 : Same even if a control station (Mp)
- *4 : Possible by specifying PC No.0 via MELSECNET(II)
- *5 : Routing parameters must be set.

Note: An error (buffer full error: F222) may occur if transient communications from multiple stations (4 or more) are concentrated at one station. Ensure that there is a sufficient interval between transient transmissions.

7.2.2 Routing function

The routing function allows an AnUCPU station to execute transient transmission to a station in another network.

To use the routing function, it is necessary to set the "routing parameters" so that the network number corresponds to the station which serves as the bridge.


The routing function via MELSECNET(II) cannot be used.

(1) The routing parameters need to be set at the AnUCPU request source and relay stations.

(a) The relay station needs settings for accessing from the request source to the destination and that from the destination to the request source.

(b) The destination does not need settings.

For example, to execute transient transmission from 1R3 to 3Ns4, the routing parameters need to be set at the AnUCPU in 1Mr, 2Mp1, 2Ns4, and 3Ns5 which serve as the bridges.



(2) Up to 64 "destination network numbers" can be set with the AnUCPU.


When the host station is the request source or when making access to other stations via the host station, a total of 64 network numbers can be used with the routing function.

(3) Positions and contents of routing parameter settings

The positions and contents of routing parameter settings for transient transmission vary according to the type of system.


(a) Two-tier system

It is not necessary to set the routing parameter.



(b) Multi-tier system 1... Two networks

It is not necessary to set the routing parameter.




(c) Multi-tier system 2... Three networks

Set the routing parameter at the relay stations.

Make settings at the request source for accessing the destination (network number 3).

Make settings at relay station 1 for accessing the destination (network number 3).

Make settings at relay station 2 for accessing the request source (network number 1).



(d) Multi-tier system 3 . . . Four networks or more


Set the routing parameter at the relay stations.

Make settings at the request source for accessing the destination (network number 4).

Make settings at relay station 1 (closest to the source) for accessing the destination (network number 4).


Make settings at relay station 2 (closest to the destination) for accessing the request source (network number 1).

Make settings at relay station 3 (other than relay stations 1 and 2) for accessing the destination (network number 4) and the request source (network number 1).




POINTS

(1) The routing function can use up to seven relay stations as shown below.



(2) When networks are connected in a loop as shown below, set the routing parameter so that the same relay stations are used for accessing the destination and for accessing the source. Do not set the routing parameter in which the access route makes one turn around the loop.




7.3 Reserve Station Function

The reserve station function permits stations that are to be connected in the future (i.e. stations that are included in the number of stations but are not actually connected) to be set so that they are not treated as faulty stations.

Since the "reserve stations" are not treated as faulty, they have no effect on link scan time.

Reserve stations are set in the common parameters (see Section 9.1.3).



COMMON PARAM. (MELSECNET/10) REMOTE I/O				PARAM. NAME		
MODULE NO.		REFRESH PARAMETER		Size		
1		LX↔X(1)	0000-1FFF	8192		
		LX↔X(2)	-			
		LY↔Y(1)	0000-1FFF	8192		
		LY↔Y(2)	-			
NO. OF STN.	LINK WDT * 10 ms	REMOTE I/O STN. NO.	M→R		M←R	
			LY	LY	LX	LX
4	200	1	1000 - 102F	0000 - 002F	1130 - 115F	0000 - 002F
		2	1250 - 128F	0050 - 008F	1200 - 124F	0000 - 004F
		RSV. 3	1300 - 134F	0000 - 004F	1330 - 13CF	0030 - 00CF
		4	1420 - 143F	0020 - 003F	1400 - 141F	0000 - 001F
		-	-	-	-	
		-	-	-	-	
		-	-	-	-	
Page Up/Page Down MODULE CHANGE Shift + F1, F2, F3, F4 End CHECK & SET Esc CLOSE						

(2) Precautions on I/O allocations

(a) Relationship between mounted modules and I/O allocations

The operating status differs according to the combination of I/O allocations and mounted modules.

The table below covers the various combinations.

I/O Allocation \ Mounted Module	Input	Output	Special	Vacant
None	O	O	O	*3
Vacant	—	—	—	*4
Input	O *1	—	x	*4
Output	O *1	O *1	x	*4
Special	x	x	O *2	—

O : Normal operation


— : Failure to operate

x : Failure to operate (if parameter error occurs → PRM.E. LED lights)

*1: The number of installation points is different from the number of I/O allocation points.


i) Number of installation points < Number of I/O allocation points

The excess I/O allocation points beyond the number of installation points are treated as dummy (idle) points.



ii) Number of installation points > number of I/O allocation points

The installation points beyond those covered by the number of I/O allocation points cannot be controlled.



*2: This only applies when the number of installation points and number of I/O allocation points are equal.

If the numbers of points are different, the system will not operate normally.

*3: Treated as 16 points.

*4: The application differs according to the I/O allocation.

- VacantUsed to set "0" points for the vacant slot.
- Input/output . . .Used to reserve points for mounting an input/output module in the future.

(b) Common parameter settings

Set the common parameters in accordance with the module information set using I/O allocation, as shown in the example below.

If the parameter settings are made on the basis of the actual module installation status, the system will not operate normally.

[Module configuration]

		0 to 3F	40 to 5F	60 to 6F	70 to 8F	90 to AF
A61P	AJ72LP25	Input 64 points	Output 32 points	Vacant 16 points	Special 32 points	Output 32 points

[I/O allocations]

Set "0" points for vacant slots

		0 to 3F	40 to 5F	60 to 7F	80 to 9F
Slot No.	I/O module	0 X64	1 Y32	2 S 0	3 F32
				4 Y32	

[Common parameters]

REMOTE I/O STN. NO.	M → R		M ← R	
	LY	LY	LX	LX
1	1040-109F	0040-009F	1000-107F	0000-007F
	-	-	-	-
	-	-	-	-
	-	-	-	-

7.5 Extension Function

The extension function permits the extension of MELSECNET/10 functions. This function is set using the "extension setting" in the common parameters.

<EXTENDED SET>	
CONSTANT LINK SCAN	[1]ms (0-500)
MAX. # OF RECONNECTION STN.	[2]STATION (1-16)
DUPLEX COMMUNICATION	[0] 0:NO 1:YES
ACCESSED ZNFR/ZNT0	[64] (1-64)
End: SET Esc: CLOSE	

7.5.1 Constant link scan function

The constant link scan function prevents the fluctuation of the link scan time due to the transient transmission function and noise, keeping it constant.


If the response time to a transient request is long, setting the constant link scan function may be effective to shorten the response time.

Set the constant link scan time to "(link scan time when all stations are normal) + 4 ms or longer".

The default is 0 ms (constant link scan function not effective).


(1) No constant link scan setting (set 0 ms)

Since the link scan is executed repeatedly, the link scan time is the time actually required for the link scans.



(2) Constant link scan setting made (set between 1 and 500 ms)


(a) Provided that the time actually required for the link scan is shorter than the constant link scan set value, the link scan time is kept constant.



- (b) Note that if the time actually required for the link scan is longer than the constant link scan set value, processing will be done in the required link scan time and it will not be possible to maintain the constant link scan time.

Such a situation can arise in the following cases:


- 1) When the network control station starts up.
- 2) When a station goes down or is reset.
- 3) When the line is unstable (communication is sometimes possible and sometimes not).
- 4) When the loop is switched (optical loop systems only).
- 5) When a cable has been disconnected (coaxial bus systems only).




7.5.2 Multiplex Transmission Function (Optical Loop System)

The multiplex transmission function allows a high speed transmission using a duplex channel (forward and reverse loops) in an optical loop system. To use this function, make settings with the "expansion setting" of the common parameter.

- (1) The multiplex transmission function uses both loops to execute efficient and high speed transmissions.



- (2) When an error occurs in the transmission channel during multiplex transmission, either the forward loop or the reverse loop is used to execute normal or loopback operation for continued data link. The transmission speed in that case is 10 MBPS.



REMARK

The multiplex transmission function is effective in reducing the link scan time when the total number of link stations is 16 or more and the link device size allocated with the common parameter is 2048 bytes or more.

The link scan time becomes 1.1 to 1.3 times shorter when compared with that when the multiplex transmission function is not used.

7.5.3 Number of online return stations setting function

The number of online return stations setting function allows the number of stations that can be returned to the online status during one link scan to be set.

Setting multiple stations enables more than one faulty station to be returned to the online status during one link scan.

However, the link scan time will be increased (max. 12 ms x number of stations, normally 3 ms x number of stations).

The default setting is two stations. The setting range is 1 to 16 stations.

7.5.4 Number of ZNFR/ZNTO accesses setting function

The number of ZNFR/ZNTO accesses setting function enables setting of the number of modules in one remote I/O station for which instructions can be executed in one scan.


This function can be set to prevent the scan time from being prolonged.

The default setting is 64. The setting range is 1 to 64.


Example: When "3" is set for the number of ZNFR/ZNTO accesses setting function

- (a) The data for the ZNFR/ZNTO instruction execution is arranged in the order of modules.
- (b) The numbers of special function modules that have executed ZNFR/ZNTO instructions are recorded in a pointer.
- (c) ZNFR/ZNTO instructions for 3 special function modules after the one indicated by the pointer are executed.

<System configuration>



<ZNFR/ZNTO instruction execution>



POINT

Execution of subsequent ZNFR/ZNTO instructions for the same special function module is ignored until the previous processing has finished (until the completion signal comes ON).

7.6 RAS Function


The RAS function stands for Reliability, Availability, and Serviceability. This is referred to as comprehensive usability of automated equipment.

7.6.1 Loopback function (Optical/Coaxial loop system)

The optical/coaxial loop system uses a duplex channel. When an error or fault occurs in the channel, the erroneous or faulty part is bypassed by switching the forward and reverse loops or by executing loopback operation to maintain the data link with the available stations.

(1) When normal


Either the forward loop or the reverse loop is used for data link.



(2) When abnormal


(a) Forward loop (reverse loop) is faulty

The reverse (forward) loop is used to continue data link.



(b) Stations are down

Halted stations are excepted and data link is continued.
 When two or more stations are down, the stations between the halted stations are also excluded from data link.




(3) Precautions for using the optical/coaxial loop system

(a) When a cable is connected or disconnected, the loop may sometimes be switched.

(b) When the loopback operation is executed due to cable breakage, both the forward and reverse loops may be normally operated depending on the conditions of the cable breakage.

When a forward loop cable between stations 1MR and 1R1 and a reverse loop cable between stations 1R3 and 1R4 breaks, data link is continued among stations, 1MR, 1R5 and 1R4 (as shown below). Since the receive side cables of the loopback stations (reverse loop of 1MR and forward loop of 1R4) in the 1MR-1R5-1R4 loop are normal, both the forward and reverse loops are normal.



- (4) If the network module has become faulty, the loopback function may not be performed depending on the fault. In that case, the data link may stop.

Identify the faulty network module in the following method.


- (a) Check the LEDs (RUN LED off, ERROR LED on) of all network modules for a faulty indication.
- (b) Power off all stations and power them on one by one, starting from the control station. At that time, check up to which station a normal data link is performed.

Replace the faulty network module and make sure that the data link is restored to normal.

7.6.2 Station separation function (Coaxial bus system)


When a station is down due to power failure, the station is separated and data link is executed with the available stations.

(1) When normal




(2) When abnormal

Down station is excluded and data link is continued.



POINT

When the cable is disconnected, terminal resistance is also disconnected and data link becomes impossible.



7.6.3 Automatic online return function


The automatic online return function allows stations that have been disconnected from the data link to be automatically returned to it when they recover normal status.

To use this function, set the mode select switch of the network module to "0".

(1) When the master station goes down

If the master station goes down, all stations go down. However, transient transmission is possible at those stations whose T.PASS LED is lit.


When the master station recovers normal status, all stations are returned to the data link.



(2) When a remote I/O station goes down

Only the remote I/O station that has gone down is disconnected.

The remote I/O module is returned to the data link when it recovers normal status.



7.6.4 Diagnosis function

The diagnosis function allows confirmation of MELSECNET/10 line conditions and network module switch settings.

(1) Offline diagnosis

By setting a network module to the test mode, the hardware, data link cable wiring, etc., can be checked during system start-up.
For the test method, see Section 3.4.

(2) Online diagnosis

The network diagnosis function of a peripheral device allows the line conditions, network module settings, etc., to be checked easily.
If trouble occurs while the system is operating, diagnosis can be performed while the network module is still online.
For the test method, see Section 5.2.

(3) Network monitor

The network monitor function of a peripheral device allows the line conditions, data link conditions, etc., to be checked easily.
Monitoring is performed using the special relays (SB) and special registers (SW) that store the data link conditions.
For the test method, see Section 5.1.

(4) Data link condition detection function

This function allows the data link conditions to be monitored easily from a peripheral device.
The data link conditions are stored in the special relays (SB) and special registers (SW) of the network module.
The stored data link conditions can also be used for interlock signals in a sequence program.
For details on the contents of the special relays (SB) and special registers (SW), see Section 10.

7.6.5 Fuse blown error/I/O verify error check disable function (error clear function)

This function disables a check for a fuse blown error (*1) or I/O verify error at a remote I/O station on the remote I/O network of a MELSECNET/10 network system.

The setting of this function allows the fuse blown error or I/O verify error detected by the remote I/O station to be cleared from the master station side program.

REMARK

*1: When the remote I/O station is the AnS series, it detects the external supply power OFF of the output module as a fuse blown error.

(1) Function explanation

- (a) When the remote I/O station is the AnS series, it detects a fuse blown error if the external supply power of the output module at the remote I/O station is switched OFF during network system operation. Since the error check of the remote I/O station can be disabled by turning ON the corresponding special relay at the master station before powering OFF the external supply, the master station can continue operation without any error.
- (b) If the fuse blown error/I/O verify error is detected at the remote I/O station, turning ON the corresponding special relay allows the master station to clear the error of the remote I/O station and continue operation.

(2) Related special relay SB

By operating the corresponding special relay SB indicated in the following table, the master station clears the fuse blown error or I/O verify error of the remote I/O station.

SB000D (13) *4	Fuse blown error check/error clear	Clears the fuse blown error detected by the remote I/O station, or disables a check for a fuse blown error at the remote I/O station. OFF: Error check enable, clear command disable. ON : Error check disable, clear command enable. (Valid when ON)
SB000E (14) *4	I/O verify error check/error clear	Clears the I/O verify error detected by the remote I/O station, or disables a check for an I/O verify error at the remote I/O station. OFF: Error check enable, clear command disable. ON : Error check disable, clear command enable. (Valid when ON)


(3) Precautions for using the special relays

- (a) In consideration of the transmission delay time from the master station to the remote I/O station, turn ON SB000D and SB000E for more than two seconds.
- (b) The remote I/O station and module where the error will be cleared cannot be specified for SB000D and SB000E. The special relays are made valid for all the remote I/O stations and modules on the network.

(4) Operating procedure


The following is the procedure to disable a fuse blown error check at the remote I/O station when the external supply power of the A1S series output module on the remote I/O station is switched OFF/ON.

- (a) Turn ON SB000D (Y1C0D) at the master station to "disable" the fuse blown error check of the remote I/O station.
- (b) Two seconds after turning ON SB000D, switch OFF the external supply power of the output module on the remote I/O station.
- (c) Take a necessary action for the remote I/O station (e.g. output module replacement, wiring repair).
- (d) After completion of the action taken for the remote I/O station, switch ON the external supply power of the output module on the remote I/O station.
- (e) In response to the output Y for switching ON the external supply power, hold SB000D from turning OFF to make the delay time elapsed until the external supply power is actually supplied to the output module.
- (f) After the waiting time has elapsed, turn OFF SB000D to return the fuse blown error check of the remote I/O station to "Enable".




(5) Program example

(a) System configuration



(b) Program example



8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

This section describes the methods for sending/receiving data, and the processing time, in a MELSECNET/10 remote I/O network.

8.1 Link Data Send/Receive Processing

8.1.1 Outline of send/receive processing

In a MELSECNET/10 remote I/O network, a data link with remote I/O stations is established by setting the number of stations, device ranges, etc., at the AnUCPU of the master station.

Described here is the data send/receive processing in such a data link.

Send/receive processing involves "link refresh" and "link scan" processing.

(1) Link refresh

This is the processing in which data is exchanged between the AnUCPU and a network module.

(a) The devices sent to the remote I/O station (Y, LY) are written from the device memory storage area of the AnUCPU to the refresh data storage area of the network module.

The devices received from the remote I/O station (X, LX) are read from the refresh data storage area of the network module to the device memory storage area of the AnUCPU.

(b) The range of devices subject to link refresh is determined by the network refresh parameters and the common parameters. (See Section 9.1.2)

(c) Link refresh is executed in the AnUCPU's END processing.

(2) Link scan

This is the processing in which data is exchanged between a network module of a master station and a network module of a remote I/O station.

(a) The link device range allocated in the common parameters is continually communicated between the master station and remote I/O stations.


(b) When one link scan has been completed, data is exchanged between the refresh data storage area and the link data storage area.

(c) The data communication is synchronized with the AnUCPU sequence scan.

8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME


MELSEC-A

[Flow of communicated data]




(3) Relationship between sequence scan and link scan

(a) Sequence scan > Link scan



(b) Sequence scan < Link scan




→ Link refresh timing

8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

MELSEC-A

8.1.2 Link data when there are faulty stations or stations where communication is stopped

If a communication error occurs, or communication stops, at a station while the data link is operating, the data of the LX, LB and LW devices that has been received from the station is latched.



8.1.3 Data link condition and PC CPU status

In the master station PC CPU statuses indicated below, the data link is temporarily stopped.

- (1) When the mode is switched from STOP to RUN.
- (2) When the system is RESET.

8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

8.2 Transmission Delay Time

8.2.1 X/Y communication

The transmission delay time for X/Y communication is determined from the following three times by using the formulae presented below:

- Sequence program scan time in the master station
- Link refresh time (see Section 8.2.3)
- Link scan time (see Section 8.2.4)

[X transmission delay time (T_{DX})]

[Sequence scan (S_m) > Link scan (LS)]

$$T_{DX} = (\underline{S_m} + \alpha m) - LS + RS \times 2 \text{ [ms]}$$

[Sequence scan (S_m) < Link scan (LS)]


$$T_{DX} = \left\{ (S_m + \alpha m) \times \left(\frac{LS + \alpha r}{S_m + \alpha m} \right)^{-1} \right\} - LS + RS \times 2 - \alpha r \text{ [ms]}$$

Note: The parts underlined with lines are different.


S_m : Sequence program scan time in the master station
 αm : Link refresh time for master station *2
 αr : Link refresh time for a remote I/O station *2
 LS : Link scan time
 RS : Link scan time for a remote I/O station

*1 Decimal fractions are rounded up
 *2 This is the total for the number of network modules installed.

[Sequence scan (S_m) > Link scan (LS)]



[Sequence scan (S_m) < Link scan (LS)]



8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

MELSEC-A

[Y transmission delay time (T_{DY})]

[Sequence scan (S_m) > Link scan (LS)]

$$T_{DY} = (S_m + \alpha_m) + LS + \alpha_r \text{ [ms]}$$

[Sequence scan (S_m) < Link scan (LS)]


$$T_{DY} = \left\{ (S_m + \alpha_m) \times \left(\frac{LS + \alpha_r}{S_m + \alpha_m} \right)^{*1} \right\} + LS + \alpha_r \text{ [ms]}$$

Note: The parts underlined with lines are different.


- S_m : Sequence program scan time in the master station
- α_m : Link refresh time for master station *2
- α_r : Link refresh time for a remote I/O station *2
- LS : Link scan time

- *1 Decimal fractions are rounded up
- *2 This is the total for the number of network modules installed.

[Sequence scan (S_m) > Link scan (LS)]



[Sequence scan (S_m) < Link scan (LS)]



8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

MELSEC-A

8.2.2 ZNFR/ZNTO instructions

The transmission delay time for ZNFR/ZNTO instructions is determined from the following three times by using the formulae presented below:

- Sequence program scan time in the master station
- Link refresh time (see Section 8.2.3)
- Link scan time (see Section 8.2.4)

[Instruction transmission delay time (M_D)]

[Sequence scan (S_m) > Link scan (LS)]

$$M_D = (S_m + \alpha m) \times 3 \text{ [ms]}$$

[Sequence scan (S_m) < Link scan (LS)]

$$M_D = \left\{ (S_m + \alpha m) \times \left(\frac{LS + \alpha r}{S_m + \alpha m} \right)^{*1} \right\} \times 3 \text{ [ms]}$$


Note: The parts underlined with lines are different.

S_m : Sequence program scan time in the master station
 αm : Link refresh time for master station *2
 αr : Link refresh time for a remote I/O station *2
 LS : Link scan time


*1 Decimal fractions are rounded up

*2 This is the total for the number of network modules installed.

[Sequence scan (S_m) > Link scan (LS)]



[Sequence scan (S_m) < Link scan (LS)]



8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

MELSEC-A

8.2.3 Link refresh time

The link refresh time (extension of the END processing time in the CPU) is determined from the following two factors by using the formulae presented below:

- Number of allocated link device points
- CPU type used

[Link scan time for master station (α_m)]

$$\alpha_m = KM1 + KM2 \times \left(\frac{B + X + Y + SB + (W + SW) \times 16}{8} \right) \text{ [ms]}$$

B : Total number of link relay (B) points used by all stations *2
 W : Total number of link register (W) points used by all stations *2
 X : Total number of link input (X) points used by all stations *2
 Y : Total number of link output (Y) points used by all stations *2
 SB : Number of link special relay (SB) points
 SW : Number of link special register (SW) points
 KM1, KM2 : Constants

	KM1*1	KM2
A2UCPU(S1) A2ASCPU(S1)	3.2	0.0023
A3U, A4UCPU	2.4	0.0023
A2USHCPU-SI	1.5	0.0023
Q02CPU-A	1.3	0.0023
Q02H, Q06HCPU-A	0.6	0.0023

*1 1 ms is added for each additional network module.

*2 This is the total, counting from the start device to the last device of those used.
 (Unused areas within this range are counted in the point total.)

[Refresh time for a remote I/O station (α_r)]

$$\alpha_r = \left(\frac{X + Y}{8} \right) \times 0.000375 \text{ [ms]}$$

X : Number of link input (X) points used in the host station
 Y : Number of link output (Y) points used in the host station

8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

MELSEC-A

8.2.4 Link scan time

(1) The link scan time in the master station is determined from the following two factors by using the formulae presented below:

- Number of allocated link device points
- Number of connected stations

[Link scan time for the master station (LS)]

$$LS = KB + (0.75 \times \text{total number of stations}) \times \left(\frac{B+X+Y+(W \times 16)}{8} \times 0.001 \right) \\ + KR + \left(\frac{Br+Xr+(Wr \times 16)}{8} \times 0.000375 \right) + (T \times 0.001) \quad [\text{ms}]$$

B : Total number of link relay (B) points used by all stations (master station + all remote I/O stations)*1
 W : Total number of link register (W) points used by all stations (master station + all remote I/O stations) *1
 X : Total number of link input (X) points used by all stations *1
 Y : Total number of link output (Y) points used by all stations *1
 Br : Total number of link relay (B) points used by each remote I/O station *2
 Wr : Total number of link register (W) points used by each remote I/O station *2
 Xr : Total number of link input (X) points used by each remote I/O station *2
 T : Maximum number of bytes sent by transient transmission in one link scan *3
 KB, KR : Constants

*1 M → R, M ← R settings

*2 M ← R settings

*3 If there are simultaneous transient transmissions from multiple stations, this is the total for all of them.

Number of Remote I/O Stations	1 to 8	9 to 16	17 to 24	25 to 32	33 to 40	41 to 48	49 to 56	57 to 64
KB	4.0	4.5	4.9	5.3	5.7	6.2	6.6	7.0
KR	3.9	3.1	2.6	2.3	1.7	1.1	0.6	0.0

8. LINK DATA SEND/RECEIVE PROCESSING & PROCESSING TIME

MELSEC-A

(2) Remote I/O stations

The link scan time for remote stations is determined from the following three factors by using the formulae presented below:

- Sequence program scan time in the master station
- Link refresh time
- Number of allocated link device points
- Number of stations connected

[Link scan time for remote stations (RS)]

[Sequence scan (Sm) < Link scan (LS)]

$$RS = LS + S_m + \alpha m \quad [\text{ms}]$$

[Sequence scan (Sm) > Link scan (LS)]

$$RS = S_m + \alpha m \quad [\text{ms}]$$

S_m : Sequence program scan time in the master station

αm : Link refresh time for the master station *1


LS : Link scan time

*1 This is the total for the number of network modules installed.

9. NETWORK SETTINGS

In order to operate a MELSECNET/10 network, the network settings (parameter settings) have to be set in the AnUCPU of the master station from a peripheral device.

There are the following types of parameter:



REMARK

For details on the operations for setting each type of parameter from a peripheral device, see the Operating Manual for the GPP function software package.

9.1 Data Link Parameters

These parameters are set in order to execute communications using the B/W and X/Y devices.

9.1.1 Number of modules settings

Information on the modules mounted to the AnUCPU is set in these settings.

The screenshot shows a screen titled "MODULES" with the following parameters and a table:

- (1) NO OF MODULES(1-4) [1]
- (2) MODULE NO. ACCESSED BY GPP [1]

	MODULE 1	MODULE 2	MODULE 3	MODULE 4
(3) I/O NO.	[03]	[]	[]	[]
(4) NETWORK MODULE TYPE	MELSECNET/10 RMT. MASTER			
(5) NETWORK NO.	[5]	[]	[]	[]

End: SET Err. CLOSE

Number of Modules Setting Screen

(1) NUMBER OF MODULES

[Purpose]

Set the number of network modules (MELSECNET/10) or data link modules (MELSECNET(II)) mounted to the AnUCPU here.

[Setting range]

1 to 4 (modules)

(2) MODULE NO. ACCESSED BY GPP

[Purpose]

Set the module number for a network whose station will be accessed from a peripheral device (SW4GP-GPPA, for example) or special function module (AJ71C24-S8, for example) that is not compatible with the AnUCPU here.

Note however, that if there is a MELSECNET (II) module, the MELSECNET (II) station will be accessed regardless of the effective module number setting.

[Setting range]

1 to 4 (module No.)

(3) I/O NO.**[Purpose]**

Set the head input number (upper two digits of three-digit hexadecimal number) for the mounted network modules (MELSECNET/10) or data link modules (MELSECNET (II)) here.

For example, if the I/O numbers are X/Y030 to 04F, set "03".

[Setting range]

A2ASCPU(S1) : 00 to 3F

A2UCPU(S1) : 00 to 3F

A3UCPU : 00 to 7F

A4UCPU : 00 to FF

(4) NETWORK MODULE TYPE**[Purpose]**

Set the type of network module (MELSECNET/10) or data link module (MELSECNET (II)) mounted here.

[Setting range]

1 : MELSECNET/10 (DEFAULT PARAMETER)

2 : MELSECNET/10 (CONTROL STATION)

3 : MELSECNET/10 (NORMAL STATION)

4 : MELSECNET/10 (REMOTE MASTER STATION)

5 : MELSECNET II (MASTER STATION)

6 : MELSECNET II (LOCAL STATION)

(5) NETWORK NO.**[Purpose]**

Set the network numbers of the network modules (MELSECNET/10) here.

Match this setting with the setting of the network No. setting switch of the network module.


[Setting range]

1 to 255

[Setting example]

Setting the parameters for the system configuration shown below.

<System configuration>




<Parameter setting screen>

<MODULES>				
NO OF MODULES(1-4)	[2]			
MODULE NO. ACCESSED BY GPP	[2]			
	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO.	[01]	[03]	[]	[]
NETWORK MODULE TYPE	MELSECNET/10 RMT. MASTER	MELSECNET/10 CONTROL STN.		
NETWORK NO.	[1]	[3]	[]	[]
End SET Esc CLOSE				

9.1.2 Network refresh parameters

These parameters set the relationship between the network module link devices (LB, LW, LX, LY) and data link condition storage devices (SB, SW), and the AnUCPU devices.



Network Refresh Parameter Setting Screen

(1) OHER MODULES

[Purpose]

Informs the user of the settings for each item at each module.

(2) MODULES

[Purpose]


The information set in "MODULES" is displayed here.

(3) L[] ↔ [] TRANSFER

[Purpose]

Set the correspondence between the network module link devices (LB, LW, LX, LY) and the AnUCPU link devices (B, W, X, Y) here.

[Setting range]




(4) SB COPIED TO, SW COPIED TO

[Purpose]

Set the correspondence between the network module data link condition storage devices (SB, SW) and the AnUCPU devices (X, Y, M, L, S, B, T, C, D, W) here.

[Setting range]



SB device data can be transferred to X/Y/M/L/S/B/F contacts, and T/C/D/W current values.

SW device data can be transferred to T/C/D/W current values.

(5) ERROR HISTORY

[Purpose]

Set the status of the transient transmission error history for SW00F0 to SW00FF here.

[Setting range]

RETAIN : The oldest information is stored.

OVERWRITE : The newest information is stored.

POINTS

(1) Relationship with "network refresh parameters" and "common parameters"
 In the AnUCPU, only the range where the network refresh parameters and common parameters overlap each other is refreshed.

(a) The range set with the common parameters is refreshed.

(b) The vacant area is also refreshed.

(2) When setting network parameters, make sure there is no overlap with the allocations for the following:

- Actual I/O (the number of I/O points allocated to actually installed modules)
- MELSECNET
- MELSECNET/MINI automatic refresh settings
- MELSECNET/10 (PC-to-PC network)

(3) Default values
 Default values are automatically set for the network refresh parameters when the number of modules settings are set (see table 10.1). Depending on the circumstances, it may be necessary to change these default settings.

- Note that LX/LY are not set in the default values.
 (However, in the case of MELSECNET (II), LX/LY0000 to 07FF X/Y0000 to 07FF are set.)
- When a MELSECNET (II) module is mounted, its setting is "module No.1" regardless of the module No. set in the number of modules settings.
- If two MELSECNET (II) modules are mounted they are treated as one module.
- MELSECNET (II) data link information is stored in M/D9200 to 9255 of the AnUCPU.


Table 10.1 Default Values for Network Refresh Parameters

Module Number Mounted	Module No.1	Module No.2	Module No.3	Module No.4
1	LB/LW0 to 1FFF → B/W0 to 1FFF SB0 to FF → Y1C00 to 1CFF SW0 to FF → D7168 to 7423	_____	_____	_____
2	LB/LW0 to FFF → B/W0 to FFF SB0 to FF → Y1C00 to 1CFF SW0 to FF → D7168 to 7423	LB/LW1000 to 1FFF → B/W1000 to 1FFF SB0 to FF → Y1D00 to 1DFF SW0 to FF → D7424 to 7679	_____	_____
3	LB/LW0 to 7FF → B/W0 to 7FF SB0 to FF → Y1C00 to 1CFF SW0 to FF → D7168 to 7423	LB/LW800 to FFF → B/W800 to FFF SB0 to FF → Y1D00 to 1DFF SW0 to FF → D7424 to 7679	LB/LW1000 to 17FF → B/W1000 to 17FF SB0 to FF → Y1E00 to 1EFF SW0 to FF → D7680 to 7935	_____
4	LB/LW0 to 7FF → B/W0 to 7FF SB0 to FF → Y1C00 to 1CFF SW0 to FF → D7168 to 7423	LB/LW800 to FFF → B/W800 to FFF SB0 to FF → Y1D00 to 1DFF SW0 to FF → D7424 to 7679	LB/LW1000 to 17FF → B/W1000 to 17FF SB0 to FF → Y1E00 to 1EFF SW0 to FF → D7680 to 7935	LB/LW800 to 1FFF → B/W1800 to 1FFF SB0 to FF → Y1F00 to 1FFF SW0 to FF → D7936 to 8191

[Setting example]

Setting the parameters for the refresh ranges indicated below. It is assumed that one network module is mounted.

<Refresh range>



<Parameter setting screen>


MELSECNET/10(RMT MAST)				I/O NO. 00	NETWORK NO. 1
LB↔B	LB	[0000]↔B	[0000]	SIZE[1000]HPOINTS	
LW↔W	LW	[0000]↔W	[0000]	SIZE[1000]HPOINTS	
LX↔X	LX	[0200]↔X	[0200]	SIZE[1200]HPOINTS	
LY↔Y	LY	[0200]↔Y	[0200]	SIZE[1200]HPOINTS	
SB COPIED TO	SB	[000]↔DEST. [B]	[1F00]	SIZE [100]HPOINTS	
SW COPIED TO	SW	[000]↔DEST. [W]	[1F00]	SIZE [100]HPOINTS	
ERROR HISTORY	RETAIN				

CHANGE MODULE WITH SHIII → F1, F2, F3, F4 KEYS. End . SET Esc . CLOSE

9.1.3 Common parameters

These parameters set conditions such as link device ranges for communication with the I/O modules/special function modules in each remote I/O station.

(1) LB/LW settings



Common Parameters Setting Screen

(a) REFRESH PARAMETER

[Purpose]

The network refresh parameter settings are displayed here.

(b) NUMBER OF STATIONS

[Purpose]

Set the number of remote I/O stations here.

[Setting range]

Optical loop system : 1 to 64

Coaxial bus system : 1 to 32

(c) LINK WDT

[Purpose]

Set the time within which it will be judged whether or not communication between the master station and a remote I/O station is normal here.

If the link scan time is longer than the W.D.T., communication is judged to be abnormal and communication is stopped.

[Setting range]

10 to 4000 ms (set in 10 ms units)


(d) M→R LB

[Purpose]

Set to define the area for the handshake data required to execute communications with the buffer memory of a special function module using ZNFR/ZNTO instructions.

Set the range of LB data sent from the "master station" to the "remote I/O station".

[Setting range]




(e) M←R LB

[Purpose]

Set to define the area for the handshake data required to execute communications with the buffer memory of a special function module using ZNFR/ZNTO instructions.


Set the range of LB data sent from the "remote I/O station" to the "master station".

[Setting range]



POINT

Set LB/LW device points so that the addresses will be consecutive in the M → R and M ← R areas respectively.




(f) M→R LW

[Purpose]

Set to define the area for the handshake data, and the area for storing the ZNTO instruction data, which are required to execute communication with the buffer memory of a special function module using ZNFR/ZNTO instructions.

Set the range of LW data sent from the "master station" to the "remote I/O station".

[Setting range]




(g) M←R LW

[Purpose]

Set to define the area for the handshake data, and the area for storing the ZNFR instruction data, which are required to execute communication with the buffer memory of a special function module using ZNFR/ZNTO instructions.

Set the range of LW data sent from the "remote I/O station" to the "master station".

[Setting range]



(h) RSERVED

[Purpose]

Displayed where reserve stations have been set.

(i) STATIONS (F1 key)

[Purpose]

Used to correct the setting for the number of remote I/O stations.

(j) RSERVE (F2 key)

[Purpose]

Used to set a station as a reserve station.

The station set is the one whose remote I/O station No. is selected with the cursor when the key is pressed.

Each time the F2 key is pressed, the station status switches between "RSV." and "not reserved" (no display).

(k) RESERVE (F4 key)

[Purpose]

Used to set reserve stations in a list.

Each time the Enter key is pressed the station status switches between "reserved" (highlighted display) and "not reserved" (normal display). The ■ display indicates that a station is reserved.

◀RESERVE STATION▶							
1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32
33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56
57	58	59	60	61	62	63	64
End : SET Esc : CLOSE							

(l) EXTEND (F5 key)

◀EXTENDED SET▶	
CONSTANT LINK SCAN	[1]ms (0-500) ← 1)
MAX. # OF RECONNECTION STN.	[2]STATION (1-16) ← 2)
DUPLEX COMMUNICATION	[0] 0:NO 1:YES ← 3)
ACCESSED ZNFR/ZNT0	[64] (1-64) ← 4)
End : SET Esc : CLOSE	

1) CONSTANT LINK SCAN

[Purpose]

Set in order to keep the link scan time constant.

[Setting range]

0 ms : Constant link scan function not executed.

1 to 500 ms : Constant link scan function executed in accordance with the set time.

2) MAX. NUMBER OF RECONNECTION STATIONS

[Purpose]

Set the number of faulty stations that can be returned to the data link in one scan here.

[Setting range]

1 to 16 stations (default value : 2 stations)

3) DUPLEX COMMUNICATION

[Purpose]

Set whether or not the multiplex transmission function is executed here.

This item cannot be set if the setting for the total number of link stations is 4 or greater.

[Setting range]

0 : Not executed 1 : Executed (default : not executed)

4) ACCESSED ZNFR/ZNTO

[Purpose]

Sets the number of ZNFR/ZNTO instructions that can be executed in 1 scan.

This setting is made to prevent the transmission delay time from being prolonged.

[Setting range]

1 to 64 (default : 64)

(m) X, Y (F9 key)

[Purpose]

Used to switch between setting screens.

(n) CLEAR (F10 key)

[Purpose]

Used to delete all the data that has been set.

CLEAR ALL COMMON PARAMETERS?


YES

NO

LB/LW setting method

This section describes the LB/LW setting method.

[Situation when there is one special function module]




- (1) The first 4 points (5) from the head of the ranges ((1) to (4)) set in the common parameters are automatically used for the handshake processing for ZNFR/ZNT0 instructions.
- (2) Set the M → R and M ← R ranges ((1) and (2), (3) and (4)) for LB/LW while ensuring that there is no overlap.
- (3) The ZNFR/ZNT0 instruction execution result is stored in the first point (6) for LW M ← R handshake processing use.
 Normal : 0
 Error : Error code (see Section 11.1)
- (4) The range (7) following the points for LW M ← R handshake processing use (5) is used to store the data read from the buffer memory using the ZNFR instruction.
- (5) The range (8) following the points for LW M → R handshake processing use (5) is used to store the data to be written to the buffer memory using the ZNT0 instruction.

POINT

When setting the LB/LW ranges, be sure to allocate a sufficient number of points (for handshake use) for the mounted special function modules. If the set number of points is insufficient, a "PRM.E." error will occur.

[Situation when there are two or more special function modules]



- (1) The "number of special function modules x 4 points" (5) from the head of the ranges ((1) to (4)) set in the common parameters are automatically used for the handshake processing for ZNFR/ZNTO instructions.
- (2) Set $M \rightarrow R$ and $M \leftarrow R$ ranges ((1) and (2), (3) and (4)) for LB/LW while ensuring that there is no overlap.
- (3) The ZNFR/ZNTO instruction execution result is stored in the first point (6) for LW $M \leftarrow R$ handshake processing use.
 Normal : 0
 Error : Error code (see Section 11.1)
- (4) The range (7) following the points for LW $M \leftarrow R$ handshake processing use (5) is used to store the data read from the buffer memory using the ZNFR instruction.
- (5) The range (8) following the points for LW $M \rightarrow R$ handshake processing use (5) is used to store the data to be written to the buffer memory using the ZNTO instruction.

POINT

When setting the LB/LW ranges, be sure to allocate a sufficient number of points (for handshake use) for the mounted special function modules. If the set number of points is insufficient, a "PRM.E." error will occur.

(2) LX/LY settings

COMMON PARAM. (MELSECNET10) REMOTE I/O		PARAM. NAME							
MODULE NO.		REFRESH PARAMETER		Size					
1		LX↔X(1)	0000-1FFF	8192					
		LX↔X(2)	-						
		LY↔Y(1)	0000-1FFF	8192					
		LY↔Y(2)	-						
NO. OF STN.	LINK WDT • 10 ms	REMOTE I/O STN. NO.	M→R		M←R				
3	200		LY	LY	LX				
		RSV. 1	1000-103F	0000-003F	1040-104F	0040-004F			
		2	1200-122F	0000-002F	1230-126F	0030-006F			
		3	-	-	-	-			
			-	-	-	-			
			-	-	-	-			
			-	-	-	-			
Page Up/Page Down MODULE CHANGE 99H ← F1, F2, F3, F4 End CHECK & SET Esc CLOSE									
1 STN	2 RSV	3	4 RESERV	5 EXTEND	6	7 EQUAL	8 POINTS	9 B.W	0 CLEAR


Common Parameter Setting Screen

(a) M→R LY

[Purpose]

Set the LY range for the master station and remote I/O stations.

[Setting range]




(b) M←R LX

[Purpose]

Set the LX ranges for the master station and remote I/O stations.

[Setting range]




(c) B,W (F9 key)

[Purpose]

Used to switch between setting screens.

LX/LY setting method

Make the master station settings while the modules are installed at the remote I/O stations.




[Precautions on setting]

- (1) Make sure that either the inputs (LX) or outputs (LY) at the remote I/O station side start from "0".

[Simple setting]


If the settings are made in the same size of I/O range as already used, the likelihood of setting errors is reduced. However, note that this increases the number of link points used.



[Setting example]


Setting the parameters for the system configuration and allocations shown below.

<System configuration>



* The special function module must be one that occupies 32 points.

<Allocations>



<Parameter setting screen>

COMMON PARAM. (MELSECNET10) REMOTE I/O		PARAM. NAME				
MODULE NO.		REFRESH PARAMETER		Size		
1		LX↔X(1) 0000-1FFF		8192		
		LX↔X(2) -		-		
		LY↔Y(1) 0000-1FFF		8192		
		LY↔Y(2) -		-		
NO. OF STN.	LINK WDT • 10 ms	REMOTE I/O STN. NO.	M→R		M←R	
			LY	LY	LX	LX
2	200	1	1020-105F	0020-005F	1000-105F	0000-005F
		2	1110-113F	0010-003F	1100-112F	0000-002F
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-

Page Up/Page Down : MODULE CHANGE Shift + F1, F2, F3, F4 End : CHECK & SET Esc : CLOSE

COMMON PARAM. (MELSECNET10) REMOTE I/O		PARAM. NAME				
MODULE NO.		REFRESH PARAMETER		Size		
1		LB↔B(1) 0000-1FFF		8192		
		LB↔B(2) -		-		
		LW↔W(1) 0000-1FFF		8192		
		LW↔W(2) -		-		
NO. OF STN.	LINK WDT • 10 ms	REMOTE I/O STN. NO.	M→R	M←R	M→R	M←R
			LB	LB	LW	LW
2	300	1	0000-000F	0020-002F	0000-001F	0040-005F
		2	0010-001F	0030-003F	0020-003F	0060-007F
			-	-	-	-
			-	-	-	-
			-	-	-	-
			-	-	-	-

Page Up/Page Down : MODULE CHANGE Shift + F1, F2, F3, F4 End : CHECK & SET Esc : CLOSE

9. NETWORK SETTINGS

MELSEC-A

9.1.4 I/O allocations

If there are one or more vacant slots, make reserve settings in the module information in advance so that the I/O numbers will not be shifted if other modules are mounted later, and to save I/O points.

Also, set the I/O allocations for each remote I/O station individually; it is not necessary to set them for all stations.

-REMOTE I/O ALLOCATION-

NETWORK
 #1 REMOTE MASTER NETWORK # 1
 I/O NO. 00 # OF ALL STN. 3

STN. NO.	1	2	3	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.	4	2	5														
STN. NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
STN. NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

End CHECK & SET Esc CLOSE

1
2
3
4
5
6
7
8
9
0 CLEAR

Remote I/O Allocation (slot No. setting) Screen

Press the [End] key!

-REMOTE I/O ALLOCATION-

COMMON PARAMETER LX 1000-111F LY 1000-111F NETWORK MODULE NO. 1

	1ST		2		3												
SLOT NO.	0	1	2	3	0	1	0	1	2	3	4						
I/O MODULE	X16	S32	Y32	F32	Y16	Y16	F32	F32	X32	X32	Y16						
SLOT NO.																	
I/O MODULE																	
SLOT NO.																	
I/O MODULE																	

VAGANCY (S) 1: OPT. X 6: 16PT. Y A: 16PT. S-MODULE E: 16PT.
 2: 16PT. (X) 7: 32PT. (Y) B: 32PT. (F) F: 32PT.
 3: 32PT. 8: 48PT. C: 48PT. G: 48PT.
 4: 48PT. 9: 64PT. D: 64PT. H: 64PT.
 5: 64PT.

Page Up / Page Down End CHECK & SET Esc CLOSE

1
2
3
4
5
6
7
8
9
0 CLEAR

Remote I/O Allocation Screen

(1) NETWORK

[Purpose]

The information for the station for which I/O allocations are to be made is displayed here.

(2) STATION NO.

[Purpose]

A number of numbers corresponding to the "total number of link stations" set in the common parameters are displayed here.

(3) SLOT NO.

[Purpose]

Set the number of slots occupied by the modules for which I/O points are to be allocated here.

[Setting range]

0 to 64

(set "0" for the stations for which no I/O allocations are to be made)

(4) CLEAR (F10 key)

[Purpose]

Used to delete the data set on the displayed screen.

SET PARAMETER TO DEFAULT VALUES?
YES <input type="checkbox"/> NO <input checked="" type="checkbox"/>

(5) COMMON PARAMETER

[Purpose]

The remote I/O station LX/LY statuses set in the common parameters are displayed here.

(6) SLOT NO.

[Purpose]

Slot numbers corresponding to the set number of points are displayed here.

(7) I/O MODULE

[Purpose]

Set the module information for each slot here.
Select the settings from the list provided (1 to 9, A to H).

[Setting example]

Setting the parameters for the remote I/O station configuration shown below.

<System configuration>

[Main base unit]

		0	1	2	3	4	5	6	7
A61P	AJ72LP25	Input 16 points	Input 16 points	Input 32 points	Output 16 points	Output 32 points	Special 32 points	Input 16 points	Input 16 points

[Extension base unit 1]

		8	9	10	11	12	13	14	15
A61P	Output 16 points	Output 16 points	Vacant	Input 16 points	Input 16 points				

Set for modules assuming
occupation of 8 slots

[Extension base unit 2]

		16	17	18	19	20
A61P	Input 32 points	Input 32 points	Output 16 points	Output 16 points	Output 16 points	

* Set "vacant, 0 points" for the vacant slots (10, 13 to 15).

9. NETWORK SETTINGS

MELSEC-A

<Parameter setting screen>

<REMOTE I/O ALLOCATION>

NETWORK

#1 REMOTE MASTER NETWORK # 1
I/O NO. 00 # OF ALL STN. 1

STN. NO.	1	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.	21															
STN. NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.																
STN. NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.																
STN. NO.	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--
SLOT NO.																

End CHECK & SET Esc. CLOSE

<REMOTE I/O ALLOCATION>

COMMON PARAMETER LX - LY - NETWORK MODULE NO. 1

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
SLOT NO.	X16	X16	X32	Y16	Y32	F32	X16	X16	Y16	Y16	S0	X16	X32	S0	S0	S0
I/O MODULE																
SLOT NO.	16	17	18	19	20											
I/O MODULE	X32	X32	Y16	Y16	Y16											
SLOT NO.																
I/O MODULE																
SLOT NO.																
I/O MODULE																


VACANCY (S) 1: 0PT. X 6: 16PT. Y A: 16PT. S-MOLULE E: 16PT.
2: 16PT. (X) 7: 32PT. (Y) B: 32PT. (F) F: 32PT.
3: 32PT. 8: 48PT. C: 48PT. G: 48PT.
4: 48PT. 9: 64PT. D: 64PT. H: 64PT.
5: 64PT.

Page Up / Page Down End CHECK & SET Esc. CLOSE

1 2 3 4 5 6 7 8 9 0 CLEAR

9.2 Routing Parameters

These parameters are set to enable transient transmission to stations in other networks.



Routing Parameter Setting Screen

(1) DESTINATION NETWORK NO.

[Purpose]

Set the network No. of the network where the request destination station is located.

Up to 64 settings can be made.

(2) RELAY NETWORK NO.

[Purpose]

Set the network No. of the first network on the route leading to the network in which the request destination station is located. (Network No. of the network to which the host station is connected).

(3) RELAY STATION NO.

[Purpose]

Set the station No. of the relevant station in the first network on the route leading to the network in which the request destination is located.

(4) L DEL (F9 key)

[Purpose]

Used to delete the setting on the line where the cursor is located.

(5) CLEAR (F10 key)

[Purpose]


Used to delete all the set routing parameters.

CLEAR ALL ROUTING PARAMETERS?

[Setting example]

Setting the parameters for the system configuration shown below.

<System configuration>



<Parameter setting screen>

(a) Setting for 1Ns2/2Ns2

<ROUTING PARAMETER>			
NO	DEST. N/W NO.	RELAY N/W NO.	RELAY STN. NO.
1	3	2	3
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			

Page Up / Page Down
End : SET Esc : CLOSE


(b) Setting for 2Ns3/3MR

ROUTING PARAMETER			
NO	DEST. N/W NO.	RELAY N/W NO.	RELAY STN.NO.
1	1	2	2
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			
13			
14			
15			

Page Up / Page Down End SET Esc. CLOSE

9.3 Precautions when the System Includes Networks Other than Remote I/O Networks

If multiple network modules (MELSECNET/10), data link modules (MELSECNET (II)), MELSEC/MINI master modules, etc., are mounted to one AnUCPU, care is required to ensure that the parameter setting ranges do not overlap each other or the actual I/O range.



Related items:

- Actual I/O
- MELSECNET local stations
- MELSECNET remote stations
- MELSECNET/MINI automatic refresh
- MELSECNET/10 PC-to-PC network
- MELSECNET/10 remote I/O network

10. PROGRAMMING

This section describes the master station program and special relays/registers required to operate the data link.

10.1 Precautions Relating to Programming

When operating a data link with remote I/O stations, observe the following points.

- (1) Create a program in which interlocks are established according to the condition of the data link between the remote I/O stations and the host station (master station).

In this case, the refresh parameters have been set as shown below.

<NETWORK REFRESH PARAMETER>


<div style="background-color: #333; color: white; padding: 2px; margin-bottom: 5px;">OTHER MODULES</div> <p>SW COPIED TO 1:D7168-D7423</p> <table border="1" style="width: 100%; border-collapse: collapse; margin-bottom: 5px;"> <tr> <td style="width: 20px; text-align: center;">1</td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> <td style="width: 20px;"></td> </tr> </table> <p>[PAGE 1] NETWORK MODULE 1</p>	1				<div style="background-color: #ccc; padding: 2px; margin-bottom: 5px;"><SW TRANS.DEV></div> <p>SPECIFY SOURCE SW, DESTINATION DEVICE, IT'S NO. AND TRANSFER SIZE.</p> <p>AVAILABLE DEVICES T,C,D,W</p>
1					

MELSECNET/10(RMT MAST)	START I/O NO. 00	NETWORK NO. 1
LB↔B	LB [0000]↔B [0000]	SIZE[2000]HPOINTS
LW↔W	LW [0000]↔W [0000]	SIZE[2000]HPOINTS
LX↔X	LX [0000]↔X [0000]	SIZE[2000]HPOINTS
LY↔Y	LY [0000]↔Y [0000]	SIZE[2000]HPOINTS
SB COPIED TO	SB [000]↔DEST. [M] [6000]	SIZE [100]HPOINTS
SW COPIED TO	SW [000]↔DEST. [D] [7000]	SIZE [100]HPOINTS
ERROR HISTORY	RETAIN	

CHANGE MODULE WITH Shift + F1, F2, F3, F4 KEYS. End : SET, Esc, CLOSE

With the above refresh parameter setting, the following interlock signals can be used in the program.


- (1) M6073 SB0049 (Master station cyclic transmission status)
- (2) D7116 SW0074 (Cyclic transmission status for each remote I/O station)
- (3) M9036 Always ON



(2) If two or more ZNFR/ZNTO instructions are executed with respect to the same special function module in a remote I/O station, write the program so that a mutual interlock is established between the two (so that an instruction can only be executed when execution of the other instruction has been completed).


(a) Example of alternate execution of ZNFR and ZNTO instructions

[(1) Executed when ON (normally) (2) Executed at start-up]



(b) Example of sequential execution of ZNFR and ZNTO instructions

[(1) Executed when ON (normally) (2) Executed when ON (normally)]



- (3) If initial settings have been made in the program for the buffer memory of a special function module on a remote I/O station, design the program by which, when only the remote I/O station is reset (when power is switched OFF or the reset switch of the network module on the remote I/O station is turned ON), the reset status will be detected at the master station and initial settings will be made to the special function module again.


Initial setting are made to a special function module when:

- (a) Sampling cycle or request for setting data set is set on the A/D converter, A616AD.
- (b) The number of channels or average processing specification is set on the AD converter, A68AD.

Whether the remote I/O station has been reset or not can be checked using the baton passing status at each station (SW0070 to SW0073) of the link special registers.

SW0070 to SW00d73 are assigned to D7112 to 7119 in the network refresh parameters. When using devices of the baton passing status at each station and cyclic transmission status at each station in a program, develop them in the bit devices M, L, etc. using the MOV instruction.

Program example for making initial settings to the special function module at remote I/O station No. 1.




10.2 Reading/Writing Data from/to Special Function Module's Buffer Memory

This section describes the instructions (ZNFR/ZNTO) used to read and write the data in the buffer memories of special function modules at remote I/O stations.

10.2.1 Reading data from buffer memory (ZNFR instruction)

The ZNFR instruction can be used in a MELSECNET/10 network system (remote I/O network) only. It is not available for a PLC-to PLC network.

[Instruction format]



Item	Details	Setting Range		
n1	Network No.	1 to 255		
n2	Station No. and position (1st, 2nd, 3rd, etc.) of the special function module	—		
	<table border="1" style="margin-left: 40px;"> <tr> <td style="text-align: center;">H</td> <td style="text-align: center;">L</td> </tr> <tr> <td style="text-align: center;">Station No.</td> <td style="text-align: center;">Position</td> </tr> </table>		H	L
H	L			
Station No.	Position			
n3	Buffer memory head address	—		
D1	Head No. of the link registers (W) used to store read data	—		
n4	Number of words of data to be read	1 to 256		
D2	Bit device No. switched ON on completion of execution	Y, M, L, S, B* ¹		

*1: The range not used by the network can be set for B.

For n1, n2, n3 and n4, specify a prefix "K[][]" for decimal setting or "H[][]" for hexadecimal setting.


(Example) Decimal: K10, hexadecimal: HA

[Program example 1]

When X20 is ON, the data addressed 10 to 14 in the buffer memory of the special function module (A68AD) placed in the 1st position of 1R2 are read out to W0014 to W0018.

It is assumed that one special function module only is placed at 1R2.

(1) System configuration



(2) Common parameters

Remote I/O Station No.	M→R	M←R	M→R	M←R
	LB	LB	LW	LW
1	—	—	—	—
2	0000 to 000F	0010 to 001F	0000 to 000F	0010 to 001F
3	—	—	—	—


(3) Handshake device range for the ZNFR instruction used by the system

LB		LW	
M→R2	M←R2	M→R2	M←R2
0000 to 0003	0010 to 0013	0000 to 0003	0010 to 0013

(4) Device range available for the ZNFR instruction

LB		LW	
M→R2	M←R2	M→R2	M←R2
Unusable	Unusable	Unusable	0014 to 001F

(5) Program




[Program example 2]

When X20 is ON, the data addressed 10 to 14 in the buffer memory of the special function module (A68AD) placed in the 1st position of 1R2 are read out to W0028 to W002C. Also, when X21 is ON, the data addressed 15 to 17 in the buffer memory of the special function module (A68AD) placed in the 2nd position of 1R2 are read out to W002D to W002F.

In this case, it is assumed that only 2 special function modules are placed at 1R2.

(1) System configuration



(2) Common parameters

Remote I/O Station No.	M→R	M←R	M→R	M←R
	LB	LB	LW	LW
1	—	—	—	—
2	0000 to 001F	0020 to 003F	0000 to 001F	0020 to 003F
3	—	—	—	—

(3) Handshake device range for the ZNFR instruction used by the system

LB		LW	
M→R2	M←R2	M→R2	M←R2
0000 to 0007	0020 to 0027	0000 to 0007	0020 to 0027


*For the handshake devices used by the system, the number of points calculated by the following expression is required, starting from the head device number of the device set in the common parameter.

Number of handshake device points =
 4 points × number of special function modules mounted on remote I/O station

(4) Device range available for the ZNFR instruction

LB		LW	
M→R2	M←R2	M→R2	M←R2
Not available	Not available	Not available	0028 to 003F


(5) Program



10.2.2 Writing data to buffer memory (ZNT0 instruction)

The ZNT0 instruction can be used in the MELSECNET/10 network system (remote I/O network) only. It is not available for the PLC-to-PLC network.

[Instruction format]



Item	Details	Setting Range		
n1	Network No.	1 to 255		
n2	Station No. and position (1st, 2nd, 3rd, etc.) of the special function module	—		
	<table border="1" style="margin-left: 40px;"> <tr> <td style="text-align: center;">H</td> <td style="text-align: center;">L</td> </tr> <tr> <td style="text-align: center;">Station No.</td> <td style="text-align: center;">Position</td> </tr> </table>		H	L
H	L			
Station No.	Position			
n3	Buffer memory head address	—		
D1	Head No. of the link registers (W) used to store data to be written	—		
n4	Number of words of data to be written	1 to 256		
D2	Bit device No. switched ON for 1 scan on completion of execution	Y, M, L, S, B* ¹		


*1: The range not used by the network can be set for B.

[Program example]

When X20 is ON, the data of W012C to W012F are written to the buffer memory addresses 0 to 3 of the special function module mounted in the 2nd place of the 2R4.

In this case, it is assumed that 3 special function modules are placed at 2R4.

(1) System configuration



(2) Common parameters

Remote I/O Station No.	M→R	M←R	M→R	M←R
	LB	LB	LW	LW
1	—	—	—	—
2	—	—	—	—
3	—	—	—	—
4	0100 to 010F	0110 to 011F	0100 to 011F	0120 to 013F

(3) Handshake device range for the ZNTO instruction used by the system

LB		LW	
M→R2	M←R2	M→R2	M←R2
0100 to 010B	0110 to 0113	0100 to 010B	0120 to 012B


*For the handshake devices used by the system, the number of points calculated by the following expression is required, starting from the head device number of the device set in the "Common Parameters".

Number of handshake device points = 4 points × number of special function modules mounted on remote I/O station

(4) Device range available for the ZNTO instruction

LB		LW	
M→R2	M←R2	M→R2	M←R2
Not available	Not available	010C to 010F	Not available

(5) Program



10.3 Special Link Relays (SB)/Registers (SW)

In a network module, the data link conditions are stored in special relays (SB) and special registers (SW).

SB/SW devices are used by the "network monitor" function of peripheral devices. Refer to Section 5 for details on the device numbers used for the individual items in the monitor screen.

At the master station, the SB/SW data is transferred to the AnUCPU in accordance with the network refresh parameters and it can therefore be used in sequence programs.

At a remote I/O station, SB/SW0000 to 00FF are transferred to M/D0 to 255.

10.3.1 Special link relays (SB)

Data link relays are switched ON and OFF in accordance with a variety of factors during data link operation. Table 10.1 lists the special link relays. The figures in parentheses in the "Number" column are in decimal notation.

Table 10.1 List of Special Link Relays

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SB0000 (0)	Link start (host station) *1	Restarts cyclic transmission at the host station. OFF: Start not designated ON: Start designated (at leading edge) *2	○	○	○	○
SB0001 (1)	Link stop (host station) *1	Stops cyclic transmission at the host station. OFF: Stop not designated ON: Stop designated (at leading edge) *2	○	○	○	○
SB0002 (2)	System link start *1	Restarts cyclic transmission in accordance with the contents of SW0000 to SW0004. OFF: Stop not designated ON: Stop designated (at leading edge) *2	○	○	○	○
SB0003 (3)	System link stop *1	Stops cyclic transmission in accordance with the contents of SW0000 to SW0004. OFF: Stop not designated ON: Stop designated (at leading edge) *2	○	○	○	○
SB0005 (5)	Retry frequency clear	Clears the retry frequency (SW00C8, SW00C9) to zero. OFF: Clearance not designated ON: Clearance designated (effective while ON)	○	○	○	○
SB0006 (6)	Communi- cation error count clear	Clears the communication error count (SW00B8 to SW00C7) to zero. OFF: Clearance not designated ON: Clearance designated (effective while ON)	○	○	○	○

*1 Used in the network test at peripheral devices.

*2 SB0000 to SB0003 become effective when a single point is switched ON.




Table 10.1 List of Special Link Relays (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SB0007 (7)	Forward loop transmission error clear	Clears the forward loop line error detection count (SW00CC). OFF : Clearance not designated ON : Clearance designated (effective while ON)	○	X	○	X
SB0008 (8)	Reverse loop transmission error clear	Clears the reverse loop line error detection count (SW00CD). OFF : Clearance not designated ON : Clearance designated (effective while ON)	○	X	○	X
SB0009 (9) *3	Loop switching count clear	Clears the loop switching count (SW00CE to E7) to zero. OFF : Clearance not designated ON : Clearance designated (effective while ON)	○	X	○	X
SB000A (10)	Transient transmission error clear	Clears transient transmission errors (SW00EE, SW00EF) to zero. OFF : Clearance not designated ON : Clearance designated (effective while ON)	○	○	○	○
SB000B (11)	Transient transmission error area setting	Specifies whether transient transmission errors (SB00F0 to FF) are overwritten or preserved. OFF : Overwrite ON : Hold	○	○	○	○
SB000D (13) *4	Fuse blown error clear/check	Clears the fuse blown error detected by the remote I/O station, or disables a check for a fuse blown error at the remote I/O station. OFF : Clear command disabled, error check enabled. ON : Clear command enabled, error check disabled. (Valid when ON)	○	○	X	X
SB000E (14) *4	I/O verify error clear/check	Clears the I/O verify error detected by the remote I/O station, or disables a check for an I/O verify error at the remote I/O station. OFF : Clear command disabled, error check enabled. ON : Clear command enabled, error check disabled. (Valid when ON)	○	○	X	X
SB0020 (32)	Module status	Indicates the status of the network module. OFF : Normal ON : Error	○	○	X	X
SB0040 (64)	Network type (host station)	Indicates the type of network set using the switches on the host station network module. OFF : PC to PC network ON : Remote I/O network	○	○	○	○
SB0043 (67)	Online switch (host station)	Indicates the mode set using the switches on the host station network module. OFF : Online (mode setting = 0 or 1) ON : Other than online (mode setting not 0 or 1)	○	○	○	○
SB0044 (68)	Station setting (host station)	Indicates the station type set using the switches on the host station network module. OFF : Normal station ON : Control station	○	○	○	○
SB0047 (71) *5	Baton passing status	Indicates the baton passing status of the host station. OFF : Normal ON : Error	○	○	○	○
SB0048 (72)	Control station status	Indicates the station that controls baton passing (transient transmission enabled status). Effective when SB0047 is OFF. OFF : Remote I/O station ON : Control station (SB0044 ON → master station SB0044 OFF → remote I/O station)	○	○	○	○

*3 SB0009 must remain ON until SW00CE becomes "0".

*4 Made valid when SB0049 is OFF (data link being executed).

*5 When SB0047 comes ON (error status) the data of SB004B to FF and SW004A to FF immediately before the error occurred is preserved. (Excludes SB0070, SB0074 and SW0070 to 77)

Table 10.1 List of Special Link Relays (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SB0049 (73)	Cyclic transmission status	Indicates the cyclic transmission status at the host station. OFF: Normal ON: Error (Set after refresh is completed)	○	○	○	○
SB004B (75)	Host station CPU status	Indicates the CPU status of the host station. OFF: Normal ON: Error	○	○	X	X
SB004C (76)	Cyclic transmission start reception status	Indicates the cyclic transmission start reception status. OFF: Start signal not received (SB0000 is OFF) ON: Start signal received (SB0000 is ON)	○	○	○	○
SB004D (77)	Cyclic transmission start completion status	Indicates the cyclic transmission start completion status. OFF: Not completed (SB0000 is OFF) ON: Start completed (SB0000 is ON)	○	○	○	○
SB004E (78)	Cyclic transmission stop reception status	Indicates the cyclic transmission stop reception status. OFF: Stop signal not received (SB0001 is OFF) ON: Stop signal received (SB0001 is OFF)	○	○	○	○
SB004F (79)	Cyclic transmission stop completion status	Indicates the cyclic transmission stop completion status. OFF: Stop not completed (SB0001 is OFF) ON: Stop completed (SB0001 is ON)	○	○	○	○
SB0050 (80)	Cyclic transmission start reception status	Indicates the cyclic transmission start reception status. OFF: Start signal not received (SB0002 is OFF) ON: Start signal received (SB0002 is ON)	○	○	○	○
SB0051 (81)	Cyclic transmission start completion status	Indicates the cyclic transmission start completion status. OFF: Not completed (SB0002 is OFF) ON: Start completed (SB0002 is ON)	○	○	○	○
SB0052 (82)	Cyclic transmission stop reception status	Indicates the cyclic transmission stop reception status. OFF: Stop signal not received (SB0003 is OFF) ON: Stop signal received (SB0003 is OFF)	○	○	○	○
SB0053 (83)	Cyclic transmission stop completion status	Indicates the cyclic transmission stop completion status. OFF: Stop not completed (SB0003 is OFF) ON: Stop completed (SB0003 is ON)	○	○	○	○
SB0054 (84)	Parameter reception status	Indicates the parameter reception status. OFF: Reception completed ON: Not received	○	○	○	○
SB0055 (85)	Received parameter error	Indicates the status of the received parameter. OFF: Parameter normal ON: Parameter error	○	○	○	○
SB0056 (86)	Communication data	Indicates the transient transmission status. OFF: Transient transmission by the control station ON: Transient transmission by a sub-control station	○	○	○	○
SB0058 (88)	Sub-control station link	Indicates the cyclic transmission status when the control station is down. OFF: Cyclic transmission at the sub-control station ON: No cyclic transmission at the sub-control station	○	○	○	○

Table 10.1 List of Special Link Relays (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SB0064 (100)	Reserve station setting	Indicates whether a reserve station has been set. (Effective when SB0049 is OFF) OFF: No reserve station set ON: Reserve station(s) set OFF when SW0064 to 67 are all "0".	○	○	○	○
SB0068 (104)	Communication mode	Indicates the link scan mode (status set in the common parameter extension setting). (Effective when SB0049 is OFF) OFF: Normal mode ON: Constant scan mode	○	○	○	○
SB0069 (105)	Transmission setting	Indicates the transmission specification in the common parameter extension settings. (Effective when SB0049 is OFF) OFF: Normal transmission specified ON: Multiplex transmission specified	○	X	○	X
SB006A (106)	Transmission condition	Indicates the transmission condition. OFF: Normal transmission in progress ON: Multiplex transmission in progress	○	X	○	X
SB0070 (112)	Baton passing status at each station	Indicates the baton passing status at each station. (Reserve stations and stations with the highest and higher station numbers are not applicable.) OFF: All stations normal ON: Error at one or more stations OFF when SW0070 to 73 are all "0".	○	○	○	○
SB0071 (113)	Master station transient transmission status	Indicates the transient transmission enabled status at the master station. OFF : Normal ON : Error	X	X	○	○
SB0074 (116)	Cyclic transmission status at each station	Indicates the cyclic transmission status at each station. (Reserve stations and stations with the highest and higher station numbers are not applicable.) OFF: Data link executed at all stations ON: Data link not executed at one or more stations OFF when SW0074 to 77 are all "0".	○	○	○	○
SB0075 (117)	Master station cyclic transmission status	Indicates the cyclic transmission status at the master station. OFF : Normal ON : Error	X	X	○	○
SB0078 (120)	Parameter communication status at each station	Indicates the parameter communication status at each station. (Reserve stations and stations with the highest and higher station numbers are not applicable.) OFF: Parameter communication not in progress ON: Parameter communication in progress OFF when SW0078 to 7B are all "0".	○	○	X	X
SB007C (124)	Parameter status at each station	Indicates the parameter status at each station. OFF: Parameter error at one or more stations ON: No parameter error at any station OFF when SW007C to 7F are all "0".	○	○	X	X
SB0080 (128)	CPU status at each station	Indicates the CPU status at each station. OFF: All stations normal ON: One or more faulty stations (including the host station) OFF when SW0080 to 83 are all "0".	○	○	○	○
SB0085 (133)	Master station CPU status	Indicates the master station CPU status. OFF: RUN, STEP RUN ON: STOP, PAUSE	X	X	○	○

Table 10.1 List of Special Link Relays (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SB0090 (144)	Host station loop status	Indicates the loop status of the host station. OFF: Normal ON: Error OFF when SW0090 is "0".	O	X	O	X
SB0091 (145)	Forward loop status	Indicates the status of stations connected in a forward loop. OFF: All stations normal ON: One or more faulty stations OFF when SW0091 to 94 are all OFF.	O	X	O	X
SB0092 (146)	Master station forward loop status	Indicates the forward loop status of the master station. OFF : Normal ON : Error	X	X	O	X
SB0095 (149)	Reverse loop status	Indicates the status of stations connected in a reverse loop. OFF: All stations normal ON: One or more faulty stations OFF when SW0095 to 98 are all OFF.	O	X	O	X
SB0096 (150)	Master station reverse loop status	Indicates the reverse loop status of the master station. OFF : Normal ON : Error	X	X	O	X
SB0099 (153)	Forward loop loopback	Indicates loopback statuses in the system's forward loop. OFF: Loopback not executed ON: Executed at one or more stations (data identifying the stations stored in SW0099)	O	X	O	X
SB009A (154)	Reverse loop loopback	Indicates loopback statuses in the system's reverse loop. OFF: Loopback not executed ON: Executed at one or more stations (data identifying the stations stored in SW009A)	O	X	O	X
SB00A8 (168)	Online test designation	Indicates whether or not an online test is designated. OFF: Not designated ON: Designated	O	O	O	O
SB00A9 (169)	Online test completion	Indicates whether or not an online test is completed. OFF: Not completed ON: Completed	O	O	O	O
SB00AA (170)	Online test response designation	Indicates the online test response status. OFF: No response received ON: Response received	O	O	O	O
SB00AB (171)	Online test completion status	Indicates the completion status of the online test. OFF: Completed without response ON: Completed with response	O	O	O	O
SB00AC (172)	Offline test designation	Indicates whether or not an offline test is designated. OFF: Not designated ON: Designated	O	O	O	O
SB00AD (173)	Offline test completion	Indicates whether or not an offline test is completed. OFF: Not completed ON: Completed	O	O	O	O
SB00EE (238)	Transient error	Indicates the error status for transient transmission. OFF: No error ON: Error	O	O	O	O

10.3.2 Special link registers (SW)

The special link registers are used to store data link information in numerical form.

The locations and causes of errors can be determined by monitoring these registers.

Table 10.2 lists the special link registers. The figures in parentheses in the "Number" column are in decimal notation.

Table 10.2 List of Special Link Registers

Number	Name	Function	Device Use Possible?																																																										
			Master Station		Remote I/O Station																																																								
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus																																																							
SW0000 (0)	Data link stop/start designation details *1	Sets the stations that stop and restart the data link. 00H: Host station 01H: All stations 02H: Designated station 41H: Group 1 to 49H: Group 9 80H: Host station (forced stop/restart) 81H: All stations (forced stop/restart) 82H: Designated station (forced stop/restart) C1H: Group 1 (forced stop/restart) to C9H: Group 9 (forced stop/restart)	○	○	○	○																																																							
SW0001 (1) • SW0002 (2) • SW0003 (3) • SW0004 (4)	Data link stop/start designation details *1	Set if "designated station" is specified (i.e., if 02H or 82H is set for SW0000). Set the bit that corresponds to the station that will stop/restart the data link to "1". 0: data link stop/restart instruction is invalid. 1: data link stop/restart instruction is valid. <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td>b15</td><td>b14</td><td>b13</td><td>b12</td> <td>to</td> <td>b4</td><td>b3</td><td>b2</td><td>b1</td><td>b0</td> </tr> <tr> <td>SW0001</td> <td>16</td><td>15</td><td>14</td><td>13</td> <td>to</td> <td>5</td><td>4</td><td>3</td><td>2</td><td>1</td> </tr> <tr> <td>SW0002</td> <td>32</td><td>31</td><td>30</td><td>29</td> <td>to</td> <td>21</td><td>20</td><td>19</td><td>18</td><td>17</td> </tr> <tr> <td>SW0003</td> <td>48</td><td>47</td><td>46</td><td>45</td> <td>to</td> <td>37</td><td>36</td><td>35</td><td>34</td><td>33</td> </tr> <tr> <td>SW0004</td> <td>64</td><td>63</td><td>62</td><td>61</td> <td>to</td> <td>53</td><td>52</td><td>51</td><td>50</td><td>49</td> </tr> </table> The figures 1 to 64 in the table are station numbers.		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0001	16	15	14	13	to	5	4	3	2	1	SW0002	32	31	30	29	to	21	20	19	18	17	SW0003	48	47	46	45	to	37	36	35	34	33	SW0004	64	63	62	61	to	53	52	51	50	49	○	○	○	○
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0001	16	15	14	13	to	5	4	3	2	1																																																			
SW0002	32	31	30	29	to	21	20	19	18	17																																																			
SW0003	48	47	46	45	to	37	36	35	34	33																																																			
SW0004	64	63	62	61	to	53	52	51	50	49																																																			
SW0020 (32)	Module status	Stores the status of the network module. 0: Normal More than 1: Error (See Section 11.1)	○	○	X	X																																																							
SW0040 (64)	Network No.	Stores the network number of the host station. Range: 1 to 255	○	○	○	○																																																							
SW0042 (66)	Station No.	Stores the station number of the host station. Range: 1 to 64 (Master station: 7DH)	○	○	○	○																																																							
SW0043 (67)	Online switch	Stores the mode switch status of the host station. Range: 0H to FH	○	○	○	○																																																							
SW0044 (68)	Station setting	Stores the statuses of the condition setting switches of the host station. 0: OFF 1: ON <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td></td> <td>b15</td><td>to</td><td>b8</td><td>b7</td><td>b6</td><td>b5</td><td>b4</td><td>b3</td><td>b2</td><td>b1</td><td>b0</td> </tr> <tr> <td>SW0044</td> <td>0</td><td>to</td><td>0</td><td>8</td><td>7</td><td>6</td><td>5</td><td>4</td><td>3</td><td>2</td><td>1</td> </tr> </table> Numbers 1 to 8 in the table are the switch numbers.		b15	to	b8	b7	b6	b5	b4	b3	b2	b1	b0	SW0044	0	to	0	8	7	6	5	4	3	2	1	○	○	○	○																															
	b15	to	b8	b7	b6	b5	b4	b3	b2	b1	b0																																																		
SW0044	0	to	0	8	7	6	5	4	3	2	1																																																		
SW0045 (69)	Setting error	Stores the host station switch settings. 0: Normal	○	○	○	○																																																							

*1 Used in the network test at peripheral devices.

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SW0046 (70)	Module classification	<p>Stores the type of network module at the host station.</p> <p>01 : Fiber-optic 10 : Coaxial cable 11 : Twisted pair 0 : Duplex 1 : Single 0 : Loop 1 : Bus</p>	○	○	○	○
SW0047 (71)	Baton passing status	<p>Stores the baton passing status of the host station.</p> <ul style="list-style-type: none"> 0 : Data link in progress 1 : Data link stopped (designation from another station) 2 : Data link stopped (designation from host station) 3 : Baton passing executed (parameter reception) 4 : Baton passing executed (parameter reception) 5 : Baton passing executed (parameters not received) 6 : Disconnection (no baton passing) 7 : Disconnection (line error) 11H: Loop test 12H: Setting confirmation test 13H: Station order confirmation test 14H: Communication test 1FH: Offline test FFH: Resetting in progress 	○	○	○	○
SW0048 (72)	Cause of data link transmission stoppage	<p>Stores information on the cause for a stop in baton passing (transient transmission enabled status).</p> <ul style="list-style-type: none"> 0: Normal communication 1: Offline 2: Offline test More than 3: Stop cause (See Section 11.1) 	○	○	○	○
SW0049 (73)	Cyclic transmission stop cause	<p>Stores the cause of a cyclic transmission stop at the host station</p> <ul style="list-style-type: none"> 0 : Normal 1 : Stop designation issued 2 : No common parameters 3 : Common parameter error 6 : Communication suspension 	○	○	○	○
SW004A (74)	Cyclic transmission stop request station	<p>Stores the station that stopped cyclic transmission at the host station. (Effective when SW0049 is "1")</p> <p>0 : Host station 1 to 64 : station No. 0 : Station No. specified 1 : "All stations" specified</p>	○	○	○	○
SW004B (75)	Host station CPU status	<p>Stores the CPU status of the host station</p> <ul style="list-style-type: none"> 0 : Normal 1 or more : Error (See Section 11.1) 	○	○	○	○

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?																																																										
			Master Station		Remote I/O Station																																																								
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus																																																							
SW004C (76)	Host station CPU error slot No.	Stores the slot No. where a host station error occurred. Only effective when SW004B is other than "0".	X	X	○	○																																																							
SW004D (77)	Data link start condition (host station)	Stores the result when data link operation has started. 0: Normal More than 1: Error (See Section 11.1)	○	○	○	○																																																							
SW004F (79)	Data link stop condition (host station)	Stores the result when data link operation has stopped. 0: Normal More than 1: Error (See Section 11.1)	○	○	○	○																																																							
SW0051 (81)	Data link start condition (system)	Stores the result when data link operation has started. 0: Normal More than 1: Error (See Section 11.1)	○	○	○	○																																																							
SW0053 (83)	Data link stop status (system)	Stores the result when data link operation has stopped. 0: Normal More than 1: Error (See Section 11.1)	○	○	○	○																																																							
SW0055 (85)	Parameters	Stores the parameter status. 0: Parameters normal More than 1: Parameter error (refer to the error codes)	○	○	○	○																																																							
SW0056 (86)	Current master station	Stores the station number of the station controlling baton passing 7DH : Master station No. Other than 7DH : Control station No.	○	○	○	○																																																							
SW0057 (87)	Designated master station	7DH : Master station No. 0 : Master station error	○	○	○	○																																																							
SW0059 (89)	Total number of link stations	Stores the highest station number set in the parameters. Range: 1 to 64 ("64" if no parameter setting)	○	○	○	○																																																							
SW005A (90)	Max. normal baton passing stations	Stores the highest station number in the number of stations that can execute baton passing normally. Range: 1 to 64	○	○	○	○																																																							
SW005B (91)	Max. cyclic transmission stations	Stores the highest station number in the maximum number of stations that can execute cyclic transmission. Range: 1 to 64	○	○	○	○																																																							
SW0064 (100) • SW0065 (101) • SW0066 (102) • SW0067 (103)	Reserve station specification	Stores information on the stations set as reserve stations. 0: Not reserve station 1: Reserve station Becomes effective when SB0049 is OFF. <table style="margin-left: 40px;"> <tr> <td></td> <td>b15</td><td>b14</td><td>b13</td><td>b12</td> <td>to</td> <td>b4</td><td>b3</td><td>b2</td><td>b1</td><td>b0</td> </tr> <tr> <td>SW0064</td> <td>16</td><td>15</td><td>14</td><td>13</td> <td>to</td> <td>5</td><td>4</td><td>3</td><td>2</td><td>1</td> </tr> <tr> <td>SW0065</td> <td>32</td><td>31</td><td>30</td><td>29</td> <td>to</td> <td>21</td><td>20</td><td>19</td><td>18</td><td>17</td> </tr> <tr> <td>SW0066</td> <td>48</td><td>47</td><td>46</td><td>45</td> <td>to</td> <td>37</td><td>36</td><td>35</td><td>34</td><td>33</td> </tr> <tr> <td>SW0067</td> <td>64</td><td>63</td><td>62</td><td>61</td> <td>to</td> <td>53</td><td>52</td><td>51</td><td>50</td><td>49</td> </tr> </table> The figures 1 to 64 in the table are station numbers.		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0064	16	15	14	13	to	5	4	3	2	1	SW0065	32	31	30	29	to	21	20	19	18	17	SW0066	48	47	46	45	to	37	36	35	34	33	SW0067	64	63	62	61	to	53	52	51	50	49	○	○	○	○
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0064	16	15	14	13	to	5	4	3	2	1																																																			
SW0065	32	31	30	29	to	21	20	19	18	17																																																			
SW0066	48	47	46	45	to	37	36	35	34	33																																																			
SW0067	64	63	62	61	to	53	52	51	50	49																																																			

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?																																																										
			Master Station		Remote I/O Station																																																								
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus																																																							
SW0068 (104)	Communication mode	Stores the constant link scan setting. 0: No setting stored 1 to 500: Set time (ms) Becomes effective when SB0049 is OFF.	○	○	○	○																																																							
SW006B (107)	Max. link scan time	Stores the maximum value, minimum value, and current value for the link scan time. (Units: ms) These values are different for the master station and remote I/O stations.	○	○	○	○																																																							
SW006C (108)	Min. link scan time	<p>Sequence scan: 0 END 0 END 0 END</p> <p>Link scan: [Pulse]</p> <p>Master station: [Interval]</p> <p>Remote I/O station: [Interval]</p>	○	○	○	○																																																							
SW006D (109)	Current link scan time		○	○	○	○																																																							
SW0070 (112) • SW0071 (113) • SW0072 (114) • SW0073 (115)	Baton passing status at each station	<p>Indicates the baton passing status at each station (including the host station).</p> <p><Online> 0: Normal (including stations with the "highest" and higher station numbers, and reserve stations) 1: Error</p> <p><Offline> 0: Normal 1: Error (including stations with the "highest" and higher station numbers, and reserve stations)</p> <table border="1"> <tr> <td></td> <td>b15</td><td>b14</td><td>b13</td><td>b12</td> <td>to</td> <td>b4</td><td>b3</td><td>b2</td><td>b1</td><td>b0</td> </tr> <tr> <td>SW0070</td> <td>16</td><td>15</td><td>14</td><td>13</td> <td>to</td> <td>5</td><td>4</td><td>3</td><td>2</td><td>1</td> </tr> <tr> <td>SW0071</td> <td>32</td><td>31</td><td>30</td><td>29</td> <td>to</td> <td>21</td><td>20</td><td>19</td><td>18</td><td>17</td> </tr> <tr> <td>SW0072</td> <td>48</td><td>47</td><td>46</td><td>45</td> <td>to</td> <td>37</td><td>36</td><td>35</td><td>34</td><td>33</td> </tr> <tr> <td>SW0073</td> <td>64</td><td>63</td><td>62</td><td>61</td> <td>to</td> <td>53</td><td>52</td><td>51</td><td>50</td><td>49</td> </tr> </table> <p>The figure 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0070	16	15	14	13	to	5	4	3	2	1	SW0071	32	31	30	29	to	21	20	19	18	17	SW0072	48	47	46	45	to	37	36	35	34	33	SW0073	64	63	62	61	to	53	52	51	50	49	○	○	○	○
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0070	16	15	14	13	to	5	4	3	2	1																																																			
SW0071	32	31	30	29	to	21	20	19	18	17																																																			
SW0072	48	47	46	45	to	37	36	35	34	33																																																			
SW0073	64	63	62	61	to	53	52	51	50	49																																																			
SW0074 (116) • SW0075 (117) • SW0076 (118) • SW0077 (119)	Cyclic transmission status at each station	<p>Stores the cyclic transmission status at each station (including the host station).</p> <p>0: Cyclic transmission in progress (including stations with the highest and higher station numbers, and reserve stations) 1: Cyclic transmission not executed</p> <table border="1"> <tr> <td></td> <td>b15</td><td>b14</td><td>b13</td><td>b12</td> <td>to</td> <td>b4</td><td>b3</td><td>b2</td><td>b1</td><td>b0</td> </tr> <tr> <td>SW0074</td> <td>16</td><td>15</td><td>14</td><td>13</td> <td>to</td> <td>5</td><td>4</td><td>3</td><td>2</td><td>1</td> </tr> <tr> <td>SW0075</td> <td>32</td><td>31</td><td>30</td><td>29</td> <td>to</td> <td>21</td><td>20</td><td>19</td><td>18</td><td>17</td> </tr> <tr> <td>SW0076</td> <td>48</td><td>47</td><td>46</td><td>45</td> <td>to</td> <td>37</td><td>36</td><td>35</td><td>34</td><td>33</td> </tr> <tr> <td>SW0077</td> <td>64</td><td>63</td><td>62</td><td>61</td> <td>to</td> <td>53</td><td>52</td><td>51</td><td>50</td><td>49</td> </tr> </table> <p>The figures 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0074	16	15	14	13	to	5	4	3	2	1	SW0075	32	31	30	29	to	21	20	19	18	17	SW0076	48	47	46	45	to	37	36	35	34	33	SW0077	64	63	62	61	to	53	52	51	50	49	○	○	○	○
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0074	16	15	14	13	to	5	4	3	2	1																																																			
SW0075	32	31	30	29	to	21	20	19	18	17																																																			
SW0076	48	47	46	45	to	37	36	35	34	33																																																			
SW0077	64	63	62	61	to	53	52	51	50	49																																																			

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?																																																										
			Master Station		Remote I/O Station																																																								
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus																																																							
SW0078 (120) • SW0079 (121) • SW007A (122) • SW007B (123)	Parameter communication status at each station	<p>Stores the parameter communication status at each station.</p> <p>0: Parameter communication not in progress (including stations with the "highest" and higher station numbers, and reserve stations)</p> <p>1: Parameter communication in progress</p> <table border="1"> <tr> <td></td> <td>b15</td> <td>b14</td> <td>b13</td> <td>b12</td> <td>to</td> <td>b4</td> <td>b3</td> <td>b2</td> <td>b1</td> <td>b0</td> </tr> <tr> <td>SW0078</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0079</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>21</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW007A</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>37</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW007B</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>53</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </table> <p>The figures 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0078	16	15	14	13	to	5	4	3	2	1	SW0079	32	31	30	29	to	21	20	19	18	17	SW007A	48	47	46	45	to	37	36	35	34	33	SW007B	64	63	62	61	to	53	52	51	50	49	O	O	X	X
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0078	16	15	14	13	to	5	4	3	2	1																																																			
SW0079	32	31	30	29	to	21	20	19	18	17																																																			
SW007A	48	47	46	45	to	37	36	35	34	33																																																			
SW007B	64	63	62	61	to	53	52	51	50	49																																																			
SW007C (124) • SW007D (125) • SW007E (126) • SW007F (127)	Parameter error status at each station	<p>Stores the parameter status at each station.</p> <p>0: Parameters normal (including stations with the "highest" and higher station numbers, and reserve stations)</p> <p>1: Parameter error</p> <table border="1"> <tr> <td></td> <td>b15</td> <td>b14</td> <td>b13</td> <td>b12</td> <td>to</td> <td>b4</td> <td>b3</td> <td>b2</td> <td>b1</td> <td>b0</td> </tr> <tr> <td>SW007C</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW007D</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>21</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW007E</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>37</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW007F</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>53</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </table> <p>The figures 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW007C	16	15	14	13	to	5	4	3	2	1	SW007D	32	31	30	29	to	21	20	19	18	17	SW007E	48	47	46	45	to	37	36	35	34	33	SW007F	64	63	62	61	to	53	52	51	50	49	O	O	X	X
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW007C	16	15	14	13	to	5	4	3	2	1																																																			
SW007D	32	31	30	29	to	21	20	19	18	17																																																			
SW007E	48	47	46	45	to	37	36	35	34	33																																																			
SW007F	64	63	62	61	to	53	52	51	50	49																																																			
SW0080 (128) • SW0081 (129) • SW0082 (130) • SW0083 (131)	Remote I/O station status	<p>Stores the statuses of the remote I/O stations (including the host station).</p> <p>0: Normal (including stations with the "highest" and higher station numbers, and reserve stations)</p> <p>1: Error</p> <table border="1"> <tr> <td></td> <td>b15</td> <td>b14</td> <td>b13</td> <td>b12</td> <td>to</td> <td>b4</td> <td>b3</td> <td>b2</td> <td>b1</td> <td>b0</td> </tr> <tr> <td>SW0080</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0081</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>21</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0082</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>37</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0083</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>53</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </table> <p>The figures 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0080	16	15	14	13	to	5	4	3	2	1	SW0081	32	31	30	29	to	21	20	19	18	17	SW0082	48	47	46	45	to	37	36	35	34	33	SW0083	64	63	62	61	to	53	52	51	50	49	O	O	O	O
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0080	16	15	14	13	to	5	4	3	2	1																																																			
SW0081	32	31	30	29	to	21	20	19	18	17																																																			
SW0082	48	47	46	45	to	37	36	35	34	33																																																			
SW0083	64	63	62	61	to	53	52	51	50	49																																																			
SW0090 (144)	Loopback information	<p>Stores information on the loop status at the host station.</p> <p>0: Loop normal</p> <p>1: Forward loop error</p> <p>2: Reverse loop error</p> <p>3: Loopback</p> <p>4: Data link disabled</p>	O	X	O	X																																																							

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?																																																										
			Master Station		Remote I/O Station																																																								
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus																																																							
SW0091 (145) • SW0092 (146) • SW0093 (147) • SW0094 (148)	Forward loop status at each station	<p>Stores the forward loop status at each station (including the host station). 0: Normal (including stations with the "highest" and higher station numbers, and reserve stations) 1: Error The status stored for disconnected stations is the status when the disconnection occurred.</p> <table border="1"> <tr> <td></td> <td>b15</td> <td>b14</td> <td>b13</td> <td>b12</td> <td>to</td> <td>b4</td> <td>b3</td> <td>b2</td> <td>b1</td> <td>b0</td> </tr> <tr> <td>SW0091</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0092</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>21</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0093</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>37</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0094</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>53</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </table> <p>The figures 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0091	16	15	14	13	to	5	4	3	2	1	SW0092	32	31	30	29	to	21	20	19	18	17	SW0093	48	47	46	45	to	37	36	35	34	33	SW0094	64	63	62	61	to	53	52	51	50	49	O	X	O	X
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0091	16	15	14	13	to	5	4	3	2	1																																																			
SW0092	32	31	30	29	to	21	20	19	18	17																																																			
SW0093	48	47	46	45	to	37	36	35	34	33																																																			
SW0094	64	63	62	61	to	53	52	51	50	49																																																			
SW0095 (149) • SW0096 (150) • SW0097 (151) • SW0098 (152)	Reverse loop status at each station	<p>Stores the reverse loop status at each station (including the host station). 0: Normal (including stations with the "highest" and higher station numbers, and reserve stations) 1: Error The status stored for disconnected stations is the status when the disconnection occurred.</p> <table border="1"> <tr> <td></td> <td>b15</td> <td>b14</td> <td>b13</td> <td>b12</td> <td>to</td> <td>b4</td> <td>b3</td> <td>b2</td> <td>b1</td> <td>b0</td> </tr> <tr> <td>SW0095</td> <td>16</td> <td>15</td> <td>14</td> <td>13</td> <td>to</td> <td>5</td> <td>4</td> <td>3</td> <td>2</td> <td>1</td> </tr> <tr> <td>SW0096</td> <td>32</td> <td>31</td> <td>30</td> <td>29</td> <td>to</td> <td>21</td> <td>20</td> <td>19</td> <td>18</td> <td>17</td> </tr> <tr> <td>SW0097</td> <td>48</td> <td>47</td> <td>46</td> <td>45</td> <td>to</td> <td>37</td> <td>36</td> <td>35</td> <td>34</td> <td>33</td> </tr> <tr> <td>SW0098</td> <td>64</td> <td>63</td> <td>62</td> <td>61</td> <td>to</td> <td>53</td> <td>52</td> <td>51</td> <td>50</td> <td>49</td> </tr> </table> <p>The figures 1 to 64 in the table are station numbers.</p>		b15	b14	b13	b12	to	b4	b3	b2	b1	b0	SW0095	16	15	14	13	to	5	4	3	2	1	SW0096	32	31	30	29	to	21	20	19	18	17	SW0097	48	47	46	45	to	37	36	35	34	33	SW0098	64	63	62	61	to	53	52	51	50	49	O	X	O	X
	b15	b14	b13	b12	to	b4	b3	b2	b1	b0																																																			
SW0095	16	15	14	13	to	5	4	3	2	1																																																			
SW0096	32	31	30	29	to	21	20	19	18	17																																																			
SW0097	48	47	46	45	to	37	36	35	34	33																																																			
SW0098	64	63	62	61	to	53	52	51	50	49																																																			
SW0099 (153)	Loopback stations (forward loop)	Stores the station numbers of stations at which loopback is executed in a forward loop. Range: 1 to 64 (master station : 7DH)	O	X	O	X																																																							
SW009A (154)	Loopback stations (reverse loop)	Stores the station numbers of stations at which loopback is executed in a reverse loop. Range: 1 to 64 (master station : 7DH)	O	X	O	X																																																							
SW00A8 (168)	Online test items / faulty stations (at requesting station)	<p>Stores information on the online test items at the requesting station and the station numbers of faulty stations. (Effective when SB00A9 is ON.)</p> <table border="1"> <tr> <td rowspan="2">SW00A8</td> <td>b15 to</td> <td>b8 b7 to</td> <td>b0</td> </tr> <tr> <td>to</td> <td>to</td> <td></td> </tr> </table> <p>Station numbers of faulty stations Test numbers 10H: Loop test 20H: Setting confirmation test 30H: Station order confirmation test 40H: Communication test</p> <p>No. of the station detected as faulty in the online test is stored. The station separated from the network before the test is excepted.</p>	SW00A8	b15 to	b8 b7 to	b0	to	to		O	O	O	O																																																
SW00A8	b15 to	b8 b7 to		b0																																																									
	to	to																																																											
SW00A9 (169)	Online test results (at requesting station)	Stores the online test results for the requesting station. (Effective when SB00A9 is ON.) 0: Test normal More than 1: Test error details	O	O	O	O																																																							

Table 10.2 List of Special Link Registers (Continued)


Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SW00AA (170)	Online test items (at responding stations)	<p>Stores information on the online tests executed at the responding stations. (Effective when SB00AB is ON.)</p> <p>Test numbers 10H: Loop test 20H: Setting confirmation test 30H: Station order confirmation test 40H: Communication test</p>	○	○	○	○
SW00AB (171)	Online test result (at responding stations)	<p>Stores the online test result for responding stations. (Effective when SB00AB is ON.) 0: Test normal More than 1: Test error details (see Section 11.1)</p>	○	○	○	○
SW00AC (172)	Offline test items / faulty stations (at requesting station)	<p>Stores information on the offline tests executed at the requesting station and the station numbers of faulty stations. (Effective when SB00AD is ON.)</p> <p>Test numbers 3: Loop test (forward loop) 4: Loop test (reverse loop) 5: Station to station test (master station) 6: Station to station test (slave station) 7: Self-loopback test 8: Internal self-loopback test</p>	○	○	○	○
SW00AD (173)	Offline test results (at requesting station)	<p>Stores the offline test results for the requesting station. (Effective when SB00AD is ON.) 0: Test normal More than 1: Test error details (See Section 11.1)</p>	○	○	○	○

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SW00B8 (184) *1	Forward loop UNDER	Stores the cumulative total of UNDER errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00B9 (185) *1	Forward loop CRC	Stores the cumulative total of CRC errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00BA (186) *1	Forward loop OVER	Stores the cumulative total of OVER errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00BB (187) *1	Forward loop short frame	Stores the cumulative total of "short frame" errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00BC (188) *1	Forward loop abort (AB. IF)	Stores the cumulative total of "AB. IF" errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00BD (189) *1	Forward loop time out (TIME)	Stores the cumulative total of "TIME" errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00BE (190) *1	Forward loop 2 kbytes error receive (DATA)	Stores the cumulative total of "DATA" errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00BF (191) *1	Forward loop DPLL error	Stores the cumulative total of DPLL errors for the forward loop. More than 0 : Error count	○	○	○	○
SW00C0 (192) *1	Reverse loop UNDER	Stores the cumulative total of UNDER errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C1 (193) *1	Reverse loop CRC	Stores the cumulative total of CRC errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C2 (194) *1	Reverse loop OVER	Stores the cumulative total of OVER errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C3 (195) *1	Reverse loop short frame	Stores the cumulative total of "short frame" errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C4 (196) *1	Reverse loop abort (AB. IF)	Stores the cumulative total of "AB. IF" errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C5 (197) *1	Reverse loop time out (TIME)	Stores the cumulative total of "TIME" errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C6 (198) *1	Reverse loop 2 kbytes error receive (DATA)	Stores the cumulative total of "DATA" errors for the reverse loop. More than 0 : Error count	○	○	○	○
SW00C7 (199) *1	Reverse loop DPLL error	Stores the cumulative total of DPLL errors for the reverse loop. More than 0 : Error count	○	○	○	○

*1 SW00B8 to C7 are reset by switching SB0006 ON.
 When the count for SW00B8 to 00C7 (UNDER, CRC, etc.) changes a little at a time over a long period, there is no problem.
 When rapid counting occurs during a short period (for example during monitoring by a peripheral device), there may be a problem in the cable.

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SW00C8 (200) *2	Forward loop retry frequency	Stores the cumulative total of transmission retries in the forward loop. More than 0 : Error count	○	○	○	○
SW00C9 (201) *2	Reverse loop retry frequency	Stores the cumulative total of transmission retries in the reverse loop. More than 0 : Error count	○	○	○	○
SW00CC (204) *3	Forward loop line error count	Stores the cumulative total of errors detected in the forward loop line. More than 0 : Line error detection count	○	X	○	X
SW00CD (205) *4	Reverse loop line error count	Stores the cumulative total of errors detected in the reverse loop line. More than 0 : Line error detection count	○	X	○	X
SW00CE (206) *5	Loop switching frequency	Stores the cumulative total of loop switches made. More than 0 : Loop switching count	○	X	○	X
SW00CF (207) *5	Loop switching data pointer	Stores the pointer that sets the next loop switching data.	○	X	○	X
SW00D0 (208) to SW00DF (223) *5	Loop switching data	<p>Stores the cause of loop switching and the condition after loop switching. A setting in the common parameters determines whether this data is overwritten or preserved.</p>  <p><Switching factor> The bit corresponding to the relevant error is set to "1". All "0" : Normal recovery b0 : Forward loop H/W error b1 : Reverse loop H/W error b2 : Forward loop forced error b3 : Reverse loop forced error b4 : Forward loop continuous communication error b5 : Reverse loop continuous communication error b6 : Forward loop continuous line error b7 : Reverse loop continuous line error</p> <p><Condition after switching> 0 : Duplex transmission 1 : Data link by forward loop 2 : Data link by reverse loop 3 : Data link by loopback</p>	○	X	○	X

*2 The count may show a number of errors when the power is switched on or off due to resetting but this does not indicate a fault.

If the retry frequency before the data link was started is not required it can be cleared by using SB0005.

*3 SW00CC is reset by switching SB0007 ON.

*4 SW00CD is reset by switching SB0008 ON.

*5 SW00CD to E7 are reset by switching SB0009 ON.

Table 10.2 List of Special Link Registers (Continued)

Number	Name	Function	Device Use Possible?			
			Master Station		Remote I/O Station	
			Fiber-Optic Loop	Coaxial Bus	Fiber-Optic Loop	Coaxial Bus
SW00E0 (224) to SW00E7 (231) *5 *6	Switching request station	Stores the station number of the station that requested the loop switch. <div style="text-align: center;"> </div>	○	○	○	○
SW00EE (238) *7	Transient transmission error	Stores the cumulative total of transient transmission errors. More than 0 : Error count	○	○	○	○
SW00EF (239) *7	Transient transmission error pointer	Stores the pointer for storing the data for the next transient transmission error.	○	○	○	○
SW00F0 (240) to SW00FF (255)	Transient transmission error history	Stores the transient transmission error codes. (See Section 11.1)	○	○	○	○

*5 SW00CD to E7 are reset by switching SB0009 ON.

*6 The loop switching request is made by the station that detects the loop error first, which means that a station other than one of those at either end of the loop may be stored as the loop switching request station.

*7 SW00EE to EF are reset by switching SW000A ON.

10.3.3 Effective SB/SW devices for offline diagnosis

During offline diagnosis almost all SB/SW devices are ineffective but those indicated below are effective. However, they are only effective at the master station.

Effective SB/SW		Mode Setting Switch		
		3	4	5 to 8
SB	00AC	O	O	O
	00AD	O	O	O
SW	0047	x	x	O
	0048	x	x	O
	0049	x	x	O
	0070 to 73	O	O	x
	00AC	O	O	O
	00AD	O	O	O

O : effective x : ineffective

10.4 Special Relays (M) and Special Registers (D) for Remote I/O Stations

This section describes the special relays (M9000 upward) and special registers (D9000 upward) of the remote I/O stations.

Special relays and special registers can be monitored, switched ON/OFF, and have data set in them, from peripheral devices.

10.4.1 Special relays (M)

Table 10.3 Special Relays

Number	Name	Function
M9000 *1	Fuse blown	OFF : Normal ON : There is an output module with a blown fuse (remains ON even after the output module has returned to the normal status if not reset).
M9002 *1	I/O module verify error	OFF : Normal ON : I/O verify error (I/O module status different from the status entered when power switched ON → module is not mounted securely). (Remains ON even after return to the normal status if not reset.)
M9008 *1	Self-diagnostic error	OFF : Normal ON : Error detected (error code stored in D9008) (Remains ON even after return to the normal status if not reset.)
M9084	Error check setting	OFF : Error check executed (check for blown fuses, I/O module verify errors) ON : Error check not executed
M9094	I/O change flag	OFF : Not changed ON : Changed (The I/O module can be changed by switching M9094 ON after the head I/O number of the new module has been set in D9094.)

*1 The RMT.E. LED lights.

10.4.2 Special registers (D)

Table 10.4 Special Registers

Number	Name	Function																																																																																																																																																									
D9000	Blown fuse module No. (Effective when M9000 is ON)	Stores the head I/O number of the module in which a fuse has blown. If a fuse has blown in more than one output module, the lowest head I/O number is stored. (Example: output module Y50 to 6F → "50H" (hexadecimal) is stored)																																																																																																																																																									
D9002	I/O module verify error module number (Effective when M9002 is ON)	Stores the head I/O number of the module for which an I/O module verify error has occurred. If there is more than one output module, the lowest head I/O number is stored. (Example: output module Y50 to 6F → "50H" (hexadecimal) is stored)																																																																																																																																																									
D9008	Self-diagnostic error number (Effective when M9008 is ON)	Stores the error numbers of self-diagnostic errors. (See Table 10.5)																																																																																																																																																									
D9010	Error slot number	Stores the slot number of the slot in which a module for which a self-diagnostic error has occurred is mounted.																																																																																																																																																									
D9014	I/O control mode	Stores the I/O control mode. 3 = I/O in refresh mode																																																																																																																																																									
D9015	Operating state	Stores the operating state of the remote I/O station CPU. 1 = STOP																																																																																																																																																									
D9072	PC communication check	Area used to perform a communication check with remote I/O station CPUs in the self-loopback test of a computer link module.																																																																																																																																																									
D9091	Self-diagnostic detailed error numbers	Stores the detailed error numbers of self-diagnostic errors. (See Table 10.5)																																																																																																																																																									
D9094	New I/O module head I/O number	The head I/O number of an I/O module mounted/removed in the online status is set in this device. (Example: I/O module occupying Y50 to 6F → "50H" (hexadecimal) is set)																																																																																																																																																									
D9100 to D9107	Fuse blown error modules	<p>*1* is stored for the I/O numbers of output modules (entered in units of 16 points) whose fuses have blown. 0 to 7F0 in the table are I/O numbers.</p> <table border="1"> <thead> <tr> <th></th> <th>F</th><th>E</th><th>D</th><th>C</th><th>B</th><th>A</th><th>9</th><th>8</th><th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th> </tr> </thead> <tbody> <tr> <td>D9100</td> <td>F0</td><td>E0</td><td>D0</td><td>C0</td><td>B0</td><td>A0</td><td>90</td><td>80</td><td>70</td><td>60</td><td>50</td><td>40</td><td>30</td><td>20</td><td>10</td><td>0</td> </tr> <tr> <td>D9101</td> <td>1F0</td><td>1E0</td><td>1D0</td><td>1C0</td><td>1B0</td><td>1A0</td><td>190</td><td>180</td><td>170</td><td>160</td><td>150</td><td>140</td><td>130</td><td>120</td><td>110</td><td>100</td> </tr> <tr> <td>D9102</td> <td>2F0</td><td>2E0</td><td>2D0</td><td>2C0</td><td>2B0</td><td>2A0</td><td>290</td><td>280</td><td>270</td><td>260</td><td>250</td><td>240</td><td>230</td><td>220</td><td>210</td><td>200</td> </tr> <tr> <td>D9103</td> <td>3F0</td><td>3E0</td><td>3D0</td><td>3C0</td><td>3B0</td><td>3A0</td><td>390</td><td>380</td><td>370</td><td>360</td><td>350</td><td>340</td><td>330</td><td>320</td><td>310</td><td>300</td> </tr> <tr> <td>D9104</td> <td>4F0</td><td>4E0</td><td>4D0</td><td>4C0</td><td>4B0</td><td>4A0</td><td>490</td><td>480</td><td>470</td><td>460</td><td>450</td><td>440</td><td>430</td><td>420</td><td>410</td><td>400</td> </tr> <tr> <td>D9105</td> <td>5F0</td><td>5E0</td><td>5D0</td><td>5C0</td><td>5B0</td><td>5A0</td><td>590</td><td>580</td><td>570</td><td>560</td><td>550</td><td>540</td><td>530</td><td>520</td><td>510</td><td>500</td> </tr> <tr> <td>D9106</td> <td>6F0</td><td>6E0</td><td>6D0</td><td>6C0</td><td>6B0</td><td>6A0</td><td>690</td><td>680</td><td>670</td><td>660</td><td>650</td><td>640</td><td>630</td><td>620</td><td>610</td><td>600</td> </tr> <tr> <td>D9107</td> <td>7F0</td><td>7E0</td><td>7D0</td><td>7C0</td><td>7B0</td><td>7A0</td><td>790</td><td>780</td><td>770</td><td>760</td><td>750</td><td>740</td><td>730</td><td>720</td><td>710</td><td>700</td> </tr> </tbody> </table>		F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	D9100	F0	E0	D0	C0	B0	A0	90	80	70	60	50	40	30	20	10	0	D9101	1F0	1E0	1D0	1C0	1B0	1A0	190	180	170	160	150	140	130	120	110	100	D9102	2F0	2E0	2D0	2C0	2B0	2A0	290	280	270	260	250	240	230	220	210	200	D9103	3F0	3E0	3D0	3C0	3B0	3A0	390	380	370	360	350	340	330	320	310	300	D9104	4F0	4E0	4D0	4C0	4B0	4A0	490	480	470	460	450	440	430	420	410	400	D9105	5F0	5E0	5D0	5C0	5B0	5A0	590	580	570	560	550	540	530	520	510	500	D9106	6F0	6E0	6D0	6C0	6B0	6A0	690	680	670	660	650	640	630	620	610	600	D9107	7F0	7E0	7D0	7C0	7B0	7A0	790	780	770	760	750	740	730	720	710	700
	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																																																																																																																											
D9100	F0	E0	D0	C0	B0	A0	90	80	70	60	50	40	30	20	10	0																																																																																																																																											
D9101	1F0	1E0	1D0	1C0	1B0	1A0	190	180	170	160	150	140	130	120	110	100																																																																																																																																											
D9102	2F0	2E0	2D0	2C0	2B0	2A0	290	280	270	260	250	240	230	220	210	200																																																																																																																																											
D9103	3F0	3E0	3D0	3C0	3B0	3A0	390	380	370	360	350	340	330	320	310	300																																																																																																																																											
D9104	4F0	4E0	4D0	4C0	4B0	4A0	490	480	470	460	450	440	430	420	410	400																																																																																																																																											
D9105	5F0	5E0	5D0	5C0	5B0	5A0	590	580	570	560	550	540	530	520	510	500																																																																																																																																											
D9106	6F0	6E0	6D0	6C0	6B0	6A0	690	680	670	660	650	640	630	620	610	600																																																																																																																																											
D9107	7F0	7E0	7D0	7C0	7B0	7A0	790	780	770	760	750	740	730	720	710	700																																																																																																																																											
D9116 to D9123	I/O module verify error modules	<p>*1* is stored for the I/O numbers of output modules (entered in units of 16 points) for which I/O module verify errors have been detected. 0 to 7F0 in the table are I/O numbers.</p> <table border="1"> <thead> <tr> <th></th> <th>F</th><th>E</th><th>D</th><th>C</th><th>B</th><th>A</th><th>9</th><th>8</th><th>7</th><th>6</th><th>5</th><th>4</th><th>3</th><th>2</th><th>1</th><th>0</th> </tr> </thead> <tbody> <tr> <td>D9116</td> <td>F0</td><td>E0</td><td>D0</td><td>C0</td><td>B0</td><td>A0</td><td>90</td><td>80</td><td>70</td><td>60</td><td>50</td><td>40</td><td>30</td><td>20</td><td>10</td><td>0</td> </tr> <tr> <td>D9117</td> <td>1F0</td><td>1E0</td><td>1D0</td><td>1C0</td><td>1B0</td><td>1A0</td><td>190</td><td>180</td><td>170</td><td>160</td><td>150</td><td>140</td><td>130</td><td>120</td><td>110</td><td>100</td> </tr> <tr> <td>D9118</td> <td>2F0</td><td>2E0</td><td>2D0</td><td>2C0</td><td>2B0</td><td>2A0</td><td>290</td><td>280</td><td>270</td><td>260</td><td>250</td><td>240</td><td>230</td><td>220</td><td>210</td><td>200</td> </tr> <tr> <td>D9119</td> <td>3F0</td><td>3E0</td><td>3D0</td><td>3C0</td><td>3B0</td><td>3A0</td><td>390</td><td>380</td><td>370</td><td>360</td><td>350</td><td>340</td><td>330</td><td>320</td><td>310</td><td>300</td> </tr> <tr> <td>D9120</td> <td>4F0</td><td>4E0</td><td>4D0</td><td>4C0</td><td>4B0</td><td>4A0</td><td>490</td><td>480</td><td>470</td><td>460</td><td>450</td><td>440</td><td>430</td><td>420</td><td>410</td><td>400</td> </tr> <tr> <td>D9121</td> <td>5F0</td><td>5E0</td><td>5D0</td><td>5C0</td><td>5B0</td><td>5A0</td><td>590</td><td>580</td><td>570</td><td>560</td><td>550</td><td>540</td><td>530</td><td>520</td><td>510</td><td>500</td> </tr> <tr> <td>D9122</td> <td>6F0</td><td>6E0</td><td>6D0</td><td>6C0</td><td>6B0</td><td>6A0</td><td>690</td><td>680</td><td>670</td><td>660</td><td>650</td><td>640</td><td>630</td><td>620</td><td>610</td><td>600</td> </tr> <tr> <td>D9123</td> <td>7F0</td><td>7E0</td><td>7D0</td><td>7C0</td><td>7B0</td><td>7A0</td><td>790</td><td>780</td><td>770</td><td>760</td><td>750</td><td>740</td><td>730</td><td>720</td><td>710</td><td>700</td> </tr> </tbody> </table>		F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0	D9116	F0	E0	D0	C0	B0	A0	90	80	70	60	50	40	30	20	10	0	D9117	1F0	1E0	1D0	1C0	1B0	1A0	190	180	170	160	150	140	130	120	110	100	D9118	2F0	2E0	2D0	2C0	2B0	2A0	290	280	270	260	250	240	230	220	210	200	D9119	3F0	3E0	3D0	3C0	3B0	3A0	390	380	370	360	350	340	330	320	310	300	D9120	4F0	4E0	4D0	4C0	4B0	4A0	490	480	470	460	450	440	430	420	410	400	D9121	5F0	5E0	5D0	5C0	5B0	5A0	590	580	570	560	550	540	530	520	510	500	D9122	6F0	6E0	6D0	6C0	6B0	6A0	690	680	670	660	650	640	630	620	610	600	D9123	7F0	7E0	7D0	7C0	7B0	7A0	790	780	770	760	750	740	730	720	710	700
	F	E	D	C	B	A	9	8	7	6	5	4	3	2	1	0																																																																																																																																											
D9116	F0	E0	D0	C0	B0	A0	90	80	70	60	50	40	30	20	10	0																																																																																																																																											
D9117	1F0	1E0	1D0	1C0	1B0	1A0	190	180	170	160	150	140	130	120	110	100																																																																																																																																											
D9118	2F0	2E0	2D0	2C0	2B0	2A0	290	280	270	260	250	240	230	220	210	200																																																																																																																																											
D9119	3F0	3E0	3D0	3C0	3B0	3A0	390	380	370	360	350	340	330	320	310	300																																																																																																																																											
D9120	4F0	4E0	4D0	4C0	4B0	4A0	490	480	470	460	450	440	430	420	410	400																																																																																																																																											
D9121	5F0	5E0	5D0	5C0	5B0	5A0	590	580	570	560	550	540	530	520	510	500																																																																																																																																											
D9122	6F0	6E0	6D0	6C0	6B0	6A0	690	680	670	660	650	640	630	620	610	600																																																																																																																																											
D9123	7F0	7E0	7D0	7C0	7B0	7A0	790	780	770	760	750	740	730	720	710	700																																																																																																																																											

Table 10.5 Error Codes


D9008 (Hex.)	D9091 (Hex.)	Name	Description	Operating Status *1	
				Cyclic	I/O
11	111	I/O allocation error	There is a mistake in the I/O allocations.	STOP	RUN
	*2 112 113	Insufficient number of LB/LW points	The number of LB/LW points set in the common parameters is insufficient for the number of special function modules.		
31	311	I/O module verify error	An I/O module verify error has occurred.	Depends on the master station	RUN
*3 32	321	Fuse blown error	A fuse blown error has occurred.		
43	431	Illegal interrupt	An interrupt has been attempted from a module other than an intelligent special function module.	RUN	STOP
*3 44	441	Number of mounted intelligent special function modules error	Two or more special function modules are installed.		
*3 44	442	Special function module sum check error	A check sum value verify error has occurred with respect to a special function module compatible with the AnUCPU.		

*1.... Operating status

STOP: I/O modules/special function modules cannot be accessed.

RUN : Forced output from a peripheral device is possible by using the test mode.

Depends on the master station: Depends on the STOP/RUN setting in the AnUCPU parameters



[Operating method] MENU → 2: PARAMETER → 5: AUXILIARY → [F7] CPU OP. MODE SET

*2 The PRM.E. LED lights.

*3 The RMT.E. LED lights.

11. TROUBLESHOOTING

To increase the system reliability, quick and proper system restoration in case of any trouble is essential as well as correct system activation. This chapter describes how to locate the faulty area and what corrective actions should be taken.


11.1 Error Codes

When transient transmission from a peripheral device or computer link module results in failure, an error code (hexadecimal) is returned to the request source (ZNFR/ZNTO instructions, the peripheral device or computer link module, etc.). Table 11.1 shows the meanings and corrective actions corresponding to each error code.

REMARKS

When the GPP function software package is used to monitor the network, the error No. of the transient transmission error can be checked on the error history monitor display screen. In this case, note that the error No. displayed on the error history monitor display screen is divided into the error code and error type.

The first two digits of the error No. represent the error type, and the last two digits show the error code.



As the error type, any of the following items will be displayed according to the value.

- CPU module (from 4000 on)
- Application layer (from F700 on)
- Relay (from F900 on)
- Test (from FD00 on)
- FA controller (from F101 on)
- MAC (from F100 on)
- Network control station (from F800 on)
- Remote station (from FA00 on)
- A/Q conversion (from FE00 on)
- LLC (from F200 on)

Table 11.1 Error Code List

Error Code	Meaning	Corrective Action
4920	No routing parameters The relevant network No. does not exist in the routing parameters.	Set routing parameters at the station where they are required. Set the routing parameters correctly at the station where they are required.
4923	Communication with the network module is not possible (the network module is set to a mode other than "online").	Set the network module to the online mode. Check if an error such as SW.E. has occurred.
4A01	Error at relevant station	Review the status of the relevant station and review the switch settings (check if there is a parameter error and check that the relevant station is set correctly at the master station).
4C20	The network refresh parameters are not set correctly.	Set the network refresh parameters correctly.

Table 11.1 Error Code List (Continued)

Error Code	Meaning	Corrective Action
F101	Initial status	Wait until SB0047 (baton passing status)/SB0049 (data link status) is OFF (normal).
F102	Initial status	
F103	Initial status (online test in progress)	
F104	Control station/sub-control station shift status	
F105	Initial status	
F106	Control station/sub-control station shift status	
F107	Baton passing error (baton missing)	<ul style="list-style-type: none"> • Make SB0047 (baton pass status)/SB0049 (data link status) OFF (normal). • Check for cable fault, cable disconnection, no termination resistor connection, noise and wiring mistake. • Perform a setting confirmation test to check the network station setting status for overlapping station numbers, control station overlapping or like.
F108	Baton passing error (baton duplicated)	
F109	Initial status (online test in progress)	Wait until SB0047 (baton passing status)/SB0049 (data link status) is OFF (normal).
F10A	Initial status (online test/offline test in progress)	
F10B	Station number duplicated	Correct the station numbers.
F10C	Control station duplicated	Correct the control station setting.
F10D	Offline status	Set to online.
F10E	Receive error retry "over"	Check for cable faults, hardware faults, noise, miswiring, failure to connect a terminal resistor (in the case of a bus), setting of the same station number twice, and setting of more than one control station.
F10F	Transmission error retry "over"	
F110	Time out error	
F111	Error at relevant station	Review the status of the relevant station and review the switch settings (check if there is a parameter error and check that the relevant station is set correctly at the master station).
F112	Loop status error	Check for cable faults, hardware faults, noise, miswiring, setting of the same station number twice, and setting of more than one control station.
F113	Transmission failure	Retry after waiting for a while. If the second attempt also results in failure, check for cable faults, hardware faults, noise, miswiring, failure to connect a terminal resistor (in the case of a bus), setting of the same station number twice, and setting of more than one control station. Review the parameters and switch settings. (Check if there is a parameter error and check that the relevant station is set correctly at the control station.)
F114	Transmission failure	Retry after waiting for a while. If the second attempt also results in failure, check for cable faults, hardware faults, noise, miswiring, failure to connect a terminal resistor (in the case of a bus), setting of the same station number twice, and setting of more than one control station.
F117	Transmission failure	Check for cable faults, hardware faults, noise, failure to connect a terminal resistor (in the case of a bus), and miswiring.
F118	Initial status (baton regeneration)	Wait until SB0047 (baton passing status)/SB0049 (data link status) is OFF (normal).
F11A	Transmission failure (duplex loop transmission stopped)	Retry after waiting a while.

Table 11.1 Error Code List (Continued)

Error Code	Meaning	Corrective Action
F11B	Disconnection	Review the parameter and switch settings (check if there is a parameter error and check that the relevant station is set correctly at the control station). Check for cable faults, hardware faults, noise, miswiring, setting of the same station number twice, and setting of more than one control station.
F11F	Initial status (no baton for the host station)	Review the parameter and switch settings (check if there is a parameter error and check that the relevant station is set correctly at the control station).
F122	Transmission failure (in the case of a bus)	Check for disconnection or looseness of the coaxial cable, failure to connect a terminal resistor, and cable faults.
F222	No vacancy in the receive buffer ("buffer full" error)	Retry after waiting a while. If the second attempt also results in an error, review the total number of transient transmissions in the system and the communication interval, and check for errors at the destination CPU such as absence of receive processing (END processing).
F701	Designated station No. error • (When sending data: Attempt made to send data to station "0". When receiving data: A message not intended for the host station has been received.) • An attempt was made to send data to the master station but it was down.	Correct the destination station number.
F702	Destination station No. error (ZNWR instruction) (The destination station number is outside the applicable range; i.e. it is "65" or higher.)	Correct the destination station number.
F703	Destination group No. error (ZNWR instruction) (The destination group number is outside the applicable range; i.e. 10 (8AH) or higher has been specified.)	Correct the destination group number.
F705	Destination CPU error (destination hardware error)	Check the destination CPU.
F707	Number of relay stations error (A destination outside the applicable relay range has been designated; there are 8 or more relay stations.)	Set appropriate destination stations. Review the system.
F709	Network No. error when receiving (the received network number is not correct)	Review the network number.
F70B	Response waiting time out	Retry after waiting a while.
F800	Mode switching error	Correct the hardware switch settings.
F801	Network No. error	
F803	Station No. error	
F804	DIP switch error	
F823	Parameter matching error (The transmission range for each station is smaller in the common parameters than in the station specific parameters.)	Correct the common parameters or the station specific parameters at each station.
F826	Time conveyor error (The parameters at the host station are older than the parameters received from the sub-control station.)	Review the parameters at the sub-control station and/or reset the host station.
F827	No automatic return	Execute processing with no automatic return function.

Table 11.1 Error Code List (Continued)

Error Code	Meaning	Corrective Action
F828	Control station shift function not set	Execute processing on the understanding that there is no control station shift function.
F832	Start rejected (Start attempted under conditions that do not allow starting)	If all stations are stopped, start all stations. Do not perform an automatic start if there is a stop designation from another station.
F833	Key word error (Start executed from a station other than a stopped station.)	Execute the start from a stopped station. Execute a forced start.
F837	Retry frequency "over"	Check the status of the control station. (Has it been reset, or has an error occurred, part way through?)
F838	Time out of corresponding timer (SW0056 is "0")	Check the status of the control station. (Has it been reset, or has an error occurred, part way through?)
F839	Communication impossible (SW0056 is "0")	Remedy the cause of the disconnection.
F83A	SW0000 request is outside the applicable range.	Correct the data of SW0000.
F902	Routing count error	When the routing function is used to connect multiple network systems, transmission from the request source should be made within eight network systems (within seven relay stations).
F906	Relay destination CPU error	Check the relay destination CPU. (Destination hardware error)
F982	Received transient transmission data cannot be processed.	Check for incorrect target station and relay station numbers. (The CPU module or network module of the target station or relay station that requested the transient transmission does not support the requested function.)
FA20	Master station routing parameter error	Correct the master station routing parameters.
FA21	Network No., station No., or module No. setting error	Correct the network No., station No. or module No.
FA22	Master station error	Set the routing parameters
FA25	ZNFR/ZNTO execution error (Buffer memory address designation, number of points designation error)	Correct the ZNFR/ZNTO instruction
FA26	Special function module handshake error	Make sure that the ZNFR/ZNTO instruction is executed with respect to a special function module.
FA30	I/O allocation error	Correct the I/O allocations
FA31	LB/LW allocation error	Correct the common parameters (LB/LW)
FA32	Illegal allocation error	Check the mounted modules.
FA33	Number of mounted intelligent special function modules error	Mount a maximum of two.
FA34	Special function module sum check error	Check the special function module. → Change it.
FA35	I/O module verify error	Check if the module is mounted securely.
FA36	Fuse blown error	Check the output module.
FD01	CRC error (offline test)	Retry. (However, if errors occur frequently, check for cable faults, hardware faults, noise, failure to connect a terminal resistor (in the case of a bus), and miswiring.)
FD02	Overrun error (offline test)	
FD03	AB.IF error (offline test)	
FD04	TIME error (offline test)	
FD05	Data error (offline test)	
FD06	Underrun error (offline test)	
FD07	Transmission failure	Retry. (However, if errors occur frequently, check for cable faults, hardware faults, noise, failure to connect a terminal resistor (in the case of a bus), and miswiring.)

Table 11.1 Error Code List (Continued)


Error Code	Meaning	Corrective Action
FD08	Transmission failure (in the case of a bus)	Check for disconnection or looseness of the coaxial cable, failure to connect a terminal resistor, and cable faults.
FD09	Loop status changes during data link operation (offline loop test)	Retry. (Do not execute loop switching part way through.) However, if the problem occurs frequently, check the line and wiring.
FD0A	Communication unstable (offline loop test)	Retry. (However, if errors occur frequently, check for cable faults, hardware faults, noise, failure to connect a terminal resistor (in the case of a bus), and looseness.)
FD0B	Wiring error (offline loop test)	Check the wiring.
FD11	"Test in progress" error	Execute the operation after the test instigated by another station is completed.
FD12	Disconnection error	Remedy the cause of the disconnection.
FD13	<p>Number of stations abnormal error</p> <ul style="list-style-type: none"> • Online diagnosis in accordance with parameter designations was executed when parameters were not set. • Online diagnosis was executed while the total number of link stations, or number of stations, set in the common parameters was a value smaller than the host station number. 	<ul style="list-style-type: none"> • Execute online diagnosis after setting the total number of link stations in the common parameters. • Designate a station number that is the same as or higher than the host station station number. Or execute online diagnosis from a station number than is equal to or lower than the designated number of stations.
FD16	Online diagnostic retry over	Check for cable fault, cable disconnection, noise and wiring mistake.
FD1A	Same station number allocated twice	Check the stations to which the station number is allocated and correct the problem.
FD1B	"Test stopped" error	A station executing a test has been stopped during test execution, for example by resetting. There is a faulty station on the line.
FD1C	Test stopped by loop switching	Retry. (Do not execute loop switching part way through.) However, if the problem occurs frequently, check the line and wiring.
FD1E	Test impossible with bus type used	Perform a test that is possible with the bus type being used.
FD31	Duplicated online diagnosis request (Online diagnosis requests made simultaneously)	Wait until one online diagnosis operation has finished before requesting another one.
FD35	Time out while waiting for response	Retry after waiting a while. Check the status of the relevant station and the line.
FD36	Time out while waiting for correspondence	
FD38	Text duplication error	
FD39	Test request destination is the host station (communication test)	Change the test request destination.
FD3A	Test request destination is an inapplicable station (communication test)	<p>The station for which the test request was designated is not an acceptable one.</p>  <p>■ : Stations for which communication test requests are not possible</p>

Table 11.1 Error Code List (Continued)

Error Code	Meaning	Corrective Action
FE20	Data error (A station whose CPU is stopped and which cannot process the data has been designated.)	Correct the routing parameters or change the stopped station to an AnUCPU.
FE21	LRDP/LWTP device range error	Check the device range at the communicating CPU. The ZNRD/ZNWR instruction was executed for the AnN/AnA/AnS(H)CPU.
FE22	AnUCPU request error	Error such as data length error

11.2 Troubleshooting

This section describes simple troubleshooting procedures.

If a problem occurs during data link operation, check the link status using the following steps in the order they are presented here.

- (1) Check the status of the line and the status of other stations by performing network monitoring at a peripheral device (see Section 5.1).
- (2) Check the lit/unlit status of the LEDs on the network module at the station at which the communication error has occurred (see Section 3.2).
- (3) Perform online diagnosis from a peripheral device and check the line status and switch settings (see Section 5.2).

REMARK

In order to ensure fast and complete recovery from problems that occur during data link operation, it is important to check the hardware settings of the network module and the connection of the data link cables on starting up the system.

It is important to carry out the following procedures relating to the network module properly: setting the hardware settings, connection of the data link cables, and performance of offline diagnosis (hardware test, internal self-loopback test, station to station test, reverse loop/forward loop test, etc.). The relevant procedures are described in Chapter 3 "PRE-OPERATION PROCEDURE".

11.2.1 Points to check first

Point to Check	Check Method
Monitor the communication status at each of the stations from a peripheral device using the network monitoring function.	Check the status of the CPU module at the station at which the communication error occurred, the status of the network module, and the loop status of each module, to determine the site of the error.
Is the "POWER" LED of the power supply module of the station at which the error occurred lit?	If the "POWER" LED is not lit, check the supply voltage to the power supply module, and check for insufficient power supply capacity, overvoltage, and failure of the power supply module.
Is the "RUN" LED of the CPU module lit?	If the "RUN" LED is not lit or is flashing, read the error code at a peripheral device and take the corrective action appropriate for the error. (For information on the meanings of error codes and the corrective action to take, refer to the users' manual for the CPU module.)
Is the lit/unlit status of the LEDs on the network module normal?	Check the lit/unlit status of the "RUN", "SW.E", "M/S.E", "PRM.E", etc., LEDs and take appropriate action if an error is indicated. (See section 13.3.) If the "T. PASS" LED turns ON and OFF or is instable, check the following since the line status is assumed to be instable. 1) Check that the connector is not nearly disconnected and the cable is not nearly broken. 2) Check that the cable used is as determined in the specifications. 3) Check that the overall distance and interstation distance are as determined in the specifications.

11.2.2 Troubleshooting when data link is disabled throughout the system

Point to Check	Check Method
<p>Monitor the communication status at each device using the network monitoring function.</p>	<p>Check the status of the line by performing a network diagnosis loop test from a peripheral device (this applies only in the case of a fiber-optic loop system). Check the CPU module and network module at the station at which the error occurred. Check the network module and data link cable by performing a self-loopback test and station to station test in offline testing to determine the location of the line error. Check if all the stations in the data link are stopped.</p>
<p>Have the network link parameters been set at the master station?</p>	<p>Check by reading the network parameters from the CPU module of the master station.</p>
<p>Is there a mistake in the switch settings of the network module at the master station?</p>	<p>Check the network No. setting switch, station No. setting switch, mode setting switch, condition setting switches, etc.</p>
<p>Is the link watch dog time setting appropriate?</p>	<p>Set the link watch dog time to 2000 ms and check if data link is possible.</p>
<p>Is the master station down?</p>	<p>Check the lit/unlit status of the LEDs on the network module of the master station.</p>

11.2.3 Troubleshooting when the data link is disabled at a specific station

Point to Check	Check Method
Monitor the communication status at each station.	Check stations at which a communication error has occurred, and the loop status, by performing line monitoring using the network monitoring function at a peripheral device. In the case of a fiber-optic loop system, check the line status and the communication status at each station using the loop test of the network diagnosis function at a peripheral device.
Is the network module at the station at which the communication error has occurred normal?	Check if an error or failure has occurred at the CPU module or network module of the station at which the communication error occurred.
Is the network module the cause of the loop error? Or is the data link cable the cause?	Check if the network module is normal by executing a self-loopback test in offline testing. Check if the data link cable is normal by executing a station to station test in offline testing.
Are there any mistakes in the network parameters of the master station?	Check that, in the common parameter settings, the setting for the total number of stations in the link is the highest station number or a higher number, and that stations which cannot communicate are set as reserve stations.
Are the network parameters at the station at which the error has occurred normal?	Read the network parameters from the CPU module at the station at which the communication error occurred and check if the "set number of modules" settings and network refresh parameters are set correctly.
Are there any mistakes in the network module switch settings?	Check the network No. setting switch, the station number setting switch, the mode setting switch, and the condition setting switches.

11.2.4 Troubleshooting when the communicated data is abnormal

(1) Abnormal cyclic transmission data

Point to Check	Check Method
Is the sequence program error-free?	Set the CPU modules at the master station to the STOP status, switch the link devices of the master station ON and OFF using test operation at a peripheral device, and check if the data is transmitted to the remote I/O station. If data is transmitted normally, correct the sequence program. If data is not transmitted normally, review the network parameters of the master station and self station.
Are there any mistakes in the network refresh parameter settings of the master station?	Check the settings of the network refresh parameters and the station specific parameters, and check which ranges of LB/LW/LX/LY devices used by the sequence program the ranges of LB/LW/LX/LY devices received from the master station are stored in.

(2) Abnormal transient transmission

Point to Check	Check Method
Does an error occur when cyclic transmission is executed?	Check the error code generated on execution of transient transmission and take the action indicated in the error code table in Section 11.1.
Are there any mistakes in the routing parameter settings?	Check the settings using the communication test in online diagnosis from a peripheral device.

11.3 LEDs on the Network Module

This section describes the LEDs that light on occurrence of an error during data link operation.

Display	Error Detection Status	Possible Causes
RUN	Not lit	A hardware error has occurred in the network module. An error has occurred in the CPU module.
SW.E.	Lit	The network No. setting switch has been set to a value outside the range 1 to 255. The station No. setting switch at the master station has been set to a value other than "0". The station No. setting switch at a remote I/O station has been set to a value outside the range 1 to 64. The mode setting switch has been set to an unusable position.
M/S.E.	Lit	It has been detected that the same station number has been set twice, or more than one master station has been set, in one network.
PRM.E.	Lit	There is an error in the I/O allocations. The number of LB/LW points is insufficient for the special function modules. There is an error in the parameters received from the master station.
D.LINK	Not lit	Cyclic transmission has been stopped by stopping data link operation from a peripheral device or by executing an online test etc. T.PASS is not lit.
T.PASS	Not lit	The station cannot participate in baton passing and transient transmission is therefore impossible. Communication has been stopped by a line error.
CRC	Lit	A code check is performed on the received data to determine if there is an error or not. An error occurs in the event of a cable fault, noise, etc.
OVER	Lit	Received data has overwritten the previous set of data before it could be processed. A hardware error has occurred in the receiving circuitry of the network module.
AB.IF	Lit	*1* bits have been received continuously in a frame of received data and the stipulated data length has been exceeded, or the data length of the received data is shorter than stipulated. Short watchdog time setting, cable fault, noise, etc. caused the error.
TIME	Lit	Baton passing has not reached the host station within the set watchdog time. Short watchdog time setting, cable fault, noise, etc. caused the error.
DATA	Lit	Error code data has been received. A cable fault, noise, etc. caused the error.
UNDER	Lit	Internal processing of send data is not being performed at regular intervals. A hardware error has occurred in the sending circuitry of the network module.
LOOP	Lit	If the F.LOOP LED is lit, it means there is a line error in the forward loop line; an error occurs if the power supply to stations that are adjacent to the host station and send data to it is switched off, if a hardware error occurs in the forward loop sending circuitry, if the forward loop data link cable is not connected or broken, or if there is a hardware error in the forward loop receiving circuitry of the host station. If the R.LOOP LED is lit, it means there is a line error in the reverse loop line; an error occurs if the power supply to stations that are adjacent to the host station and send data to it is switched off, if a hardware error occurs in the reverse loop sending circuitry, if the reverse loop data link cable is not connected or broken, or if there is a hardware error in the reverse loop receiving circuitry of the host station.
RMT.E.	Lit	An I/O module verify error or fuse blown error has occurred.
ST.E.	Lit	It has been detected that the same station has been set twice in one network.

POINT

Refer to the following if the "T. PASS" LED turns ON and OFF or is instable.

<Cause>

It is assumed that the line status is instable.

<Corrective action>

- 1) Check that the connector is not nearly disconnected and the cable is not nearly broken.
- 2) Check that the cable used is as determined in the specifications.
- 3) Check that the overall distance and interstation distance are as determined in the specifications.

APPENDICES

APPENDIX 1 NETWORK PARAMETER SETTING SHEETS

When the MELSECNET/10 parameters are set at a peripheral device, filling in these forms provides a convenient record of the settings. The configuration of these forms differs somewhat from that of the setting screens actually displayed by the peripheral device.

1.1 "Number of Modules" Settings

SET NUMBER OF MODULES

NO OF NETWORK MODULES (1-4) []

MODULE NO. ACCESSED BY GPP []

	MODULE 1	MODULE 2	MODULE 3	MODULE 4
I/O NO.	[]	[]	[]	[]
NETWORK MODULE TYPE	[]	[]	[]	[]
	1 : MELSECNET/10 (DEFAULT PARAMETER) 2 : MELSECNET/10 (CONTROL STATION) 3 : MELSECNET/10 (NORMAL STATION)		4 : MELSECNET/10 (REMOTE I/O MASTER) 5 : MELSECNET II (MASTER STATION) 6 : MELSECNET II (LOCAL STATION)	
NETWORK NO.	[]	[]	[]	[]

1.2 Network Refresh Parameters

NETWORK REFRESH PARAMETER OF MELSECNET/10

NETWORK MODULE []

LB ↔ B	LB [] ↔ B [] SIZE [] HPOINTS
LW ↔ W	LW [] ↔ W [] SIZE [] HPOINTS
LX ↔ X	LX [] ↔ X [] SIZE [] HPOINTS
LY ↔ Y	LY [] ↔ Y [] SIZE [] HPOINTS
SB COPIED TO	SB [] ↔ DEST. [][] SIZE [] HPOINTS
SW COPIED TO	SW [] ↔ DEST. [][] SIZE [] HPOINTS
HISTORY	[] 0: RETAIN 1: OVERWRITE

1.3 Common Parameters (MELSECNET/10), Remote I/O Network

(1) LB/LW settings

LB/LW settings

MODULE NO.

NO. OF STN.	LINK WDT * 10ms

RESERVE	REMOTE I/O STN. NO.	M → R	M ← R	M → R	M ← R
		LB	LB	LW	LW
	1	—	—	—	—
	2	—	—	—	—
	3	—	—	—	—
	4	—	—	—	—
	5	—	—	—	—
	6	—	—	—	—
	7	—	—	—	—
	8	—	—	—	—
	9	—	—	—	—
	0	—	—	—	—

If the station number is a two-digit one, write the extra digit in the box enclosed by a dotted line.
 The highest station number is 64.
 Circle the station numbers of reserve stations.

(2) LX/LY settings

SETTING THE LX/LY TRANSMISSION RANGES IN EACH STATION

MODULE NO.

NO. OF STN.	LINK WDT * 10ms

I/O MASTER

RESERVE	REMOTE I/O STN. NO.	M → R	M ← R	M → R	M ← R
		LB	LB	LW	LW
	1	—	—	—	—
	2	—	—	—	—
	3	—	—	—	—
	4	—	—	—	—
	5	—	—	—	—
	6	—	—	—	—
	7	—	—	—	—
	8	—	—	—	—
	9	—	—	—	—
	0	—	—	—	—

If the station number is a two-digit one, write the extra digit in the box enclosed by a dotted line.
 The highest station number is 64.
 Circle the station numbers of reserve stations.

(3) Extension settings

EXTENSION SETTINGS

	Default values
CONSTANT LINK SCAN [] ms(0-500)[0] ms
MAX. # OF RECONNECTION STN.[] STATION(1-16)[2] stations
DUPLEX COMMUNICATION [] 0:NO 1:YES[0]
ACCESSED ZNFR/ZNTO [] (1-64)[64]

1.4 I/O Allocations

(1) Number of slots setting

Number of slots setting

STATION NO.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
NUMBER OF SLOTS																
STATION NO.	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
NUMBER OF SLOTS																
STATION NO.	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
NUMBER OF SLOTS																
STATION NO.	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64
NUMBER OF SLOTS																

(2) Module settings

Module settings

STATION NO.																			
SLOT NO.																			
I/O MODULE																			
STATION NO.																			
SLOT NO.																			
I/O MODULE																			
STATION NO.																			
SLOT NO.																			
I/O MODULE																			
STATION NO.																			
SLOT NO.																			
I/O MODULE																			

VACANCY	X (X)	Y (Y)	MODULE (F)
S 0	X 0	Y 0	F16
S16	X16	Y16	F32
S32	X32	Y32	F48
S48	X48	Y48	F64
S64	X64	Y64	

1.5 Routing Parameters

Routing parameters


No.	DEST. N/W NO.	RELAY N/W NO.	RELAY STATION NO.
[]1			
[]2			
[]3			
[]4			
[]5			
[]6			
[]7			
[]8			
[]9			
[]0			

If the number to be entered in the No. column is a two-digit one, fill in the box [].

1.6 Network Module Settings

(1) Master station

NETWORK MODULE SETTINGS



- (1) Network No. setting switch setting range
 X100 [] Setting range: 0 to 2
 X10 [] Setting range: 0 to 9
 X1 [] Setting range: 0 to 9

- (2) Station No. setting range
 X10 [] Setting range: 0 to 6
 X1 [] Setting range: 0 to 9


- (3) Mode setting switch
 [] Setting range: 0 to F

- (4) Condition setting switch

SW	ON/OFF condition	OFF	ON
1	[]	PC-to-PC network	Remote I/O network
2	[]	All OFF	
3	[]		
4	[]		
5	[]		
6	[]		
7	[]		
8	[]		

(2) Remote I/O station

NETWORK MODULE SETTINGS



(1) Station No. setting switch (STATION No.)

- X10 [] Setting range: 0 to 6
- X1 [] Setting range: 0 to 9

(2) Mode setting switch (MODE)

- [] Setting range: 0 to F

(3) All OFF

APPENDIX 2 GLOSSARY

A

A6BR10(DC)

See the definition for "Coaxial repeater unit".

AB.IF

Error that occurs if a greater number of ones ("1") than stipulated are received consecutively, or if the receive data length is too short. [p3-4, 11-10]

AJ72LP25/AJ72BR15

Modules required at the remote I/O stations of a remote I/O network. AJ72LP25 is used in optical loop systems and AJ72BR15 is used in coaxial bus systems.

AnUCPU

A PC CPU essential for constructing a MELSECNET/10 system. It has 8192 points for each of the following devices: X, Y, B, W.

Automatic return function

A function whereby stations that have been disconnected due to a fault are automatically returned to the data link when the fault is remedied. [p7-22]

B

Baton passing

The right to send data.
The right to execute a cyclic transmission or transient transmission is conceded once per link scan.

C

Coaxial bus system

A system that uses coaxial buses. [p1-7, p3-16]

Coaxial cable

A link cable essential for the construction of coaxial bus systems. There are two types: 3C-2V and 5C-2V. [p2-4]

Coaxial repeater unit

A unit that can be used to extend the distance of a coaxial bus system (up to 500 m). Since up to 4 units can be used in one network, the maximum total extension distance of one network is 2.5 km. [p3-16]

Common parameters

Parameters used to set the number of stations, the ranges of devices that can be sent by each station, etc. [p9-10]

Communication test

One of the offline diagnosis tests, in which transient transmission and the routing parameters are checked. [p5-29]

Condition monitor

Display of host station switch/parameter settings, data link and test information, etc., using a peripheral device. [p5-12]

Constant link scan function

A function that enables the link scan time to be kept constant. [p7-14]

CPU R/W

Indicates communication with the PLC CPU. [p3-4]

CRC

Receive data code check error.
[p3-4, 3-9, 11-10]

Cyclic transmission function

Function whereby communication is executed between the stations of a PC-to-PC network, or between the master station and remote I/O stations of remote I/O network.
B, W, X, and Y devices are used. [p7-2]

D

DATA

Indicates an error when 2 kbytes or more of erroneous data have been received.
[p3-4, 3-9, 11-10]

Data link module

Modules required at each station in order to establish a MELSECNET or MELSECNET/B data link.

D.LINK

Indicates operation of a data link. [p3.4, 3-9, 11-10]

DUAL

Indicates execution of multiplex transmission. [p3-4]

E

Error history monitor

Display of an error history for loop/communication/transient transmissions using a peripheral device. [p5-21]

F

Fiber-optic cable

A link cable essential for the construction of optical loop systems. There are two types: SI and QSI. [p2-3]

5C-2V

See the definition of "Coaxial cable". Lengths up to 500 m can be used.

Faulty station

A station that is completely incapable of data link operation because the power supply is OFF. [p8-3]

Forward/reverse loop tests

One of the offline diagnosis tests, in which the entire line is tested. [p3-28]

G

GPP function software package

Software that is loaded in a peripheral device to enable programming, monitoring, etc. [p1-10]

H

Hardware test

One of the offline tests, in which a hardware test including the send/receive circuits is performed. [p3-20]

Intelligent special function module

A module that executes interrupt processing with respect to the PC CPU. [p1-12]

Internal self-loopback test

One of the offline diagnosis tests, in which a hardware test including the send/receive circuits is performed. [p3-22]

I/O allocation

The setting of module information for each remote I/O station. [p7-11, p9-23]

I

LB/LW/LX/LY

See the definition for "Link device".

Line monitor

Display of line/data link/CPU/parameter information using a peripheral device. [p5-2]

Link cable

A cable used to connect network modules and operate a data link. There are two types: fiber-optic cables and coaxial cables. [p2-3]

Link device

Link devices are the devices used to operate a data link. At the PLC CPU side they are called B/W/X/Y and at the network module side LB/LW/LX/LY.

Link refresh

Processing in which data is exchanged between an AnUCPU and a network module. [p8-1]

Link scan

Processing in which data is exchanged between network modules. [p8-1]

LOOP

Indicates a forward loop (F.LOOP) or reverse loop (R.LOOP) error. [p3-4, 3-9, 11-10]

Loopback

Looping back in order to operate the data link while bypassing faulty stations. [p7-18]

Loop test

One of the online tests, in which the loop status is checked. Can only be used in an optical loop system. [p5-26]

M

Master station

A station that is the control source for a remote I/O network and uses an AJ71LP21 or AJ71BR11. Parameters must be set for this station. [p1-7]

MNG

Indicates that the station has been set as the control station or master station. [p3-4]

Module setting

Setting the module information of remote I/O stations for which I/O allocations are to be made. [p7-11, p9-23]

M/S.E.

The control station/master station or a station No. is duplicated. [p3-4]

Multiplex transmission function

A function, usable only in optical loop systems in which both forward and reverse loops are normal, whereby the transmission speed can be increased. [p7-16]

Multi-tier system

A system in which more than one network is connected. [p1-8, p6-3]

N

Network diagnosis

See the definition of "Online diagnosis".

Network module

A type of module required at each station in order to establish a MELSECNET/10 data link. Examples include AJ71LP21, AJ71BR11, AJ72LP25, and AJ72BR15. [p1-10]

Network monitor

Display of the network statuses using a peripheral device. [p5-1]

Network refresh parameters

Parameters used to set the correspondence between the devices of network modules (LX/LY/LB/LW/SB/SW) and the devices of the PC CPU (X/Y/B/W/M...). [p9-5]

Network setting

Setting of the parameters required for data link operation by using a peripheral device. [p9-1]

Number of modules settings

Settings that set the information for the network modules and data link modules mounted to the AnUCPU. [p9-2]

Number of online return stations setting function

Function that allows the number of stations that can be returned to the online status in one link scan to be set. [p7-17]

O

Offline diagnosis

A test in which a network module is set to the test mode, a network module hardware test is performed and the data link cable wiring etc. is checked. [p3-17]

Online diagnosis

A test in which the line status and network module settings are checked using a peripheral device. [p5-25]

Optical loop system

A system that uses fiber-optic cables. [p1-7, p3-12]

OVER

Indicates that receive data processing is delayed. [p3-4, 3-9, 11-10]

P

PC

Indicates that a PC-to-PC network has been set. [p3-4]

PC-to-PC network

Network comprised exclusively of stations that have PC CPUs.

Peripheral device

Equipment used for programming, monitoring, storage, etc. [p1-10]

POWER

Indicates a module's power supply status. [p3-4, 3-9]

PRM.E.

Indicates an error in the parameter settings. [p3-4, 3-9, 11-10]

Q

QSI fiber-optic cable

Cables made of quartz glass that can be used over a maximum distance of 1km, twice that possible with SI fiber-optic cables. [p2-3]

R

RD

Indicates that data is being received. [p3-4, 3-9, 11-10]

REMOTE

Indicates that a remote I/O network has been set. [p3-4]

Remote I/O network

A network comprised exclusively of remote I/O stations. [p1-1]

Remote I/O station

A station controlled by a master station. The models used are the AJ72LP25 and the AJ72BR15. [p1-7]

Reserve station

Set in order to avoid the problem of station to be connected in the future (which is included in the number of stations but is not actually connected) being treated as a faulty station. [p7-10]

RMT.E.

Blown fuse, I/O module verify error. [p3-9, 11-10]

Routing function

A function that allows transient transmission to stations in other networks. The routing parameters must be set to use this function. [p7-7]

Routing parameters

Parameters that must be set to use the routing function. [p7-7, p9-27]

RUN

Indicates the normal/error status of a module. [p3-4, 3-9, 11-10]

S

SB/SW

See the definition for "Special link relays (SB)/special link registers (SW)".

SD

Indicates that data is being sent. [p3-4, 3-9, 11-10]

Self-loopback test

One of the offline tests, in which a hardware test including send/receive circuits and cables is performed. [p3-24]

Setting confirmation test

One of the online diagnosis tests, in which the switch settings of each station are checked. [p5-27]

SI fiber-optic cables

Made of multicomponent glass. There are two types: H type and L type. [p2-3]

Slot setting

Setting of the number of remote I/O station slots for which I/O allocations are to be made. [p7-11, p9-23]

S.MNG

Indicates that the station has been switched to a sub-control station. [p3-4]

Special link relays (SB)/special link registers (SW)

Devices that store the statuses of the data link. [p10-14]

Special relays (M)/special registers (D)

Devices that store the statuses of the host station in a remote I/O station.

Station order confirmation test

One of the online diagnosis tests, used to confirm the station numbers of connected stations. [p5-28]

Station separation function

Function whereby a station that has gone down in a coaxial bus system can be isolated from the link and data link operation continued by using the operational stations. [p7-20]

Station-to-station test

One of the offline diagnosis tests, used to test communication between two stations. [p3-26]

ST.E.

Indicates that a station No. is duplicated. [p3-9, 11-10]

Suspended station

A station at which cyclic transmission is stopped but transient transmission is still possible. [p8-3]

SW.E.

Indicates an error in a module's switch settings. [p3-4, 3-9, 11-10]

T

Terminal resistance

An essential component in the construction of a coaxial bus system (2 required per network). [p1-10, p3-18]

3C-2V

See the definition of "Coaxial cable". Lengths up to 300 m can be used. [p3-24]

TIME

Indicates that a data link watchdog timer has timed out. [p3-4, 3-9, 11-10]

Total number of link stations

In a PC-to-PC network, the total number of stations (control station + normal stations.)
In a remote I/O network, the number of remote I/O stations. [p9-10]

T.PASS

See the definition for "Baton passing".

Transmission delay time

The time taken for data to be transmitted from the master station to a remote I/O station, or from a remote I/O station to the master station. [p8-4]

Transient transmission function

A function whereby communication is only executed when there is a request. [p7-6]

Two-tier system

A single network. [p1-7, p6-1]

U

UNDER

Indicates that the internal processing for receive data is not at fixed intervals. [p3-4, 3-9, 11-10]

W

WAIT

Waiting for communication with a special function module.

W.D.T.

The time used to determine whether or not the data link is operating normally. [p9-11]

Z

ZNFR/ZNTO

Special instructions used to read data from/write data to the buffer memories of special function modules at remote I/O stations. [P4-24, 10-3]

WARRANTY

Please confirm the following product warranty details before starting use.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the dealer or Mitsubishi Service Company. Note that if repairs are required at a site overseas, on a detached island or remote place, expenses to dispatch an engineer shall be charged for.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued. Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not possible after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of chance loss and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to damages caused by any cause found not to be the responsibility of Mitsubishi, chance losses, lost profits incurred to the user by Failures of Mitsubishi products, damages and secondary damages caused from special reasons regardless of Mitsubishi's expectations, compensation for accidents, and compensation for damages to products other than Mitsubishi products and other duties.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

6. Product application

- (1) In using the Mitsubishi MELSEC programmable logic controller, the usage conditions shall be that the application will not lead to a major accident even if any problem or fault should occur in the programmable logic controller device, and that backup and fail-safe functions are systematically provided outside of the device for any problem or fault.
- (2) The Mitsubishi general-purpose programmable logic controller has been designed and manufactured for applications in general industries, etc. Thus, applications in which the public could be affected such as in nuclear power plants and other power plants operated by respective power companies, and applications in which a special quality assurance system is required, such as for Railway companies or National Defense purposes shall be excluded from the programmable logic controller applications.

Note that even with these applications, if the user approves that the application is to be limited and a special quality is not required, application shall be possible.

When considering use in aircraft, medical applications, railways, incineration and fuel devices, manned transport devices, equipment for recreation and amusement, and safety devices, in which human life or assets could be greatly affected and for which a particularly high reliability is required in terms of safety and control system, please consult with Mitsubishi and discuss the required specifications.

Microsoft Windows, Microsoft Windows NT are registered trademarks of Microsoft Corporation in the United States and other countries.

Pentium is a registered trademark of Intel Corporation in the United States and other countries.

Other company and product names herein are either trademarks or registered trademarks of their respective owners.

SPREAD

Copyright (C) 1998 Farpoint Technologies, Inc.

HEADQUARTERS

MITSUBISHI ELECTRIC EUROPE B.V. **EUROPE**
 German Branch
 Gothaer Straße 8
D-40880 Ratingen
 Phone: +49 (0)2102 / 486-0
 Fax: +49 (0)2102 / 486-1120

MITSUBISHI ELECTRIC EUROPE B.V.-org.sl. **CZECH REP.**
 Czech Branch
 Avenir Business Park, Radlická 714/113a
CZ-158 00 Praha 5
 Phone: +420 - 251 551 470
 Fax: +420 - 251-551-471

MITSUBISHI ELECTRIC EUROPE B.V. **FRANCE**
 French Branch
 25, Boulevard des Bouvets
F-92741 Nanterre Cedex
 Phone: +33 (0)1 / 55 68 55 68
 Fax: +33 (0)1 / 55 68 57 57

MITSUBISHI ELECTRIC EUROPE B.V. **IRELAND**
 Irish Branch
 Westgate Business Park, Ballymount
IRL-Dublin 24
 Phone: +353 (0)1 4198800
 Fax: +353 (0)1 4198890

MITSUBISHI ELECTRIC EUROPE B.V. **ITALY**
 Italian Branch
 Viale Colleoni 7
I-20041 Agrate Brianza (MB)
 Phone: +39 039 / 60 53 1
 Fax: +39 039 / 60 53 312

MITSUBISHI ELECTRIC EUROPE B.V. **POLAND**
 Poland Branch
 Krakowska 50
PL-32-083 Balice
 Phone: +48 (0)12 / 630 47 00
 Fax: +48 (0)12 / 630 47 01

MITSUBISHI ELECTRIC EUROPE B.V. **RUSSIA**
 52, bid. 3 Kosmodamianskaya nab 8 floor
RU-115054 Moscow
 Phone: +7 495 721-2070
 Fax: +7 495 721-2071

MITSUBISHI ELECTRIC EUROPE B.V. **SPAIN**
 Spanish Branch
 Carretera de Rubí 76-80
E-08190 Sant Cugat del Vallés (Barcelona)
 Phone: 902 131121 // +34 935653131
 Fax: +34 935891579

MITSUBISHI ELECTRIC EUROPE B.V. **UK**
 UK Branch
 Travellers Lane
UK-Hatfield, Herts. AL10 8XB
 Phone: +44 (0)1707 / 27 61 00
 Fax: +44 (0)1707 / 27 86 95

MITSUBISHI ELECTRIC CORPORATION **JAPAN**
 Office Tower "Z" 14 F
 8-12,1 chome, Harumi Chuo-Ku
Tokyo 104-6212
 Phone: +81 3 622 160 60
 Fax: +81 3 622 160 75

MITSUBISHI ELECTRIC AUTOMATION, Inc. **USA**
 500 Corporate Woods Parkway
Vernon Hills, IL 60061
 Phone: +1 847 478 21 00
 Fax: +1 847 478 22 53

EUROPEAN REPRESENTATIVES

GEVA **AUSTRIA**
 Wiener Straße 89
AT-2500 Baden
 Phone: +43 (0)2252 / 85 55 20
 Fax: +43 (0)2252 / 488 60

TEHNIKON **BELARUS**
 Oktyabrskaya 16/5, Off. 703-711
BY-220030 Minsk
 Phone: +375 (0)17 / 210 46 26
 Fax: +375 (0)17 / 210 46 26

ESCO DRIVES & AUTOMATION **BELGIUM**
 Culliganlaan 3
BE-1831 Diegem
 Phone: +32 (0)2 / 717 64 30
 Fax: +32 (0)2 / 717 64 31

Koning & Hartman b.v. **BELGIUM**
 Woluwelaan 31
BE-1800 Vilvoorde
 Phone: +32 (0)2 / 257 02 40
 Fax: +32 (0)2 / 257 02 49

INEA BH d.o.o. **BOSNIA AND HERZEGOVINA**
 Aleja Lipa 56
BA-71000 Sarajevo
 Phone: +387 (0)33 / 921 164
 Fax: +387 (0)33 / 524 539

AKHNATON **BULGARIA**
 4 Andrej Ljapchev Blvd. Pb 21
BG-1756 Sofia
 Phone: +359 (0)2 / 817 6044
 Fax: +359 (0)2 / 97 44 06 1

INEA CR d.o.o. **CROATIA**
 Losinjska 4 a
HR-10000 Zagreb
 Phone: +385 (0)1 / 36 940 -01 / -02 / -03
 Fax: +385 (0)1 / 36 940 -03

AutoCont C.S. s.r.o. **CZECH REPUBLIC**
 Technologická 374/6
CZ-708 00 Ostrava-Pustkovce
 Phone: +420 595 691 150
 Fax: +420 595 691 199

Beijer Electronics A/S **DENMARK**
 Lykkegårdsvej 17
DK-4000 Roskilde
 Phone: +45 (0)46 / 75 76 66
 Fax: +45 (0)46 / 75 56 26

Beijer Electronics Eesti OÜ **ESTONIA**
 Pärnu mnt.160i
EE-11317 Tallinn
 Phone: +372 (0)6 / 51 81 40
 Fax: +372 (0)6 / 51 81 49

Beijer Electronics OY **FINLAND**
 Peltoie 37
FIN-28400 Ulvila
 Phone: +358 (0)207 / 463 540
 Fax: +358 (0)207 / 463 541

UTEKO **GREECE**
 5, Mavrogenous Str.
GR-18542 Piraeus
 Phone: +30 211 / 1206 900
 Fax: +30 211 / 1206 999

MELTRADE Kft. **HUNGARY**
 Fertő utca 14.
HU-1107 Budapest
 Phone: +36 (0)1 / 431-9726
 Fax: +36 (0)1 / 431-9727

Beijer Electronics SIA **LATVIA**
 Rītausmas iela 23
LV-1058 Rīga
 Phone: +371 (0)784 / 2280
 Fax: +371 (0)784 / 2281

Beijer Electronics UAB **LITHUANIA**
 Savanorių Pr. 187
LT-02300 Vilnius
 Phone: +370 (0)5 / 232 3101
 Fax: +370 (0)5 / 232 2980

EUROPEAN REPRESENTATIVES

ALFATRADE Ltd. **MALTA**
 99, Paola Hill
Malta- Paola PLA 1702
 Phone: +356 (0)21 / 697 816
 Fax: +356 (0)21 / 697 817

INTEHSIS srl **MOLDOVA**
 bld. Traian 23/1
MD-2060 Kishinev
 Phone: +373 (0)22 / 66 4242
 Fax: +373 (0)22 / 66 4280

HIFLEX AUTOM.TECHNIEK B.V. **NETHERLANDS**
 Wolweverstraat 22
NL-2984 CD Ridderkerk
 Phone: +31 (0)180 - 46 60 04
 Fax: +31 (0)180 - 44 23 55

Koning & Hartman b.v. **NETHERLANDS**
 Haarlerbergweg 21-23
NL-1101 CH Amsterdam
 Phone: +31 (0)20 / 587 76 00
 Fax: +31 (0)20 / 587 76 05

Beijer Electronics AS **NORWAY**
 Postboks 487
NO-3002 Drammen
 Phone: +47 (0)32 / 24 30 00
 Fax: +47 (0)32 / 84 85 77

Fonseca S.A. **PORTUGAL**
 R. João Francisco do Casal 87/89
PT - 3801-997 Aveiro, Esgueira
 Phone: +351 (0)234 / 303 900
 Fax: +351 (0)234 / 303 910

Sirius Trading & Services srl **ROMANIA**
 Aleea Lacul Morii Nr. 3
RO-060841 Bucuresti, Sector 6
 Phone: +40 (0)21 / 430 40 06
 Fax: +40 (0)21 / 430 40 02

Craft Con. & Engineering d.o.o. **SERBIA**
 Bulevar Svetog Cara Konstantina 80-86
SER-18106 Nis
 Phone: +381 (0)18 / 292-24-4/5
 Fax: +381 (0)18 / 292-24-4/5

INEA SR d.o.o. **SERBIA**
 Izletnicka 10
SER-113000 Smederevo
 Phone: +381 (0)26 / 617 163
 Fax: +381 (0)26 / 617 163

SIMAP s.r.o. **SLOVAKIA**
 Jána Derku 1671
SK-911 01 Trenčín
 Phone: +421 (0)32 743 04 72
 Fax: +421 (0)32 743 75 20

PROCONT, spol. s r.o. Prešov **SLOVAKIA**
 Kúpeľná 1/A
SK-080 01 Prešov
 Phone: +421 (0)51 7580 611
 Fax: +421 (0)51 7580 650

INEA d.o.o. **SLOVENIA**
 Stegne 11
SI-1000 Ljubljana
 Phone: +386 (0)1 / 513 8100
 Fax: +386 (0)1 / 513 8170

Beijer Electronics AB **SWEDEN**
 Box 426
SE-20124 Malmö
 Phone: +46 (0)40 / 35 86 00
 Fax: +46 (0)40 / 93 23 01

Omni Ray AG **SWITZERLAND**
 Im Schörl 5
CH-8600 Dübendorf
 Phone: +41 (0)44 / 802 28 80
 Fax: +41 (0)44 / 802 28 28

GTS **TURKEY**
 Bayraktar Bulvarı Nutuk Sok. No:5
TR-34775 Yukarı Dudullu-Ümraniye-İSTANBUL
 Phone: +90 (0)216 526 39 90
 Fax: +90 (0)216 526 39 95

CSC Automation Ltd. **UKRAINE**
 4-B, M. Raskovoyi St.
UA-02660 Kiev
 Phone: +380 (0)44 / 494 33 55
 Fax: +380 (0)44 / 494-33-66

EURASIAN REPRESENTATIVES

Kazpromautomatiks Ltd. **KAZAKHSTAN**
 Mustafina Str. 7/2
KAZ-470046 Karaganda
 Phone: +7 7212 / 50 11 50
 Fax: +7 7212 / 50 11 50

MIDDLE EAST REPRESENTATIVES

ILAN & GAVISH Ltd. **ISRAEL**
 24 Shenkar St., Kiryat Arie
IL-49001 Petah-Tiqva
 Phone: +972 (0)3 / 922 18 24
 Fax: +972 (0)3 / 924 0761

TEXEL ELECTRONICS Ltd. **ISRAEL**
 2 Ha'umanut, P.O.B. 6272
IL-42160 Netanya
 Phone: +972 (0)9 / 863 39 80
 Fax: +972 (0)9 / 885 24 30

CEG INTERNATIONAL **LEBANON**
 Cebaco Center/Block A Autostrade DORA
Lebanon - Beirut
 Phone: +961 (0)1 / 240 430
 Fax: +961 (0)1 / 240 438

AFRICAN REPRESENTATIVE

CBI Ltd. **SOUTH AFRICA**
 Private Bag 2016
ZA-1600 Isando
 Phone: +27 (0)11 / 977 0770
 Fax: +27 (0)11 / 977 0761