

# mitsubishi

---

## A8GT-50KBF External I/O Module

---

### Mitsubishi General Purpose PC User's Manual

Thank you for choosing the Mitsubishi General Purpose PC Graphic Operation Terminal 800 series. To ensure correct use of this equipment, please read this manual carefully before operating it.



MODEL	A8GT-50KBF-U-E
MODEL CODE	13JL28

IB-NA-66787-A (9707)MEE

---

The United States	Mitsubishi Electronics America, Inc., (Industrial Automation Division) 800 Biemann Court, Mt. Prospect, IL 60056. Phone : (708) 298-9223
Canada	Mitsubishi Electric Sales Canada, Inc., (Industrial Automation Division) 4299 14th Avenue, Markham, Ontario L3R OJ2 Phone : (416) 475-7728
United Kingdom	Mitsubishi Electric UK Ltd., (Industrial Sales Division) Travellers Lane, Hatfield, Herts., AL10 8XB Phone : (0707) 276100
Germany	Mitsubishi Electric Europe GmbH, (Industrial Automation Division) Gothaer Strasse 8, Postfach 1548, D-4030 Ratingen 1 Phone : (02102) 4860
Taiwan	Setsuyo Enterprise Co., Ltd., (106) 11th Fl., Chung-Ling Bldg., 363, Sec. 2, Fu-Hsing S. Rd., Taipei, Taiwan. R.O.C. Phone : (02) 732-0161
Hongkong (& China)	Ryoden International Ltd., (Industrial & Electrical Controls Division) 10/F., Manulife Tower, 169 Electric Rd., North Point, Hong Kong. Phone : 8878870
Singapore (& Malaysia)	MELCO Sales Singapore Pte. Ltd., (Industrial Division) 307 Alexandra Rd. #05-01/02, Mitsubishi Electric Bldg., Singapore 0315. Phone : 4732308
Thailand	F.A. Tech Co., Ltd., 1138/33-34 Rama 3 Rd., Yannawa, Bangkok 10120. Phone : (02) 295-2861-4
Australia	Mitsubishi Electric Australia Pty. Ltd., (Industrial Controls Division) 348 Victoria Rd., Rydalm ere, N.S.W. 2116. Phone : (02) 684-7200
Republic of South Africa	M.S.A. Manufacturing (Pty) Ltd., (Factory Automation Division) P.O. Box 39733, Bramley, Johannesburg 2018. Phone : (011) 444-8080



**MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE: MITSUBISHI DENKI BLDG MARUNOUCHI TOKYO 100 TELEX: J24532 CABLE MELCO TOKYO  
NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN

---

When exported from Japan, this manual does not require application to the Ministry of International Trade and Industry for service transaction permission.

# •SAFETY PRECAUTIONS•

(Read these precautions before using.)

When using Mitsubishi equipment, thoroughly read this manual and the associated manuals introduced in this manual. Also pay careful attention to safety and handle the module properly.

These precautions apply only to Mitsubishi equipment. Refer to the CPU module user's manual for a description of the PC system safety precautions.


These •SAFETY PRECAUTIONS• classify the safety precautions into two categories: "DANGER" and "CAUTION".

## DANGER

Procedures which may lead to a dangerous condition and cause death or serious injury if not carried out properly.

## CAUTION

Procedures which may lead to a dangerous condition and cause superficial to medium injury, or physical damage only, if not carried out properly.

Depending on circumstances, procedures indicated by  CAUTION may also be linked to serious results.

In any case, it is important to follow the directions for usage.

Store this manual in a safe place so that you can take it out and read it whenever necessary. Always forward it to the end user.

## [DESIGN PRECAUTIONS]

### DANGER

- Some faults of the GOT, this unit or connection cables may keep the outputs on or off.  
An external monitoring circuit should therefore be provided to check for output signals which may lead to a serious accident.  
Otherwise, mis-output or misoperation can cause an accident.

## [INSTALLATION PRECAUTIONS]

### **DANGER**

- When installing and removing this module from the GOT main module be sure to shut off the power at all external switches. If all the switches are not turned off, the module could be damaged or malfunction.
- When connecting the bus connection cable to this module be sure to turn off the switch to all external power switches to the GOT and PC CPU. If all the switches are not turned off, it may cause malfunction.

### **CAUTION**

- Use this module in an environment that is within the general specifications written in the GOT User's Manual. If the power supply is used in an environment that is outside of the general specifications then electric shock, fire, malfunction, or product damage or degradation could occur.
- For a correct installation, insert the bus connection cable to this module, A7GT-BUS2S, bus connector conversion module, and base unit connector until you hear it click.  
A bad connection could cause erroneous input or output.
- When installing this module in the GOT main module, install it in the GOT installation area and be sure it is fastened with a module fastening screw that is tightened within the specified torque range.  
If the module fixing screws are loosen, it may cause malfunction, damage or falling of the module.  
If the module fixing screws are too tight, the GOT main module or the screws could break.

## [Wiring Instructions]

### **DANGER**

- Before starting wiring, always switch off all phases of the power supply externally.

### **CAUTION**

- During wiring, care should be taken so that foreign matter such as shield and wire offcuts do not enter this unit.  
Otherwise, a fire, fault or misoperation can occur.

## [WIRNG INSTRUCTIONS]

### CAUTION

- The communication and power cables connected to the module must be fixed securely, e.g. contained in ducts or clamped.  
A failure to do so could cause the cables to dangle, move, or be carelessly pulled, leading to a damaged module or cable or a malfunction due to a cable connection fault.

## [STARTING AND MAINTENANCE PRECAUTIONS]

### DANGER

- While power is on, do not touch the terminals. Otherwise, an electric shock or malfunction could occur.
- Before starting cleaning or terminal screw retightening, always switch off external GOT power in all phases.  
A failure to do so could cause an electric shock.  
Undertightening could cause the module to drop, short-circuit or malfunction.  
Overtightening could cause the module to drop, short-circuit or malfunction

### CAUTION

- Do not disassemble or modify this module.  
Otherwise, a failure, malfunction, injury or fire could occur.
- Do not touch the conductive and electronic parts of this module directly.  
Otherwise, the module could malfunction or fail.
- This module is made of resin. Do not drop it or subject it to hard impact.  
This may cause the module to fail.
- When disconnecting the communication or power cable from the module, do not hold and pull the cable part.  
When disconnecting the cable having a connector, hold the connector plugged in the module.  
Before disconnecting the cable having no connector, loosen the screws in the module.  
If the cable connected to the module is pulled, the module or cable may be damaged or a malfunction may occur due to a cable connection fault.

## [DISPOSAL PRECAUTIONS]

 <b>CAUTION</b>
--

- |   |
|---|
| <ul style="list-style-type: none"><li>● When disposing of this product, treat it as industrial waste.</li></ul> |
|---|

## Revisions

\* The manual number is noted at the lower left of the back cover.

Print Date	*Manual Number	Revision
Jul. 1997	IB (NA)-66787-A	First printing

This manual confers no industrial property rights or any rights of any other kind, nor does it confer any patent licenses. Mitsubishi electric Corporation cannot be held responsible for any problems involving industrial property rights which may occur as a result of using the contents noted in this manual.

## About This Manual

The following product manuals are available. Please use this table as a reference to request the appropriate manual as necessary.

### Detailed Manual

<b>Manual Name</b>	<b>Manual No. (Type Code)</b>
A850GOT Graphic Operation Terminal User's Manual (Packaged with the A850GOT)	IB-66669 (13J847)
A852GOT Graphic Operation Terminal User's Manual (Packaged with the A852GOT)	IB-66767 (13JL15)
A853GOT Graphic Operation Terminal User's Manual (Packaged with the A853GOT)	IB-66785 (13JL26)
Compact Building Block Type I/O Module User's Manual (Optional)	IB-66541 (13JE81)
Building Block Type I/O Module User's Manual (Optional)	IB-66140 (13J643)
GOT Upgrade Additional Manual (Packaged with the Software Package Product Packing)	IB-66744 (13J888)




# Table of Contents

<b>1</b>	<b>Overview</b>	<b>1</b>
<b>2</b>	<b>Components Including in the Package</b>	<b>1</b>
<b>3</b>	<b>Specifications</b>	<b>2</b>
<b>4</b>	<b>System configuration</b>	<b>7</b>
4.1	System Configuration for No Outputs	7
4.2	System Configuration for Outputs	8
4.2.1	System configuration	8
4.2.2	Connection of external I/O unit and terminal block conversion unit.	10
4.2.3	Connection of external inputs and external outputs to the terminal block conversion	12
<b>5</b>	<b>User-fabricated connection cables</b>	<b>14</b>
5.1	cable for connection between external I/O unit and original operator panel	14
5.2	cable for connection between external I/O unit and terminal block conversion unit.	16
<b>6</b>	<b>Parts Identification</b>	<b>18</b>
<b>7</b>	<b>Installation Procedure</b>	<b>19</b>
<b>8</b>	<b>Outline Dimension Drawing</b>	<b>21</b>
<b>APPENDIX</b>		
	<b>Appendix 1 Depth Diagram for Use of the STE</b>	<b>22</b>

# 1 Overview

This user's manual gives the specifications, system configurations, parts identification, installation procedure and outline dimensions of the A8GT-50KBF type external I/O unit (referred to as the external I/O unit).

The external I/O unit is fitted to the A85□GOT type graphic operation terminal (referred to as the GOT) to receive up to 8/64 points of inputs and provide up to 16 points of outputs.



Note: This unit is used with the following versions of software:  
SW2NIW-A8GOTP, SW2NIW-A8SYSP; version J or later

# 2 Accessories

After opening the container, check that the following products are present.

Description	Quantity
External I/O unit	1
External connector (soldered type)	1
This manual	1

### 3 Specifications

Input Specifications		
Input system		Dynamic scan
Number of input points		8/64 points
Isolation system		Photocoupler isolation
Rated input voltage		12VDC                      24VDC
Rated input current		Approx. 4mA                      Approx. 9mA
Operating voltage range		10.2 to 26.4VDC (ripple percentage within 5%)
Max. number of simultaneous input points		100% simultaneous ON (at 26.4VDC)
ON voltage/ON current		8VDC or more/2mA or more
OFF voltage/OFF current		4VDC or less/1mA or less
Input resistance		Approx. 2.4K $\bullet$
Response time *1	ON to OFF	Approx. 0.4ms or less (24VDC)
	OFF to ON	Approx. 0.4ms or less (24VDC)
Dynamic scan cycle		13.3ms


Output Specifications		
Output system		Direct
Number of output points		16 points
Isolation system		Photocoupler isolation
Rated load voltage		12/24VDC
Max. load current*2		0.1A/1 point
Operating load voltage range		10.2 to 26.4VDC (ripple percentage within 5%)
Max. inrush current		0.4A
Leakage current at OFF		0.1mA or less
Max. voltage drop at ON		2.5VDC (0.1A)
Response time*1	ON to OFF	2ms or less
	OFF to ON	2ms or less (resistive load)
Surge suppressor		Clamp diode

I/O Specifications	
External connection system	40-pin connector
Applicable wire size	0.3mm <sup>2</sup>
Operation indicator	None
External supply power	Voltage*3 12/24VDC (10.2 to 26.4V, ripple percentage 5% or less)
	Current 1.65A for external output 0.05A for internal consumption only
Fuse rating*4	2A fuse, unreplaceable
Internal current consumption	0.10A
Weight	250g(0.55lb)
Accessory	1 piece of external wiring connector (soldered type)

\*1: Time in the I/O section.

\*2: The maximum load current varies with the number of simultaneous ON points. Refer to the following information:

Relationships between output load current (common current), number of simultaneous ON points and ambient temperature



\*3: A fuse-blown error will also be displayed when the external supply power switches off.


\*4: The fuse in the output unit is provided to prevent the external wiring from burning out if the outputs of the unit are shorted. Therefore, it may not protect the output elements. The fuse may not be blown if the output elements are damaged in the fault mode other than a short circuit.

### External Connector Pin-Outs

View from the unit front

Connector used: Fujitsu's FCN-364P040-AU

B1 B2 B3 B4 B5 B6 B7 B8 B9 B10 B11 B12 B13 B14 B15 B16 B17 B18 B19 B20




A1 A2 A3 A4 A5 A6 A7 A8 A9 A10 A11 A12 A13 A14 A15 A16 A17 A18 A19 A20

### Pin Numbers and Signal Names of External Connector

Pin Number	Signal Name	Pin Number	Signal Name
1A	XD7	1B	XD6
2A	XD5	2B	XD4
3A	XD3	3B	XD2
4A	XD1	4B	XD0
5A	XSCN7	5B	XSCN8
6A	XSCN5	6B	XSCN4
7A	XSCN3	7B	XSCN2
8A	XSCN1	8B	XSCN0
9A	YDF	9B	YDE
10A	YDD	10B	YDC
11A	YDB	11B	YDA
12A	YD9	12B	YD8
13A	YD7	13B	YD6
14A	YD5	14B	YD4
15A	YD3	15B	YD2
16A	YD1	16B	YD0
17A	HOT24/12	17B	HOT24/12
18A	HOT24/12	18B	RTN24/12
19A	RTN24/12	19B	
20A		20B	FG

## External Connection Diagram (1) (8-point inputs, 16-point outputs)




\*1: A fuse-blown error will also be displayed when the external supply power switches off.

\*2: The fuse in the output unit is provided to prevent the external wiring from burning out if the outputs of the unit are shorted.


Therefore, it may not protect the output elements.

The fuse may not be blown if the output elements are damaged in the fault mode other than a short circuit.

## External Connection Diagram (2) (64-point inputs, 16-point outputs)



\*1: When there is a probability that two or more switches are pressed simultaneously, each switch must be provided with a diode. (Refer to the right figure.)




\*2: A fuse-blown error will also be displayed when the external supply power switches off.

\*3: The fuse in the output unit is provided to prevent the external wiring from burning out if the outputs of the unit are shorted. Therefore, it may not protect the output elements. The fuse may not be blown if the output elements are damaged in the fault mode other than a short circuit.

# 4 System Configuration

The system configuration depends on whether the external I/O unit provides outputs or not.

## 4.1 System Configuration for No Outputs






## 4.2 System Configuration for Outputs


### 4.2.1 System configuration

#### (1) For 8-point inputs



- 1 The cable for connection between external I/O unit and terminal block conversion unit may also be fabricated by the user.

**(2) For 64-point inputs**




- 1 The cable for connection between external I/O unit and terminal block conversion unit may also be fabricated by the user.

## 4.2.2 Connection between the external I/O unit and terminal block conversion unit


### (1) For use of the terminal block conversion unit (A6TBY36-E)

Cable for connection  
between external  
I/O unit and  
terminal block  
conversion unit




## (2) For use of the terminal block conversion unit (A6TBY54-E)

Cable for connection  
between external  
I/O unit and  
terminal block  
conversion unit




## 4.2.3 Connection of external inputs and external outputs to the terminal block conversion unit.

### (1) For use of the terminal block conversion unit (A6TBY36-E)



**(2) For use of the terminal block conversion unit (A6TBY54-E)**



# 5. User-fabricated Connection Cables


The following is the way of fabricating the connection cable which can be fabricated by the user.

## 5.1 Cable for connection between external I/O unit and original operator panel

Fabricate the connection cable in accordance with the following wiring diagram, parts diagram and assembly drawing.

(Max cable length:20m(65.62feet))


### (1)A wiring diagram



## (2) Parts list

Part number	Name	Type	Quantity	Maker
1)	Connector	FCN-361J040-AU	1	FUJITSU LTD
2)	connector cover	FCN-360C040-B	1	
3)	paired sealed cable	UL 2464 AWG <sup>2</sup> 26×20P	•	Oki Electric Cable Co.,Ltd
4)	FG cable	UL 1015 AWG14 or equivalent	1	•
5)	Cable for connection of external input power supply.	•	2	•

## (3) Assembly



### POINT

- The grounding wire (green wire, approx. 1m) coming out of the connector of the user-fabricated connection cable must be connected to the control box or the like.
- Grounding should be independent where possible.
- Use class 3 grounding method (grounding resistance is 100•max.).
- The grounding point should be as near as possible to the external I/O module to minimize the grounding cable length.
- Adjust the grounding cable length according to the grounding position and install a terminal or the like for grounding.
- When grounding, always connect the FG cable for connection with the GOT's power supply terminal block and the FG wire of the user-fabricated connection cable separately.




## 5.2 cable for connection between external I/O unit and terminal block conversion unit.

Fabricate the connection cable in accordance with the following wiring diagram, parts diagram and assembly drawing.

(Max cable length:10m(32.81feet))


### (1)A wiring diagram



## (2) Parts list

Part number	Name	Type	Quantity	Maker
1)	Connector	FCN-361J040-AU	1	FUJITSU LTD
2)	connector cover	FCN-360C040-B	1	
3)	paired sealed cable	UL 2464 AWG <sup>2</sup> 26×20P	•	Oki Electric Cable Co.,Ltd
4)	FG cable	UL 1015 AWG14 or equivalent	1	•


## (3) Assembly



### POINT

- The grounding wire (green wire, approx. 1m) coming out of the connector of the user-fabricated connection cable must be connected to the control box or the like.
- Grounding should be independent where possible.
- Use class 3 grounding method (grounding resistance is 100•max.).
- The grounding point should be as near as possible to the external I/O module to minimize the grounding cable length.
- Adjust the grounding cable length according to the grounding position and install a terminal or the like for grounding.
- When grounding, always connect the FG cable for connection with the GOT's power supply terminal block and the FG wire of the user-fabricated connection cable separately.

## 6 Parts Identification



No.	Name	Description
1)	I/O cable connection interface	Interface for connection of the I/O cable
2)	Unit fixing screws	Screws used to fix the unit to the GOT
3)	Connector	Connector used to plug the unit to the GOT.
4)	Rating plate	•

# 7. Installation Procedure

Mount or dismount the module to or from the GOT in the following


- 1) Thread external I/O module mounting screw holes in the control box or the like. (2- $\phi$ 3.5 mounting holes)

The external I/O module's GOT connection cable is 50cm long. Install the external I/O module within this distance so that the GOT-end connector of the cable may be fitted into the GOT's connector.

When mounting the external I/O module on the back of the control box door, use care to avoid screw holes passing through the control box surface.

- 2) Tighten the module fixing screws (2 pcs.) in the specified torque range 39 to 59N·cm (4 to 6kg·cm).

- 3) Fit the GOT-end connector of the cable into the connector in the GOT outside.





When using the A8GT-50STE option module mounting bracket(referred to as the “STE”. For details, see below.) to fit this module to the back of the GOT main unit ,refer to the A8GT-50STE Option Module Mounting Bracket User’s Manual.

The STE is a mounting bracket used to install the option module (A8GT-50PRF,A8GT-50KBF) to the A85 GOT main unit.

### When using the STE

The option module can be fitted to the GOT main unit.


Control box



### When not using the STE

As the option module is used on the control box, secure an installation space

Control box




### Restrictions on Use of the STE

- The communication module (e.g. A7GT-BUS,A8GT-J61BT15) cannot be fitted to the GOT.
- When performing Operating system installation or monitor data downloading from the DOS/V personal computer to the GOT ,the “25 pins to 9 pins conversion connector” cannot be used on the GOT.

# 8 Outline Dimension Drawing


Unit:mm(inch)



# Appendix

## Appendix 1 Depth Diagram for Use of the STE

---



Unit:mm(inch)